

SINAMICS S120 Combi

Manual · 01/2012

SINAMICS

SIEMENS

SIEMENS

SINAMICS

S120 SINAMICS S120 Combi

Manual




Preface

System overview	1
Line-side power components	2
S120 Combi Power Modules	3
Reinforcement plates	4
External fan unit	5
Topology rules for DRIVE-CLiQ	6
Motor Modules Booksize Compact as expansion axes	7
DC link components	8
Electrically connecting Motor Modules and DC link components	9
Additional system components	10
Encoder system connection	11
Accessories	12
Cabinet design and EMC	13
Service and maintenance	14
Appendix	A

Legal information

Warning notice system

This manual contains notices you have to observe in order to ensure your personal safety, as well as to prevent damage to property. The notices referring to your personal safety are highlighted in the manual by a safety alert symbol, notices referring only to property damage have no safety alert symbol. These notices shown below are graded according to the degree of danger.

 DANGER
indicates that death or severe personal injury will result if proper precautions are not taken.
 WARNING
indicates that death or severe personal injury may result if proper precautions are not taken.
 CAUTION
with a safety alert symbol, indicates that minor personal injury can result if proper precautions are not taken.
CAUTION
without a safety alert symbol, indicates that property damage can result if proper precautions are not taken.
NOTICE
indicates that an unintended result or situation can occur if the relevant information is not taken into account.


If more than one degree of danger is present, the warning notice representing the highest degree of danger will be used. A notice warning of injury to persons with a safety alert symbol may also include a warning relating to property damage.

Qualified Personnel

The product/system described in this documentation may be operated only by **personnel qualified** for the specific task in accordance with the relevant documentation, in particular its warning notices and safety instructions. Qualified personnel are those who, based on their training and experience, are capable of identifying risks and avoiding potential hazards when working with these products/systems.

Proper use of Siemens products

Note the following:

 WARNING
Siemens products may only be used for the applications described in the catalog and in the relevant technical documentation. If products and components from other manufacturers are used, these must be recommended or approved by Siemens. Proper transport, storage, installation, assembly, commissioning, operation and maintenance are required to ensure that the products operate safely and without any problems. The permissible ambient conditions must be complied with. The information in the relevant documentation must be observed.

Trademarks

All names identified by ® are registered trademarks of Siemens AG. The remaining trademarks in this publication may be trademarks whose use by third parties for their own purposes could violate the rights of the owner.

Disclaimer of Liability

We have reviewed the contents of this publication to ensure consistency with the hardware and software described. Since variance cannot be precluded entirely, we cannot guarantee full consistency. However, the information in this publication is reviewed regularly and any necessary corrections are included in subsequent editions.

Preface

Foreword

SINAMICS documentation

The SINAMICS documentation is organized in the following categories:

- General documentation / Catalogs
- User documentation
- Manufacturer / Service documentation

More information

Using the following link, you can find information on the topics:

- Ordering documentation/overview of documentation
- Additional links to download documents
- Using documentation online (find and search in manuals/information)

<http://www.siemens.com/motioncontrol/docu>

Please send any questions about the technical documentation (e.g. suggestions for improvement, corrections) to the following e-mail address:

docu.motioncontrol@siemens.com

My Documentation Manager

Using the following link, you can find information on how to create your own individual documentation based on Siemens' content, and adapt it for your own machine documentation:

<http://www.siemens.com/mdm>

Training

Using the following link, you can find information on SITRAIN - training from Siemens for products, systems and automation engineering solutions:

<http://www.siemens.com/sitrain>

FAQs

You can find Frequently Asked Questions in the Service&Support pages under **Product Support**.

<http://support.automation.siemens.com>

SINAMICS

You can find information on SINAMICS at:

<http://www.siemens.com/sinamics>.

Usage phases and the available tools/documents

Table 1 Usage phase and the available tools/documents

Usage phase	Tools
Orientation	SINAMICS S Sales Documentation
Planning/configuration	SIZER configuration tool
Decision making/ordering	SINAMICS S Catalogs
Configuring/installation	<ul style="list-style-type: none">• SINAMICS S120 Manuals• SINAMICS S120 Combi Manual• SINUMERIK 828D PPU Manual
Commissioning	<ul style="list-style-type: none">• SINAMICS S120 Combi List Manual• SINUMERIK 828D Turning and Milling Commissioning Manual
Usage/operation	<ul style="list-style-type: none">• SINAMICS S120 Function Manual FH1• SINAMICS S120 Combi List Manual
Maintenance/Service	<ul style="list-style-type: none">• SINAMICS S120 Combi Manual• SINAMICS S120 Combi List Manual

Target group

This documentation is intended for machine manufacturers, commissioning engineers, and service personnel who use the SINAMICS drive system.

Benefits

This manual provides information on the components and functions of devices so that the target group is capable of installing, setting up, testing, operating, and troubleshooting the devices safely and correctly.

Standard scope

The scope of the functionality described in this document can differ from the scope of the functionality of the drive system that is actually supplied.

It may be possible for other functions not described in this documentation to be executed in the drive system. This does not, however, represent an obligation to supply such functions with a new control or when servicing.

Functions that are not available in a particular product version of the drive system may be described in the documentation. The functionality of the supplied drive system should only be taken from the ordering documentation.

Extensions or changes made by the machine manufacturer must be documented by the machine manufacturer.

For reasons of clarity, this documentation does not contain all of the detailed information on all of the product types. This documentation cannot take into consideration every conceivable type of installation, operation and service/maintenance.

Technical support

Country-specific telephone numbers for technical support are provided in the Internet under **Contact:**

<http://www.siemens.com/automation/service&support>

EC Declarations of Conformity

The EC Declaration of Conformity for the EMC Directive can be found on the Internet at:

<http://support.automation.siemens.com>

There – as a search term – enter the number **15257461** or contact your local Siemens office.

The EC Declaration of Conformity for the Low Voltage Directive can be found on the Internet at:

<http://support.automation.siemens.com>

There – as a search term – enter the number **22383669** .

Note

When operated in dry areas, SINAMICS S devices conform to the Low Voltage Directive 73/23/EEC or 2006/95/EEC.

Note

SINAMICS S devices fulfill EMC Directive 89/336/EEC or 2004/108/EEC in the configuration specified in the associated EC Declaration of Conformity for EMC and when the Configuration Manual EMC Installation Guideline, order number 6FC5297-0AD30-0□P□, is implemented.

Note

The Manual describes a desired state which, if maintained, ensures the required level of operational reliability and compliance with EMC limit values.

Should there be a deviation from the Equipment Manual requirements, appropriate actions (e.g. measurements) must be taken to check/prove that the desired reliable operation is ensured and EMC limit values are complied with.

EMC limit values in South Korea

이 기기는 업무용(A급) 전자파적합기기로서 판매자 또는 사용자는 이 점을 주의하시기 바라며, 가정외의 지역에서 사용하는 것을 목적으로 합니다.

For sellers or other user, please keep in mind that this device is an A-grade electromagnetic wave device. This device is intended to be used in areas other than home.

The EMC limit values to be complied with for South Korea correspond to the limit values of the EMC product standard for variable-speed electric drives EN 61800-3, Category C2 or limit value class A, Group 1 according to EN55011. By applying suitable supplementary measures, the limit values according to Category C2 or according to limit value class A, Group 1 are maintained. Further, additional measures may be required, for instance, using an additional radio interference suppression filter (EMC filter). The measures for EMC-compliant design of the system are described in detail in this manual respectively in the Installation Guideline EMC.

The measures for EMC-compliant design of the system are described in detail in this manual respectively in the Installation Guideline EMC.

Please note that the final statement on compliance with the standard is given by the respective label attached to the individual unit.

Spare parts

Spare parts are available on the Internet at:

<http://support.automation.siemens.com/WW/view/de/16612315>

Test certificates

The Safety Integrated functions of SINAMICS components are generally certified by independent institutes. An up-to-date list of certified components is available on request from your local Siemens office. If you have any questions relating to certifications that have not been completed, please ask your Siemens contact.

ESD information

CAUTION

Electrostatic sensitive devices (ESDs) are individual components, integrated circuits, or boards that may be damaged by either electrostatic fields or electrostatic discharge.

Regulations for handling ESD components:

When handling electronic components, you must ensure that the person carrying out the work, the work place, and packaging are properly grounded.

Personnel may only come into contact with electronic components, if

- They are grounded with an ESD wrist band, or
- They are in ESD areas with conductive flooring, ESD shoes or ESD grounding straps.

Electronic boards should only be touched if absolutely necessary. They must only be handled on the front panel or, in the case of printed circuit boards, at the edge.

Electronic boards must not come into contact with plastics or items of clothing containing synthetic fibers.

Boards must only be placed on conductive surfaces (work surfaces with ESD surface, conductive ESD foam, ESD packing bag, ESD transport container).

Do not place boards near display units, monitors, or television sets (minimum distance from screen: 10 cm).

Measurements may only be taken on boards when the measuring device is grounded (via protective conductors, for example) or the measuring probe is briefly discharged before measurements are taken with an isolated measuring device (for example, touching a bare metal housing).

DANGER

Electrical, magnetic and electromagnetic fields (EMF) that occur during operation can pose a danger to persons who are present in the direct vicinity of the product - especially persons with pacemakers, implants, or similar devices.

The relevant directives and standards must be observed by the machine/plant operators and persons present in the vicinity of the product. These are, for example, EMF Directive 2004/40/EEC and standards EN 12198-1 to -3 applying to the European Economic Area (EEA) and in Germany the accident prevention regulation BGV 11 and the associated rule BGR 11 "Electromagnetic fields" from the German employer's liability accident insurance association.

These state that a hazard analysis must be drawn up for every workplace, from which measures for reducing dangers and their impact on persons are derived and applied, and exposure and danger zones are defined and observed.

The relevant safety notes in each chapter must be observed.

General safety instructions

 **DANGER**

Commissioning is absolutely prohibited until it has been completely ensured that the machine, in which the components described here are to be installed, is in full compliance with the provisions of the EC Machinery Directive.

Only qualified personnel may install, commission and service SINAMICS S units.

The personnel must take into account the information provided in the technical customer documentation for the product, and be familiar with and observe the specified danger and warning notices.

Operational electrical equipment and motors have parts and components which are at hazardous voltage levels that may cause serious injuries or death when touched.

All work on the electrical system must be carried out when the system has been disconnected from the power supply.

In combination with the drive system, the motors are generally approved for operation on TN and TT line supplies with grounded neutral and on IT line supplies.

In operation on IT line supplies, the occurrence of a first fault between an active part and ground must be signaled by a monitoring device. In accordance with IEC 60364-4-41 it is recommended that the first fault should be eliminated as quickly as practically possible.

For line supplies with a grounded phase conductor, an isolating transformer with grounded neutral (secondary side) must be connected between the supply and the drive system to protect the motor insulation from excessive stress. The majority of TT line supplies have a grounded phase conductor, so in this case an isolating transformer must be used.

 **DANGER**

Correct and safe operation of SINAMICS S units assumes correct transportation in the transport packaging, correct long-term storage in the transport packaging, setup and installation, as well as careful operation and maintenance.


The details in the catalogs and proposals also apply to the design of special equipment versions.


In addition to the danger and warning information provided in the technical customer documentation, the applicable national, local, and system-specific regulations and requirements must be taken into account.

According to EN 61800-5-1 and UL 508 only safely isolated protective extra-low voltages of the electronic modules may be connected to all connections and terminals.

 **DANGER**




Using protection against direct contact via DVC A (PELV) is only permissible in areas with equipotential bonding and in dry rooms indoors. If these conditions are not fulfilled, other protective measures against electric shock (e.g. protection through protective impedances or limited voltage, or use of protection class I and II) must be used.

 DANGER
<p>As part of routine tests, SINAMICS S components will undergo a voltage test in accordance with EN 61800-5-1. Before the voltage test is performed on the electrical equipment of machines to EN 60204-1, Section 18.4, all connections of SINAMICS units must be disconnected/unplugged to prevent them from being damaged.</p> <p>Motors should be connected up corresponding to the circuit diagram supplied with the motor (refer to the connection examples of Motor Modules). They must not be connected directly to the three-phase supply because this will damage them.</p>

 WARNING
<p>Operating the equipment in the immediate vicinity (< 1.8 m) of cell phones with a transmitter power of > 1 W may cause the equipment to malfunction.</p>

Explanation of symbols

Table 2 Symbols

Symbol	Meaning
	Protective earth (PE)
	Ground (e.g. M 24 V)
	Functional ground Equipotential bonding

Residual risks

Residual risks of power drive systems

The control and drive components of a power drive system (PDS) are approved for industrial and commercial use in industrial line supplies. Their use in public line supplies requires a different configuration and/or additional measures.

These components may only be operated in closed housings or in higher-level control cabinets with protective covers that are closed, and when all of the protective devices are used.

These components may only be handled by qualified and trained technical personnel who are knowledgeable and observe all of the safety information and instructions on the components and in the associated technical user documentation.

When carrying out a risk assessment of a machine in accordance with the EU Machinery Directive, the machine manufacturer must consider the following residual risks associated with the control and drive components of a power drive system (PDS).

1. Unintentional movements of driven machine components during commissioning, operation, maintenance, and repairs caused by, for example:
 - Hardware defects and/or software errors in the sensors, controllers, actuators, and connection technology
 - Response times of the controller and drive
 - Operating and/or ambient conditions not within the scope of the specification
 - Condensation / conductive contamination
 - Parameterization, programming, cabling, and installation errors
 - Use of radio devices / cellular phones in the immediate vicinity of the controller
 - External influences / damage
2. Exceptional temperatures as well as emissions of light, noise, particles, or gas caused by, for example:
 - Component malfunctions
 - Software errors
 - Operating and/or ambient conditions not within the scope of the specification
 - External influences / damage
3. Hazardous shock voltages caused by, for example:
 - Component malfunctions
 - Influence of electrostatic charging
 - Induction of voltages in moving motors
 - Operating and/or ambient conditions not within the scope of the specification
 - Condensation / conductive contamination
 - External influences / damage

4. Electrical, magnetic and electromagnetic fields generated in operation that can pose a risk to people with a pacemaker, implants or metal replacement joints, etc. if they are too close.
5. Release of environmental pollutants or emissions as a result of improper operation of the system and/or failure to dispose of components safely and correctly.

Note

Functional safety of SINAMICS components

The components must be protected against conductive contamination (e.g. by installing them in a cabinet with degree of protection IP54B to EN 60529).

Assuming that conductive contamination at the installation site can definitely be excluded, a lower degree of cabinet protection may be permitted.

For more information about residual risks of the components in a power drive system, see the relevant chapters in the technical user documentation.

Table of contents

	Preface	3
1	System overview.....	21
1.1	SINAMICS S120 Combi components	21
1.2	System data	23
1.3	Derating as a function of the installation altitude and ambient temperature.....	25
1.4	Standards.....	26
2	Line-side power components	29
2.1	Introduction	29
2.2	Information on the disconnecter unit.....	30
2.3	Overcurrent protection by means of line fuses and circuit breakers.....	30
2.4	Line supply connection via residual-current devices	33
2.5	Overvoltage protection.....	34
2.6	Line filters	35
2.6.1	Description	35
2.6.2	Safety information	35
2.6.3	Interface description.....	37
2.6.3.1	Overview	37
2.6.3.2	Line/load connection	38
2.6.4	Dimension drawing	39
2.6.5	Technical data.....	39
2.7	Line reactors	40
2.7.1	Description	40
2.7.2	Safety information	40
2.7.3	Connection description	41
2.7.3.1	Overview	41
2.7.3.2	Line/load connection	41
2.7.4	Dimension drawings.....	42
2.7.5	Technical data.....	44
2.8	Line connection versions	45
2.8.1	Ways of connecting the line supply	45
2.8.2	Operating line connection components on the line supply	46
2.8.3	Operation of the line connection components via a transformer	47
2.8.3.1	Safety information	47
2.8.3.2	Line connection conditions.....	47
2.8.3.3	Dimensioning an isolating transformer/autotransformer for several loads	48
2.8.3.4	Operating line connection components via an autotransformer	53
2.8.3.5	Operating line connection components via an isolating transformer	54

3	S120 Combi Power Modules	57
3.1	Introduction	57
3.1.1	Description	57
3.1.2	Module versions	59
3.1.3	Approved controls	59
3.1.4	Expansion axes that can be connected	60
3.2	Safety information	61
3.3	Interface description	64
3.3.1	Overview diagrams	64
3.3.2	X1 line connection	69
3.3.3	X2-X5 motor connection	70
3.3.4	X11 brake connection	71
3.3.5	X12/X13 fan connection	72
3.3.6	X21/X22 EP terminals	72
3.3.7	X200-X205 DRIVE-CLiQ interfaces	74
3.3.8	X220 TTL encoder	76
3.3.9	X224 24 V connector	80
3.4	Connection examples	81
3.5	Meaning of the LEDs on the S120 Combi	84
3.6	Dimension drawings	85
3.7	Installation	86
3.7.1	Drilling patterns and installation cut-outs	86
3.7.2	Installing an S120 Combi Power Module	88
3.8	Electrical connection	89
3.8.1	Line supply cable	90
3.8.2	Power cables for motors	91
3.8.3	Signal cables at the EP terminals	92
3.9	Technical data	93
3.9.1	Characteristics	98
4	Reinforcement plates	101
4.1	Description	101
4.2	Installation	102
4.3	Technical data	104
5	External fan unit	105
5.1	Description	105
5.2	Overview	105
5.3	Dimension drawing	107
5.4	Installation	108
5.5	Technical data	110

6	Topology rules for DRIVE-CLiQ	111
6.1	Connection examples	113
6.1.1	Operation with a 3 axes Power Module	113
6.1.2	Operation with a 4 axes Power Module	115
7	Motor Modules Booksize Compact as expansion axes	119
7.1	Description	119
7.2	Safety information	119
7.3	Interface description.....	122
7.3.1	Overview	122
7.3.2	X1/X2 motor connection.....	124
7.3.3	X11/X12 motor brake connection	125
7.3.4	X21/X22 EP terminals / temperature sensor Motor Module	126
7.3.5	X200-X203 DRIVE-CLiQ interface.....	127
7.4	Connection example	128
7.5	Meaning of the LEDs on the Motor Module Booksize Compact.....	129
7.6	Dimension drawings.....	130
7.7	Installation.....	133
7.8	Technical data.....	134
7.8.1	Characteristics	136
8	DC link components	141
8.1	Braking Module Booksize	141
8.1.1	Description	141
8.1.2	Safety information	142
8.1.3	Interface description.....	143
8.1.3.1	Overview	143
8.1.3.2	X1 braking resistor connection.....	144
8.1.3.3	X21 digital inputs/outputs.....	145
8.1.4	Connection example	146
8.1.5	Meaning of LEDs	147
8.1.6	Dimension drawing	148
8.1.7	Installation.....	149
8.1.8	Technical data.....	150
8.1.8.1	Characteristic curves	151
8.1.8.2	Configuration instructions	152
8.2	Control Supply Module CSM.....	153
8.2.1	Description	153
8.2.2	Safety information	154
8.2.3	Interface description.....	155
8.2.3.1	Overview	155
8.2.3.2	X1 line connection.....	156
8.2.3.3	X21 signaling contact.....	157
8.2.3.4	X24 24 V terminal adapter	158
8.2.3.5	S1 DIP switch.....	159
8.2.4	Connection example	160
8.2.5	Meaning of the LEDs on the Control Supply Module.....	162
8.2.6	Dimension drawing	163

8.2.7	Installation	164
8.2.8	Technical data	165
8.3	Braking resistors	166
8.3.1	Description	166
8.3.2	Safety information	166
8.3.3	Dimension drawings	167
8.3.4	Technical data	169
9	Electrically connecting Motor Modules and DC link components	171
9.1	Introduction	171
9.2	Removing the front cover and opening the DC link cover on the S120 Combi	171
9.3	Connection of DC link busbars and 24 V busbars	173
9.4	Connecting an additional component.....	175
10	Additional system components	177
10.1	Terminal Module TM54F	177
10.1.1	Description	177
10.1.2	Safety information	178
10.1.3	Interface description.....	178
10.1.3.1	Overview	178
10.1.3.2	X500/X501 DRIVE-CLiQ interfaces	179
10.1.3.3	X514 power supply for digital outputs and sensors	180
10.1.3.4	X520 sensor power supply.....	180
10.1.3.5	X521 fail-safe digital inputs + power supply with forced dormant error detection	181
10.1.3.6	X522 fail-safe digital inputs	182
10.1.3.7	X523 fail-safe digital output.....	183
10.1.3.8	X524 Electronics power supply.....	184
10.1.3.9	X525 fail-safe digital output.....	185
10.1.3.10	X531 fail-safe digital inputs + power supply with forced dormant error detection	186
10.1.3.11	X532 fail-safe digital inputs	187
10.1.3.12	X533 fail-safe digital output.....	188
10.1.3.13	X535 fail-safe digital output.....	189
10.1.4	Connection example	190
10.1.5	Meaning of LEDs.....	191
10.1.6	Dimension drawing.....	193
10.1.7	Installation	194
10.1.8	Protective conductor connection and shield support	195
10.1.9	Technical data	196
10.2	DRIVE-CLiQ Hub Module DMC20	197
10.2.1	Description	197
10.2.2	Safety information	197
10.2.3	Interface description.....	198
10.2.3.1	Overview	198
10.2.3.2	X524 Electronics power supply.....	199
10.2.3.3	X500 - X505 DRIVE-CLiQ interfaces	199
10.2.3.4	Meaning of the LED on the DMC20	200
10.2.4	Dimension drawing.....	201
10.2.5	Installation	202
10.2.6	Technical data	203

10.3	DRIVE-CLiQ Hub Module External DME20	204
10.3.1	Description	204
10.3.2	Safety information	204
10.3.3	Interface description.....	205
10.3.3.1	Overview	205
10.3.3.2	X524 Electronics power supply.....	206
10.3.3.3	X500-X505 DRIVE-CLiQ interfaces	207
10.3.4	Dimension drawing	208
10.3.5	Installation.....	209
10.3.6	Technical data.....	209
10.3.7	Specifications for use with UL approval.....	210
11	Encoder system connection.....	211
11.1	Sensor Module Cabinet-Mounted SMC20	211
11.1.1	Description	211
11.1.2	Safety information	211
11.1.3	Interface description.....	212
11.1.3.1	Overview	212
11.1.3.2	X500 DRIVE-CLiQ interface	213
11.1.3.3	X520 encoder system interface	214
11.1.3.4	X524 Electronics power supply.....	215
11.1.3.5	Meaning of LEDs on the Sensor Module Cabinet-Mounted SMC20	216
11.1.4	Dimension drawing	217
11.1.5	Installation.....	218
11.1.6	Technical data.....	219
11.2	Sensor Module External SME20.....	220
11.2.1	Description	220
11.2.2	Safety Information	220
11.2.3	Interface description.....	221
11.2.3.1	Overview	221
11.2.3.2	Connection example	221
11.2.3.3	DRIVE-CLiQ interface.....	222
11.2.3.4	Encoder system interface	223
11.2.4	Dimension drawing	224
11.2.5	Installation.....	225
11.2.6	Technical data.....	226
11.3	Sensor Module External SME25.....	228
11.3.1	Description	228
11.3.2	Interface description.....	228
11.3.2.1	Overview	228
11.3.2.2	Connection example	229
11.3.2.3	DRIVE-CLiQ interface.....	229
11.3.2.4	Encoder system interface	230
11.3.3	Dimension drawing	231
11.3.4	Installation.....	232
11.3.5	Technical data.....	233
12	Accessories	235
12.1	DRIVE-CLiQ cabinet bushing	235
12.1.1	Description	235
12.1.2	Safety Information.....	235

12.1.3	Interface description.....	236
12.1.3.1	Overview	236
12.1.4	Dimension drawing.....	236
12.1.5	Installation	237
12.1.6	Technical data.....	239
12.2	DRIVE-CLiQ coupling	240
12.2.1	Description	240
12.2.2	Safety information	240
12.2.3	Interface description.....	240
12.2.3.1	Overview	240
12.2.4	Dimension drawing.....	241
12.2.5	Installation	242
12.2.6	Technical data.....	242
13	Cabinet design and EMC.....	243
13.1	General information.....	243
13.2	Safety information	244
13.3	Directives.....	244
13.4	Notes on electromagnetic compatibility (EMC).....	245
13.5	Cable shielding and routing.....	246
13.6	24 V DC supply	248
13.6.1	General information.....	248
13.6.2	24 V power supply and connection of components	250
13.6.3	Overcurrent protection in the 24 V solid-state circuit.....	252
13.6.4	Typical 24 V current consumption of the components.....	253
13.6.5	Selecting power supply units.....	255
13.7	Connection system.....	256
13.7.1	DRIVE-CLiQ signal cables.....	256
13.7.2	Power cables for motors	258
13.7.2.1	Approved power cables.....	258
13.7.3	Current-carrying capacity and derating factors for power cables and signal cables	260
13.7.4	Connectable conductor cross-sections for spring-loaded terminals	262
13.7.5	Connectable conductor cross-sections for screw terminals.....	262
13.8	Protective connection and equipotential bonding	264
13.9	Note on control cabinet cooling.....	265
13.9.1	General information.....	265
13.9.2	Ventilation.....	269
13.9.3	Dimensioning Climate Control Equipment	271
13.9.4	Power loss of components in rated operation.....	272
13.9.4.1	General information.....	272
13.9.4.2	Power losses for SINUMERIK 828D, DC link components and supplementary system components.....	272
13.9.4.3	Power losses for S120 Combi Power Modules.....	273
13.9.4.4	Power loss for line filters and line reactors	273
13.9.4.5	Electronics losses of power units.....	274
13.9.4.6	Losses in partial-load operation	275

14	Service and maintenance	277
14.1	Technical Support	277
14.2	Spare parts.....	278
14.3	Replacing the fan	279
14.3.1	Safety instructions when replacing a fan	279
14.3.2	Replacing the Internal fan on the S120 Combi Power Module	280
14.3.3	Replacing the fan on the Motor Modules Booksize Compact.....	282
14.3.4	Replacing the fan on the Control Supply Module	284
14.4	Cleaning the S120 Combi heat sink	286
14.5	Forming the DC link capacitors.....	287
14.6	Recycling and disposal	288
A	Appendix.....	289
A.1	List of abbreviations	289
	Index.....	299

System overview

1.1 SINAMICS S120 Combi components

System components

- Line-side power components such as fuses and contactors to switch the energy supply
- Reactors and filters to maintain EMC regulations
- Motor Modules for 1 - 2 expansion axes, which operate as inverters and provide the energy to the connected motors
- DC link components (Braking Module, Control Supply Module) used optionally for stabilizing the DC link voltage
- Additional system components and encoder system connections to expand the functionality and to handle various interfaces for encoders and process signals.

The SINAMICS S120 Combi is intended for installation in a control cabinet. It sets itself apart as a result of the following properties:

- Easy to handle, simple installation and wiring
- Practical connection system, cable routing in accordance with EMC requirements
- Standardized design, seamless integration

Application and cooling method

The S120 Combi Power Module is optimized as a drive for machine tools and processing machines with 3-6 axes. The Power Module is available with the "external air cooling" cooling method.

Motor Modules in the booksize compact format are used as expansion axes.

1.1 SINAMICS S120 Combi components




Figure 1-1 Connection example, S120 Combi 4 axes Power Module with 2 expansion axes (maximum expansion stage)

1.2 System data

Technical data

The following technical data apply for SINAMICS S120 Combi Power Modules.

Electrical data	
Line connection voltage	3-ph. 380 V AC -10 % to 3-ph. 480 V AC +10 % Above 2000 m installation altitude, refer to the characteristic for voltage derating
Line frequency	45 Hz to 66 Hz
Line supply types	TN, TT, and IT line supplies
Electronics power supply	24 V DC -15/+20 % ¹⁾ , safety extra-low voltage DVC A (PELV)
Short-circuit current rating SCCR in accordance with UL508C (up to 600 V)	1.1 kW – 447 kW: 65 kA
Interference suppression to EN 61800-3	Category C2 for plant and system versions in conformance with the documentation
Overvoltage category	III to EN 61800-5-1
Degree of contamination	2 according to EN 61800-5-1

1) If a motor holding brake is used, restricted voltage tolerances (24 V ± 10 %) may have to be taken into account.

Environmental conditions	
Degree of protection	IP20 or IPXXB to EN 60529, open type to UL508
Protection class for line current circuits Protection class for electronic circuits	I (with protective conductor connection) and III (protective extra low voltage DVC A / PELV) acc. to EN 61 800-5-1
Permissible cooling medium temperature (air) and installation altitude in operation	0 °C to +45 °C up to an installation altitude of 1000 m without derating, installation altitude >1000 °C up to 4000 m, see the derating characteristic with respect to the installation altitude or reduction of the ambient temperature by 3.5 K per 500 m.
Chemically active substances <ul style="list-style-type: none"> Long-term storage in the transport packaging Transport in the transport packaging Operation 	Class 1C2 to EN 60721-3-1 Class 2C2 to EN 60721-3-2 Class 3C2 to EN 60721-3-3
Biological environmental conditions <ul style="list-style-type: none"> Long-term storage in the transport packaging Transport in the transport packaging Operation 	Class 1B1 to EN 60721-3-1 Class 2B1 to EN 60721-3-2 Class 3B1 to EN 60721-3-3

System overview

1.2 System data

Environmental conditions	
Vibratory load <ul style="list-style-type: none"> • Long-term storage in the transport packaging • Transport in the transport packaging • Operation 	Class 1M2 to EN 60721-3-1 Class 2M3 to EN 60721-3-2 Test values: Frequency range: 10 Hz to 58 Hz With constant deflection of 0.075 mm Frequency range: 58 Hz to 200 Hz With constant acceleration of 1 g
Shock load <ul style="list-style-type: none"> • Long-term storage in the transport packaging • Transport in the transport packaging • Operation 	Class 1M2 acc. to EN 60721-3-1 Class 2M3 acc. to EN 60721-3-2 Test values: 15 g / 11 ms
Climatic environmental conditions <ul style="list-style-type: none"> • Long-term storage in the transport packaging • Transport in the transport packaging • Operation 	Class 1K4 acc. to EN 60721-3-1 Temperature -25 °C to +55 °C Class 2K4 acc. to EN 60721-3-2 Temperature -40 °C to +70 °C Class 3K3 acc. to EN 60721-3-3 Temperature +0 °C to +45 °C Relative air humidity 5% to 95 % Oil mist, salt mist, formation of ice, moisture condensation, dripping, spraying, splashing water, and water jets not permissible

Certificates	
Declarations of Conformity	CE (Low Voltage and EMC Directives)
Approvals	cURus

1.3 Derating as a function of the installation altitude and ambient temperature

The S120 Combi Power Modules and Motor Modules Booksize Compact are designed for operation at an ambient temperature of 40 °C, installation altitudes up to 1000 m above sea level and the relevant specified pulse frequency.

The air pressure and therefore air density drop at altitudes above sea level. At these altitudes, the same quantity of air does not have the same cooling effect and the air gap between two electrical conductors can only insulate a lower voltage. Typical values for air pressure are summarized in the table below:

Table 1- 1 Air pressure for various installation altitudes

Installation altitude above sea level in [m]	0	2000	3000	4000	5000
Air pressure in mbar [kPa]	100	80	70	62	54

The output current must be reduced if the modules are operated at ambient temperatures above 40 °C (see derating characteristics for the individual modules). Ambient temperatures above 55 °C are not permissible.

The air gaps inside the devices can insulate surge voltages of surge voltage category III in accordance with EN 60664-1 up to an installation altitude of 2000 m. At installation altitudes above 2000 m, the Power Modules must be connected using an isolating transformer. The isolating transformer reduces surge voltages of surge voltage category III in power supplies to surge voltages of surge category II at the power terminals of the Power Modules and thereby conforms to the permissible voltage values for air gaps inside the unit. The design of the secondary line supply system must be as follows:

- TN system with grounded star point (no grounded outer conductor)
- IT system

A reduction of the line supply voltage phase-phase is not necessary.

1.4 Standards

Note

The standards listed in the table below are non-binding and do not in any way claim to be complete. The standards listed do not represent a guaranteed property of the product.

Only the statements made in the Declaration of Conformity shall be deemed binding.

Table 1-2 Fundamental, application-relevant standards in succession: EN, IEC/ISO, DIN, VDE

Standards*	Title
EN 1037 ISO 14118 DIN EN 1037	Safety of machinery; avoiding unexpected starting
EN ISO 9001 ISO 9001 DIN EN ISO 9001	Quality management systems - requirements
EN ISO 12100-x ISO 12100-x DIN EN ISO 12100-x	Safety of Machinery; General Design Guidelines; Part 1: Basic terminology, methodology Part 2: Technical Principles and Specifications
EN ISO 13849-x ISO 13849-x DIN EN ISO 13849-x	Safety of machinery; safety-related parts of control systems; Part 1: General basic design principles Part 2: Validation
EN ISO 14121-1 ISO 14121-1 DIN EN ISO 14121-1	Safety of Machinery - Risk Assessment; Part 1: Guidelines
EN 55011 CISPR 11 DIN EN 55011 VDE 0875-11	Industrial, scientific and medical high-frequency devices (ISM devices) - radio interference - limit values and measuring techniques
EN 60146-1-1 IEC 60146-1-1 DIN EN 60146-1-1 VDE 0558-11	Semiconductor converters; general requirements and line-commutated converters; Part 1-1: Defining the basic requirements
EN 60204-1 IEC 60204-1 DIN EN 60204-1 VDE 0113-1	Electrical equipment of machines; Part 1: General definitions
EN 60228 IEC 60228 DIN EN 60228 VDE0295	Conductors for cables and insulated leads
EN 60269-1 IEC 60269-1 DIN EN 60269-1 VDE 0636-1	Low-voltage fuses; Part 1: General requirements

Standards*	Title
IEC 60287-1 to -3	Cables - Calculation of the current carrying capacity Part 1: Current carrying capacity equations (100 % load factor) and calculating the losses Part 2: Thermal resistance - Part 3: Main sections for operating conditions
HD 60364-x-x IEC 60364-x-x DIN VDE 0100-x-x VDE 0100-x-x	Erection of power installations with nominal voltages up to 1000 V; Part 200: Definitions Part 410: Protection for safety, protection against electric shock Part 420: Protection for safety, protection against thermal effects Part 430: Protection of cables and conductors for over-current Part 450: Protection for safety, protection against undervoltage Part 470: Protection for safety; use of protection for safety Part 5xx: Selecting and erecting electrical equipment Part 520: Wiring systems Part 540: Earthing, protective conductor, potential bonding conductor Part 560: Electrical equipment for safety purposes
EN 60439 IEC 60439 DIN EN 60439 VDE 0660-500	Low-voltage switchgear assemblies; Part 1: Type-tested and partially type-tested assemblies
EN 60529 IEC 60529 DIN EN 60529 VDE 0470-1	Degrees of protection provided by enclosures (IP code)
EN 60721-3-x IEC 60721-3-x DIN EN 60721-3-x	Classification of environmental conditions Part 3-0: Classification of environmental parameters and their severities; Introduction Part 3-1: Classification of environmental parameters and their severities; Long-term storage Part 3-2: Classification of environmental parameters and their severities; Transport Part 3-3: Classification of environmental parameters and their severities; stationary use, weather protected
EN 60947-x-x IEC 60947 -x-x DIN EN 60947-x-x VDE 0660-x	Low-voltage switchgear
EN 61000-6-x IEC 61000-6-x DIN EN 61000-6-x VDE 0839-6-x	Electromagnetic compatibility (EMC) Part 6-1: Generic standard; Immunity for residential, commercial and light-industrial environments Part 6-2: Generic standards; Immunity for industrial environments Part 6-3: Generic standards; Generic standard emission for residential, commercial and light-industrial environments Part 6-4: Generic standards; Generic standard noise emission for industrial environments
EN 61140 IEC 61140 DIN EN 61140 VDE 0140-1	Protection against electric shock; Common aspects for installation and equipment
EN 61800-2 IEC 61800-2 DIN EN 61800-2 VDE 0160-102	Adjustable-speed electrical power drive systems; Part 2: General requirements - Rating specifications for low-voltage adjustable frequency a.c. power drive systems
EN 61800-3 IEC 61800-3 DIN EN 61800-3 VDE 0160-103	Adjustable-speed electrical power drive systems; Part 3: EMC - Requirements and specific test methods

1.4 Standards

Standards*	Title
EN 61800-5-x IEC 61800-5-x DIN EN 61800-5-x VDE 0160-105-x	Adjustable-speed electrical power drive systems; Part 5: Safety requirements; Main section 1: Electrical, thermal and energy requirements Main section 2: Functional safety requirements
EN 62061 IEC 62061 DIN EN 62061 VDE 0113-50	Safety of machinery; Functional safety of safety-related electrical, electronic and programmable electronic control systems
UL 50 CSA C22.2 No. 94.1	Enclosures for Electrical Equipment
UL 508 CSA C22.2 No. 142	Industrial Control Equipment Process Control Equipment
UL 508C CSA C22.2 No. 14	Power Conversion Equipment Industrial Control Equipment

* The technical requirements in the standards listed are not necessarily identical.

Line-side power components

2.1 Introduction

The following components should be used to connect the S120 Combi drive line-up to the line supply:

- Line disconnector
- Overcurrent protection device (line fuse or circuit breaker)
- Line contactor (this is required for electrical isolation)
- Line filter
- Line reactor (always required)

The line connection for a SINAMICS S120 Combi comprises in addition to the regionally required protective devices, an optional line filter and a line reactor:




Figure 2-1 Overview diagram, line connection

2.2 Information on the disconnecter unit

A line disconnecter is required to correctly disconnect the drive line-up from the line supply. The line disconnecter of the machine's electrical equipment can be used for this purpose. The line disconnecter must be selected in compliance with the requirements of the internationally binding standard relating to the electrical equipment of machines EN 60204-1, Section 5.3. The relevant technical data and any other loads connected to the electrical equipment must be taken into account when making your selection.

NOTICE
If an operational drive line-up is switched off using a line disconnecter, then the voltage at interface X21, terminal 3 (EP +24 V) and 4 (EP M) must first be interrupted at the S120 Combi. This can be achieved with a leading disconnecting auxiliary contact (≥ 10 ms), for example.
This protects external loads located parallel to the drive on the same switching component.

The accessories required for the line disconnecter must be selected from the manufacturer catalogs. See also catalog NC61.

2.3 Overcurrent protection by means of line fuses and circuit breakers

Line fuses and circuit breakers should be used for the line/overcurrent protection in order to limit the damage to the S120 Combi if a fault does occur. NH, D, and DO type fuses with a gL characteristic or suitable circuit breakers according to IEC 60947 can be used for this purpose.

Table 2- 1 Characteristics of the line fuses and circuit breakers for S120 Combi Power Modules

Infeed	Protective device				Prospective short-circuit current	
	Fuse		Circuit breaker		Minimum value	Maximum value
	Rated current	Tripping time	Rated current	Tripping time		
16 kW	35 A	< 10 ms	35 A	< 15 ms	> 1 kA	< 65 kA
20 kW	63 A	< 10 ms	63 A	< 15 ms	> 2.5 kA	< 65 kA

Table 2- 2 Recommended LV HRC line fuses (gL) and circuit breakers for S120 Combi Power Modules

Infeed	Recommended line fuse	Recommended circuit breaker
16 kW	3NA3814	3RV1031-4FA10
20 kW	3NA3822	3RV1041-4JA10

 **DANGER**

As a general rule, the higher loop impedance of TT line supplies means they are not suitable for tripping the installed overcurrent protection devices within the prescribed period should an insulation fault occur. If TT line supplies are used, residual-current-operated circuit breakers (refer to the chapter titled "Residual-current-operated circuit breakers (RCD)") should ideally be used in addition to the overcurrent protection devices.

 **WARNING****Selecting the overcurrent protection devices**

In order to avoid the risk of fire or electric shock, overcurrent protection devices should be dimensioned so that in the case of a fault, the equipment is switched off sufficiently quickly. At the place of installation, measurements should be performed to check whether a suitably high short-circuit current flows to trip the protective devices quickly enough. To do this, the loop impedance (faulted-circuit impedance) should be measured and the prospective short-circuit current calculated as well as the time-current characteristics of the overcurrent protection devices calibrated using measuring instruments according to EN 61557-3.

If the necessary break times are not maintained, then the next smaller overcurrent protection device must be used.

 **WARNING**

It is not permissible to overdimension fuses as this can result in significant levels of danger and also faults.

Note

The devices can be connected to line supplies up to 480 V_{AC}, which can supply a maximum of 65 kA symmetrical ("prospective current" according to EN 60269-1).

Information on the tripping time of line fuses

In order that the line fuses trip in a timely manner, the loop resistance as well as the vector group of the feeding line transformer must ensure that, if a fault occurs, the touch voltage of the devices is disconnected by the fuses provided within the permissible tripping time (see figure below, in accordance with EN 61800-5-1 Ed. 2).




Figure 2-2 Permissible tripping time of fuses

The boundary conditions indicated above also serve to avoid a fire in case of a fault. If you do not comply with these boundary conditions, you must take additional measures, e.g., residual current transformer.

Fuse and plant conditions such as loop resistance and short-circuit power must be harmonized to one another so that the limit curve is not exceeded. This guarantees the shock-hazard protection.

2.4 Line supply connection via residual-current devices

Selectively tripping, AC/DC-sensitive residual-current devices (type B) can be used in addition to the overcurrent protection devices.

CAUTION

Residual-current devices have to be installed if the line supply conditions in terms of short-circuit power and loop impedance at the infeed point are not such that the installed overcurrent protection devices will trip within the prescribed period if a fault occurs. Since TT line supplies do not generally meet this requirement, residual-current devices must always be installed for this type of system.

Residual-current operated circuit breakers (RCD)

DANGER

Residual-current operated circuit breakers alone are not permissible to provide protection against direct and indirect contact.

When using residual-current operated circuit breakers, it should be noted that

- It is only permissible to use a delayed tripping, selective AC/DC-sensitive residual-current operated circuit breaker, type B.
- The max. permitted grounding resistance of the "selective protective device" is observed (83 Ω max. for residual-current devices with 0.3 A rated differential current).
- Accessible parts of the Power Drive System and the machine are connected to the system's protective ground conductor.
- The maximum total length of the shielded power cables in the drive line-up (motor cables incl. line supply cables from the line filter to the connecting terminals of the S120 Combi) is 175 m.
- Only recommended line filters must be used during operation.
- Only one residual-current circuit breaker may be connected in series (cascading is not possible).
- Switching elements (line disconnecter, contactors) for connecting and disconnecting the drive line-up have max. 35 ms delay time between the closing/opening of the individual main contacts.




Figure 2-3 Connecting a residual-current operated circuit breaker

Recommendation

SIEMENS selectively switching AC/DC-sensitive residual-current circuit breakers in accordance with EN 61009-1 of the 5SM series (e.g. 5SM3646-4 or 5SM3646-4+5SW3300 with an auxiliary disconnecter (1 NC contact / 1 NO contact) for a rated current of 63 A and rated fault current of 0.3 A (see catalog "BETA Modular Installation Devices - ET B1").

NOTICE
AC or pulse-sensitive RCCBs are not suitable.

2.5 Overvoltage protection

To protect the units against line-side surge voltages, you are advised to install an overvoltage protection device directly at the infeed point (upstream of the main switch). To fulfill the requirements of CSA C22.2 no. 14-05, surge protection is essential. The Raycap company has suitable surge arresters.

2.6 Line filters

2.6.1 Description

Line filters have the task to attenuate conducted interference emission in the frequency range according to the specifications of EMC legislation. They are mainly effective in the frequency range from 150 kHz to 30 MHz; this is the range relevant to ensure compliance with the appropriate standard.


In conjunction with a line filter and the associated line reactor, drive line-ups with S120 Combi Power Modules fulfill Category C2 according to EN 61800-3. An EMC compliant design is always assumed.

Line filters for 16 kW and 20 kW are designed for use with systems and equipment with a maximum total cable length of 175 m of category C2 to EN 61800-3.

Note

The line filter is only suitable for direct connection to TN line supplies. When connected to other line supplies, an isolation transformer is required.

2.6.2 Safety information

 DANGER
<p>The drive components generate high leakage currents in the protective conductor. The components must only be operated in control cabinets or in closed electrical operating areas and must be connected with the protective conductor. To protect against electric shock, the protective conductor connection at the control cabinet or machine must be implemented in accordance with one of the following measures:</p> <ul style="list-style-type: none"> • stationary connection and protective conductor connection by means of $\geq 10 \text{ mm}^2 \text{ Cu}$ or $\geq 16 \text{ mm}^2 \text{ Al}$ • stationary connection and installation of a second protective conductor with the same cross-section as the first protective conductor • stationary connection and automatic shutdown of the line supply if the protective conductor is interrupted • Connection with a plug connector for industrial applications in accordance with EN 60309 and a minimum protective conductor cross-section of $\geq 2.5 \text{ mm}^2 \text{ Cu}$ as part of a multi-core supply cable with appropriate strain relief

 **DANGER**

Risk of electric shock

A hazardous voltage is still present for up to 5 minutes after the power supply has been switched off.

 **WARNING**

Cooling clearances

The 100 mm clearances for circulating air above and below the filter must be observed. This prevents thermal overloading of the filter.

 **WARNING**

The input and output connections/terminals must not be interchanged:

- incoming line supply cable to LINE L1, L2, L3
- outgoing cable to line reactor at LOAD L1', L2', L3'

The line filter may be damaged if this is not observed.

 **CAUTION**

The S120 Combi must only be connected to the SINAMICS line filter via the associated line reactor. Additional loads must be connected upstream of the SINAMICS line filter (if required, via a separate line filter). If this is not observed, other loads could be damaged or destroyed.

CAUTION

According to product standard IEC 61800-3, RFI suppression commensurate with the relevant rated conditions must be provided and is a legal requirement in the EU (EMC Directive). Line filters and line reactors are required to achieve this. Only line filters listed in this Manual should be used. The use of filters of other makes can lead to limit value violations, resonances, overvoltages and irreparable damage to motors or other equipment. The machine manufacturer must provide verification that the machine equipped with the drive products and the installed suppression elements, e.g. line filters, are CE/EMC-compliant before the machines are placed in the market.

Note

If a high-voltage test is conducted with alternating voltage in the system, the existing line filters must be disconnected in order to obtain accurate measurements.

2.6.3 Interface description

2.6.3.1 Overview




Figure 2-4 Line filter for S120 Combi

Either the upper or lower PE screw can be used for the connection. One of the screws remains unused. "Looping-through" the protective connection to the line reactor is not permissible.

2.6.3.2 Line/load connection

Table 2- 3 Line filter connection

Order number	6SL3000-0BE21-6DAx
Rated infeed power	16 kW and 20 kW
Line connection L1, L2, L3	Screw terminal 10 mm ² ¹⁾ 1.5 - 1.8 Nm
Load connection L1', L2', L3' (U, V, W)	Screw terminal 10 mm ² ¹⁾ 1.5 - 1.8 Nm
PE connection	Grounding bolt for M5 ring cable lug according to DIN 46234 6 Nm

1) see Chapter "Control cabinet installation and EMC / connection system" - screw terminal 6

Note

The line filter 6SL3000-0BE21-6DAx can be used for all S120 Combi Power Modules.

2.6.4 Dimension drawing




Figure 2-5 Dimension drawing of the line filter, all dimensions in mm and (inches)

2.6.5 Technical data

Table 2-4 Technical data, line filter

6SL3000-0BE21-6DA0	Unit	
Rated power	kW	16 and 20
Connection voltage: Line supply voltage	V _{AC}	3-ph. 380 AC -10% (-15% < 1 min) to 3-ph. 480 AC +10%
Line frequency	Hz	47 to 63 Hz
Rated current	A _{AC}	36
Power loss ¹⁾	W	16
Dimensions (W x H x D)	mm	50 x 420 x 226
Weight, approx.	kg	5
Degree of protection		IP20

1) For an overview, see the power loss tables in chapter Control cabinet installation


2.7 Line reactors

2.7.1 Description

Line reactors for the S120 Combi limit low-frequency line harmonics to permissible values. For this reason, line reactors should always be used.

2.7.2 Safety information

CAUTION
Only the line reactors described in this Manual must be used. The following can occur if line reactors are used that have not been approved for SINAMICS S120 Combi by SIEMENS: - The infeed in the S120 Combi may be damaged/destroyed. - Line harmonics may occur that damage/destroy loads connected to the same line supply.

 CAUTION
The line reactors may reach high surface temperatures of > 80 °C. To prevent adjacent components from being damaged due to these high temperatures, a clearance of 100 mm must be maintained around the reactors. If this clearance cannot be observed, additional measures such as shielding plates or a cooling must be provided.

CAUTION
Reactors generate magnetic fields. Components and cables which could be subject to interference or be affected by these fields must, therefore, be located a sufficient distance (at least 200 mm) away or be shielded accordingly.

Note

Connecting cables

The connecting cables between the line reactor and S120 Combi must be kept as short as possible.

If at all possible, shielded connecting cables should be used.

When using unshielded connecting cables, the cores must be protected from rubbing against the shield connection clip.

Do not route any cables near the line reactor. If this cannot be avoided, observe a minimum distance of 200 mm.

2.7.3 Connection description

2.7.3.1 Overview




Figure 2-6 Line reactor for S120 Combi (example for 16 kW infeed)

2.7.3.2 Line/load connection

Table 2- 5 Connection of line reactors

Order number	6SL3100-0EE21-6AA0	6SL3100-0EE22-0AA0
Power [kW]	16	20
Line connection 1U1, 1V1, 1W1	Screw terminal ¹⁾ 16 mm ² 1.5 - 1.8 Nm	Screw terminal ¹⁾ 16 mm ² 1.5 - 1.8 Nm
Load connection 1U2, 1V2, 1W2	Screw terminal ¹⁾ 16 mm ² 1.5 - 1.8 Nm	Screw terminal ¹⁾ 16 mm ² 1.5 - 1.8 Nm
PE connection	Grounding studs for M6 ring cable lugs according to DIN 46234	Grounding studs for M6 ring cable lugs according to DIN 46234

1) see Chapter "Control cabinet installation and EMC / connection system" - screw terminal 7

2.7.4 Dimension drawings




Figure 2-7 Dimension drawing of line reactor for S120 Combi (16 kW infeed), all dimensions in mm and (inches)




Figure 2-8 Dimension drawing of the line reactor for S120 Combi (20 kW infeed), all dimensions in mm and (inches)

2.7.5 Technical data

Table 2- 6 Technical data, line reactors for S120 Combi

	Unit	6SL3100-0EE21-6AA0	6SL3100-0EE22-0AA0
Rated power	kW	16	20
Rated current	A_{rms}	28	33
Power loss ¹⁾	W	75	98
Dimensions (W x H x D)	mm	219 x 176 x 120	219 x 176 x 130
Weight	kg	10.7	10.9
Degree of protection		IP20	IP20

1) For an overview, see the power loss tables in chapter Control cabinet installation

2.8 Line connection versions

2.8.1 Ways of connecting the line supply

A distinction is made between:

- Direct operation of the line connection components on the line supply
- Operating line connection components via an autotransformer
- Operating line connection components via an isolating transformer




Figure 2-9 Overview of line connection versions

Note

Line connection of motors

In combination with the drive system, the motors are generally approved for operation on TN and TT line supplies with grounded neutral point and on IT line supplies.

In operation on IT line supplies, the occurrence of a first fault between an active part and ground must be signaled by a monitoring device. In accordance with IEC 60364-4-41, it is recommended that the first fault be eliminated as quickly as is practically possible in order to minimize the temporary overload of the motor insulation.

For all other line supplies, except TN and TT line supplies with grounded neutral point and IT line supplies, such as line supplies with a grounded phase conductor, an isolation transformer with grounded neutral point (secondary side) must be connected between the line supply and the drive system in order to protect the motor insulation from a continuous and inadmissibly high stress level.

2.8.2 Operating line connection components on the line supply

The SINAMICS S120 Combi drive system is designed to be directly connected to TN, TT, and IT line supplies with a rated voltage of 3-ph. 380 V to 3-ph. 480 V AC.




Figure 2-10 Direct operation on the line supply

2.8.3 Operation of the line connection components via a transformer

2.8.3.1 Safety information

CAUTION
The integrated infeed can be damaged/destroyed when using line filters that have not been approved by SIEMENS for the SINAMICS S120 Combi Power Modules. Furthermore, line harmonics can occur that damage/destroy loads connected to the same line supply. It is not permissible to connect other loads after the line filter.

NOTICE
If the system fault level is too low, this can result in faults at the integrated infeed of the SINAMICS S120 Combi Power Modules. It can also cause faults and damage to other equipment and devices that are connected at the same line connection point as the S120 Combi Power Module.

Note

Using a transformer with the S120 Combi Power Module does not replace the external line reactor.

2.8.3.2 Line connection conditions

The S120 Combi is approved for operation on line supplies from $S_{K \text{ line}}/P_n \geq 70$.

If a TN line supply is specified on the secondary side, then a transformer with grounded neutral point must be used. However, the loop resistance must be small enough to trigger the fuses as fast as required.

Vector group

Suggestion: Dyn5 or Yyn0; this means either a delta or star circuit on the primary side and star circuit on the secondary side where the neutral point is brought-out.

2.8.3.3 Dimensioning an isolating transformer/autotransformer for several loads

An S120 Combi Power Module with integrated infeed and other loads / machines should be connected to the line supply via an isolating/autotransformer (matching transformer). The following diagram shows the connection using an isolating transformer as example.




Figure 2-11 Operating several loads through an isolating transformer

An isolating/autotransformer (matching transformer) must be dimensioned for the total of all loads connected to it. The apparent powers required must be determined and added as indicated in the table titled "Transformer configuration instructions". If the transformer is too small (S_n or S_k), this can lead to increased line voltage dips and faults in the line supply and in other loads at this connecting point.

If other loads are connected to the secondary side of the matching transformer, the boundary conditions indicated under a) and b) must be followed when selecting the matching transformer.

S_{n1} , S_{n2} = calculated rated power of the transformer resulting from a) and b)

u_k = short-circuit voltage of the matching transformer in %
(must be between 1% and 3% for the S120 Combi)

S_k = short-circuit power.

 **WARNING**

A sufficiently high system fault level (short-circuit power) is required to ensure that when a fault does occur, the fuses rupture in the specified time. An insufficient system fault level (short-circuit power) increases the time to trip beyond permissible levels (e.g. a fire is possible).

Supplementary conditions

a) Rated power

The rated power of the matching transformer S_{n1} must always be a factor of 1.27 higher than the rated power P_n of the S120 Combi Power Module.

$$S_{n1} \geq 1.27 \cdot P_n$$

Example:

The minimum rated power of a matching transformer for a 16 kW S120 Combi Power Module is 21 kVA.

b) Short-circuit power

In order to avoid faults and disturbances at the other loads that are connected to the secondary side of the matching transformer, the total short-circuit power of the plant connection and that of the matching transformer at the connection point must reach the following values:

$$S_{k \text{ line}} \geq 70 \cdot P_n$$

Special case:

During operation with only one supply at a transformer, the values may be reduced by the factor 0.73.

$$S_{k \text{ line}} \geq 0.73 \cdot 70 \cdot P_n$$

For example $S_{k \text{ line}}$ for 16 kW S120 Combi Power Module: $S_{k \text{ line}} = 0.82 \text{ MVA} = 820 \text{ kVA}$

From $S_{K \text{ transformer}}$ the required rated power of the matching transformer can be calculated.

$$S_{n2} = \frac{S_{K \text{ plant}} [\text{kVA}] \cdot S_{K \text{ line}} [\text{kVA}] \cdot u_k [\%]}{(S_{K \text{ plant}} [\text{kVA}] - S_{K \text{ line}} [\text{kVA}]) \cdot 100 [\%]} \quad [\text{kVA}]$$

Note:

The system fault level (short-circuit power) at the plant connection $S_{K \text{ plant}}$ plays a decisive role in dimensioning/selecting the matching transformer.

From the rated power (S_{n1} or S_{n2}) calculated under a) and b), the higher value must be used for the matching transformer.

Table 2-7 Transformer configuration instructions

S120 Combi Power Module P_n	Required rated power S_n of the isolation transformer/autotransformer	Required short-circuit voltage u_k	Required system fault level $S_{K \text{ line}}$
16 kW	$S_n \geq 21 \text{ kVA}$	$u_k \leq 3 \%$	$S_{K \text{ line}} \geq 1.12 \text{ MVA}$
20 kW	$S_n \geq 26 \text{ kVA}$	$u_k \leq 3 \%$	$S_{K \text{ line}} \geq 1.4 \text{ MVA}$

Note

Ask your local power utility company for the system fault level $S_{K \text{ line}}$.

Example 1

u_k matching transformer = 3 %
 $S_{K \text{ plant}} = 50000 \text{ kVA}$
 $S_{K \text{ line}} = 16 \text{ kW} \cdot 70 \cdot 0.73 = 820 \text{ kVA}$

According to a)
 $S_{n1} = 1.27 \cdot 16 \text{ kW} = 21 \text{ kVA}$

According to b)

$$S_{n2} = \frac{50000 \text{ kVA} \cdot 820 \text{ kVA} \cdot 3\%}{(50000 \text{ kVA} - 820 \text{ kVA}) \cdot 100\%} = 25 \text{ kVA}$$

$S_{n2} > S_{n1} \Rightarrow S_{n2}$ is decisive

The matching transformer requires a rated power S_n of 25 kVA for a short-circuit voltage u_k of 3%.

Example 2

u_k matching transformer = 1 %
 $S_{K \text{ plant}} = 50000 \text{ kVA}$
 $S_{K \text{ line}} = 16 \text{ kW} \cdot 70 \cdot 0.73 = 820 \text{ kVA}$

according to a)
 $S_{n1} = 1.27 \cdot 16 \text{ kW} = 21 \text{ kVA}$

According to b)

$$S_{n2} = \frac{50000 \text{ kVA} \cdot 820 \text{ kVA} \cdot 1\%}{(50000 \text{ kVA} - 820 \text{ kVA}) \cdot 100\%} = 8.3 \text{ kVA}$$

$S_{n1} > S_{n2} \Rightarrow S_{n1}$ is decisive

The matching transformer requires a rated power S_n of 21 kVA for a short-circuit voltage u_k of 1%.

Example 3

If $S_{K \text{ plant}}$ is lower, then a higher-rating transformer must be used.

u_k matching transformer = 3 %
 $S_{K \text{ plant}} = 3000 \text{ kVA}$
 $S_{K \text{ line}} = 16 \text{ kW} \cdot 70 \cdot 0.73 = 820 \text{ kVA}$

according to a)
 $S_{n1} = 1.27 \cdot 16 \text{ kW} = 21 \text{ kVA}$

According to b)

$$S_{n2} = \frac{3000 \text{ kVA} \cdot 820 \text{ kVA} \cdot 3\%}{(3000 \text{ kVA} - 820 \text{ kVA}) \cdot 100\%} = 33.9 \text{ kVA}$$

$S_{n2} > S_{n1} \Rightarrow S_{n2}$ is decisive

The matching transformer requires a rated power S_n of 34 kVA for a short-circuit voltage u_k of 3%.

Example 4

If $S_{K \text{ plant}}$ is lower, you can use, alternatively to example 3, a transformer with a lower u_k .

$u_k \text{ matching transformer} = 1 \%$,

$S_{K \text{ plant}} = 3,000 \text{ kVA}$

$S_{K \text{ line}} = 16 \text{ kW} \cdot 70 \cdot 0.73 = 820 \text{ kVA}$

according to a)

$S_{n1} = 1.27 \cdot 16 \text{ kW} = 21 \text{ kVA}$

According to b)

$$S_{n2} = \frac{3000 \text{ kVA} \cdot 820 \text{ kVA} \cdot 1\%}{(3000 \text{ kVA} - 820 \text{ kVA}) \cdot 100\%} = 11.3 \text{ kVA}$$

$S_{n1} > S_{n2} \Rightarrow S_{n1}$ is decisive


The matching transformer requires a rated power S_n of 21 kVA for a short-circuit voltage u_k of 1%.

Note

S_{n2} for the matching transformer can be reduced by reducing u_k . In the examples listed above, the power drawn from other loads has not been taken into account.

2.8.3.4 Operating line connection components via an autotransformer

An autotransformer can be used to adapt the voltage in the range up to 3-ph. 480 V AC +10 %.

 DANGER
<p>To ensure protective separation an isolation transformer must be used for voltages greater than 3-ph. 480 V AC + 10 %.</p>

Application example:

- The motor insulation must be protected from excessive voltages.




Figure 2-12 Operation via an autotransformer

2.8.3.5 Operating line connection components via an isolating transformer

An isolating transformer converts the line supply type of the plant or system (e.g. IT/TT line supply) to a TN line supply. Additional voltage adaptation to the permissible voltage tolerance range is possible.

An isolating transformer must be used in the following cases:

- The insulation of the Motor Module and/or the motor is not suitable for the voltages that occur.
- There is no compatibility with an existing residual-current protective device.
- The installation altitude is higher than 2000 m above sea level.
- A line filter should be used in a line supply system that is not a TN line supply system with grounded neutral conductor.

CAUTION

If the line supply voltage is greater than 480 V +10 %, it is not permissible to use an autotransformer.

An isolating transformer must be used to ensure protective separation.

An isolating transformer must have the following properties:

- The transformer secondary must be in the star connection (a delta connection is not permissible!)
- The neutral conductor must be brought out. It must be connected with the PE of the line filter, line reactor and S120 Combi (infeed).
Notice: If the neutral conductor is not brought out and/or not connected, then all of the restrictions of an IT line supply apply!
- If the line supply is available in a star connection on the primary side, then the vector group that is required is: Yyn0
- If the line supply is available in a delta connection on the primary side, then the vector group that is required is: Dyn5




Figure 2-13 Operation via an isolation transformer

S120 Combi Power Modules

3.1 Introduction

3.1.1 Description

The SINAMICS S120 Combi

The S120 Combi is a Power Module with integrated infeed, Motor Modules (inverter) for 3 or 4 axes and a TTL encoder evaluation for the spindle. The S120 Combi is available in the following versions for various current ratings:

- 3 axes Power Module with infeed, spindle and 2 feed axes
- 4 axes Power Module with infeed, spindle and 3 feed axes

The Power Modules are cooled using external air cooling that employs through-hole technology. The required fan unit is optionally available. A fan solution on the customer side with comparable rated data is possible.

The S120 Combi is infeed/energy-recovery capable. The infeed provides the integrated Motor Modules with an uncontrolled DC voltage.

In the infeed mode regarding the current and voltage waveforms, the infeed has a typical characteristic of a 6-pulse diode rectifier bridge. In the energy recovery mode, the current waveform is a square wave.

The energy recovery is switched in depending on the power that is fed back. Energy recovery is deactivated when the infeed is operating under no-load conditions.

The integrated Motor Modules operate with a fixed IGBT clock frequency of 4 kHz.

The overload factor for the infeed and all axes is ≤ 2 .

The S120 Combi is suitable for direct operation on TN, IT and TT line supplies.

Controlling the motor holding brake

The S120 Combi has an integrated brake control function for a motor holding brake. The motor holding brake is connected at terminal X11. The assignment of the motor holding brake to the feed axes of the S120 Combi can be freely parameterized using the software. Motor holding brakes up to 1 A are controlled.

Temperature sensor connection

A temperature sensor can either be connected using terminal X21 or alternatively using the sub-D connector of the TTL encoder (X220). The interface used is selected using the software. In this case, only the selected evaluation is available.

Encoder connection

The S120 Combi supports sin/cos encoders, TTL encoders and encoders with integrated DRIVE-CLiQ with a 5 V supply for motors. The TTL encoder is connected via the integrated X220 encoder interface and is permanently assigned to spindle output X2. The sin/cos encoder for spindle output X2 is connected to interface X205 via an SMx20 Sensor Module. In this particular case, encoder interface X220 is automatically inactive.

Fixed topology rules apply when connecting DRIVE-CLiQ encoders. Each feed axis is precisely assigned one DRIVE-CLiQ interface (see Chapter "Topology rules for DRIVE-CLiQ").

HTL encoders, SSI encoders and a 24 V encoder power supply are not supported.

Interface assignment

The assignment of the interfaces on the S120 Combi is permanently defined and must not be changed.

The DRIVE-CLiQ connection of the expansion axes is always implemented via DRIVE-CLiQ interface X101 at the SINUMERIK control. A detailed description is provided in the chapters "Interface description" of the S120 Combi and "Topology rules for DRIVE-CLiQ".

Measuring systems and additional encoders should always be connected via the DMC20 Hub Module.

Internal temperature sensing and internal fan

The internal temperature of the S120 Combi is sensed. In conjunction with this is the temperature-dependent control of the internal fan to cool the inside of the unit. The S120 Combi Power Module is switched off if its internal temperature becomes too high.

An operating hours counter for the internal fan is available via the software in parameter P0254 (infeed).

3.1.2 Module versions

Table 3- 1 S120 Combi versions

Infeed [kW]	Spindle Motor Module 1 [Arms]	Feedrate 1 Motor Module 2 [Arms]	Feedrate 2 Motor Module 3 [Arms]	Feedrate 3 Motor Module 4 [Arms]	Order number
3 axes					
16	18	5	5	-	6SL3111-3VE21-6FA0
16	24	9	9	-	6SL3111-3VE21-6EA0
20	30	9	9	-	6SL3111-3VE22-0HA0
4 axes					
16	18	9	5	5	6SL3111-4VE21-6FA0
16	24	9	9	9	6SL3111-4VE21-6EA0
20	30	12	9	9	6SL3111-4VE22-0HA0

3.1.3 Approved controls

The S120 Combi is approved for operation with the following controls:

- SINUMERIK 828D with PPU versions
 - PPU 24x.2
 - PPU 26x.2
 - PPU 28x.2

Table 3- 2 Overview of the order numbers of the approved SINUMERIK 828D controls

PPU version	Keyboard	Order number (without CNC software)
240.2	Vertical	6FC5370-4AT20-0AA0 (Turning) 6FC5370-4AM20-0AA0 (Milling)
241.2	Horizontal	6FC5370-3AT20-0AA0 (Turning) 6FC5370-3AM20-0AA0 (Milling)
260.2	Vertical	6FC5370-6AA20-0AA0
261.2	Horizontal	6FC5370-5AA20-0AA0
280.2	Vertical	6FC5370-8AA20-0AA0
281.2	Horizontal	6FC5370-7AA20-0AA0

3.1.4 Expansion axes that can be connected

The S120 Combi can be expanded with Motor Modules from the SINAMICS S120 Booksize Compact series by one or two axes.

Table 3- 3 Expansion axes for the S120 Combi Power Modules

Motor Module Booksize Compact	Width	Order number
Single Motor Module 3 A	50 mm	6SL3420-1TE13-0AA0
Single Motor Module 5 A	50 mm	6SL3420-1TE15-0AA0
Single Motor Module 9 A	50 mm	6SL3420-1TE21-0AA0
Single Motor Module 18 A	75 mm	6SL3420-1TE21-8AA0
Double Motor Module 2 x 1.7 A	75 mm	6SL3420-2TE11-7AA0
Double Motor Module 2 x 3 A	75 mm	6SL3420-2TE13-0AA0
Double Motor Module 2 x 5 A	75 mm	6SL3420-2TE15-0AA0

NOTICE

Number of expansion axes

A maximum of two expansion axes can be connected to an S120 Combi Power Module, i.e. two Single Motor Modules or one Double Motor Module.

For a description of the Motor Modules Booksize Compact, see Chapter "Motor Modules Booksize Compact as expansion axes".

3.2 Safety information

 **DANGER**

Risk of electric shock

A hazardous voltage is still present for up to 5 minutes after the power supply has been switched off.

The front cover must not be opened until this time has elapsed.

It is only permissible to operate the S120 Combi when the front cover is mounted. When operating without expansion axes, the factory-mounted DC link cover must not be removed. Damaged components must not be used further, Secondary damage or accidents can otherwise result.

 **DANGER**

If cables are not connected to terminals X1 (line connection) and X2 (motor connection - spindle), then touch protection according to degree of protection IP20 to EN 60529 is not guaranteed.

 **DANGER**

DC link discharge time

The danger note for the DC link discharge time must be placed on the component in the national language.

A set of labels in 16 languages is provided with the component.

 **DANGER**

If the S120 Combi is not disconnected from the line supply system (e.g. via the line contactor or main switch), the DC link remains charged.

CAUTION

DC link busbars

After the S120 Combi has been expanded with expansion axes and/or DC link components, the correct tightening torque of the DC link busbar bolts must be checked (1.8 Nm, tolerance +30 %). The check is made before commissioning when the overall plant or system is in a no-voltage state with the DC link discharged. After transportation, the screws must be tightened.

CAUTION

Operation on line supplies where energy recovery is not possible

In a line supply system without energy recovery capability (e.g. diesel generator), the energy recovery capability of the S120 Combi must be deactivated using parameter p3533 (see description of functions). The braking energy must then be dissipated via an additional Braking Module with braking resistor provided in the drive line-up.

 **DANGER**

In the interests of operator and fire protection, the line supply conditions in terms of short-circuit power and loop impedance at the infeed point must be such that they will trip the installed overcurrent protection devices within the prescribed period if a fault occurs (short circuit or short circuit to exposed conductive part).

Note

System fault level at the infeed point

In order to limit the line harmonics to an appropriate level for additional loads, the system fault level at the infeed point must be at least a factor 70 higher than the rated power of the integrated infeed.

 **DANGER**

The drive components generate high leakage currents in the protective conductor. The components may only be operated in control cabinets or in locked, electrical equipment rooms. They must be connected with the protective conductor. To protect against electric shock, the protective conductor connection at the control cabinet or system must be implemented in accordance with one of the following measures:

- Fixed connection and protective conductor connection with $\geq 10 \text{ mm}^2 \text{ Cu}$ or $\geq 16 \text{ mm}^2 \text{ Al}$
- stationary connection and installation of a second protective conductor with the same cross-section as the first protective conductor
- stationary connection and automatic shutdown of the line supply if the protective conductor is interrupted
- Connection with a plug connector for industrial applications in accordance with EN 60309; minimum protective conductor cross-section of $\geq 2.5 \text{ mm}^2 \text{ Cu}$ as part of a multi-core supply cable with appropriate strain relief

 **DANGER**

It is mandatory that the shield for the motor holding brake is connected. MOTION-CONNECT cables must be used for the integrated motor holding brake, as otherwise the insulation strength of the cores is not guaranteed. Risk of electric shock.

! WARNING

Cable shields and unused power cable cores (e.g. brake cores) must be connected to PE potential to prevent capacitive cross-talk charges.
Non-observance can cause lethal shock voltages.

! CAUTION**Cooling clearances**

The 80 mm clearances above and below the components must be observed.

CAUTION**Connection for temperature sensors**

Connecting cables to temperature sensors must always be installed with shielding. The cable shield must be connected at both ends and over a large surface area. Temperature sensor cables that are routed together with the motor cable must be twisted in pairs and shielded separately.

CAUTION

The total length of the power cables (motor feeder cables etc.) must not exceed 175 m.

CAUTION

Only cables from SIEMENS may be used for DRIVE-CLiQ connections.

NOTICE

As a result of the external air cooling, the fan and the heat sinks can accumulate a lot of dirt. This causes the temperature monitoring to respond in the S120 Combi Power Module. Therefore, the fans and heat sink must be checked for pollution at regular intervals and, if necessary, cleaned.

NOTICE

Operation without the line reactor is not permissible.

Note

After installation, the seal on the optional fan unit must be checked to ensure that it tightly seals. Additional sealing can be used, if necessary.

3.3 Interface description

3.3.1 Overview diagrams




Figure 3-1 S120 Combi 3 axes Power Module




Figure 3-2 S120 Combi 3 axes Power Module: View from the top




Figure 3-3 S120 Combi 3 axes Power Module: View from below




Figure 3-4 S120 Combi 4 axes Power Module

3.3 Interface description




Figure 3-5 S120 Combi 4 axes Power Module: View from the top




Figure 3-6 S120 Combi 4 axes Power Module: View from below

3.3.2 X1 line connection

Table 3-4 X1 line connection (infeed)

	Terminal	Technical specifications
<div style="border: 1px solid black; padding: 5px; width: fit-content;"> <p style="text-align: center; margin: 0;">INPUT</p> <p style="margin: 0;">LINE X1</p> <div style="display: flex; justify-content: space-around; align-items: center; margin: 5px 0;"> ○ ○ ○ ⊕ </div> <p style="margin: 0; text-align: center;">U1 V1 W1 PE</p> </div>	U1	Max. connectable cross-section: 16 mm ² Type: Screw terminal 7 (see Chapter "Control cabinet installation and EMC / connection system") Tightening torque: 1.5 - 1.8 Nm
	V1	
	W1	
	PE connection	

3.3 Interface description

3.3.3 X2-X5 motor connection

Table 3- 5 X2 spindle (18 A, 24 A and 30 A Motor Modules)



	Terminal	Technical specifications
	U2	Motor connection Max. connectable cross-section: 10 mm ² Type: Screw terminal 6 (see Chapter "Control cabinet installation and EMC / connection system") Tightening torque: 1.5 - 1.8 Nm
	V2	
	W2	
	PE connection	

Table 3- 6 X3 to X5 feedrate (5 A, 9 A and 12 A Motor Modules)


	Terminal	Technical specifications
 <p>(only for 4 axes Power Module)</p>	U2	Motor connection Max. connectable cross-section: 6 mm ² Type: Screw terminal 5 (see Chapter "Control cabinet installation and EMC / connection system") Tightening torque: 1.5 - 1.8 Nm
	V2	
	W2	
	PE connection	

Note

The total length of the power cables must not exceed 175 m.

3.3.4 X11 brake connection

Table 3-7 Brake connection X11

	Terminal	Designation	Technical specifications
 Connector	BR +	Brake connection +	Voltage 24 V DC max. load current 1 A min. load current 0.1 A Max. connectable cross-section 2.5 mm ² Type: Spring-loaded terminal 1 (see Chapter "Control cabinet installation and EMC / connection system") The brake connector is part of the prefabricated cable.
	BR -	Brake connection -	

 **WARNING**

Only protective extra-low voltages (PELV) must be connected to all connections and terminals between 0 and 48 V DC.

The voltage tolerances of the motor holding brakes (24 V ± 10%) must be taken into account.


Note

The motor brake must be connected via connector X11. The BR- cable must not be connected directly to electronics ground (M).

3.3 Interface description

3.3.5 X12/X13 fan connection

Table 3- 8 X12/X13 connection of the external fan unit

	Terminal	Designation	Technical specifications
	1	Ground	
	2	Fan monitoring	
	3	+24 V	Current-carrying capacity, 2 x 1 A or 1 x 2 A
	4	Ground	
Max. connectable cross-section: 1.5 mm ² Type: Screw terminal 1 (see Chapter "Control cabinet installation and EMC / connection system")			

CAUTION

When connecting a customer's own fan unit using 2-core cables, terminals 1 and 2 must be connected using a jumper.

Note

When connecting a customer's own fan unit using 3-core cables, the white core (fault signal) can be connected to terminal 2.

3.3.6 X21/X22 EP terminals

Table 3- 9 X21 EP terminals - infeed




	Terminal	Designation	Technical specifications
	1	-	Reserved, do not use
	2	-	
	3	EP +24 V (Enable Pulses)	Supply voltage: 24 V DC (20.4 V - 28.8 V) Current consumption: 10 mA Isolated input Signal propagation times: L → H: 100 μs H → L: 1000 μs
	4	EP M1 (Enable Pulses)	
Max. connectable cross-section: 1.5 mm ² Type: Screw terminal 1 (see Chapter "Control cabinet installation and EMC / connection system")			

Table 3- 10 X22 EP terminals/temperature sensor - axes

	Terminal	Designation	Technical specifications
	1	+ Temp	Temperature sensors ¹⁾ : KTY84–1C130 / PTC / bimetallic switch with NC contact
	2	- Temp	
	3	EP +24 V (Enable Pulses)	Supply voltage: 24 V DC (20.4 V - 28.8 V) Current consumption: 10 mA Isolated input Signal propagation times: L → H: 100 µs H → L: 1000 µs The pulse inhibit function is only available when Safety Integrated Basic Functions are enabled.
	4	EP M1 (Enable Pulses)	
Max. connectable cross-section: 1.5 mm ² Type: Screw terminal 1 (see Chapter "Control cabinet installation and EMC / connection system")			

1) The temperature sensor type can be selected by parameters (see the List Manual SINUMERIK 828D).

 DANGER
Risk of electric shock! Only temperature sensors that meet the safety isolation specifications contained in EN 61800-5-1 may be connected to terminals "+Temp" and "-Temp". If these instructions are not complied with, there is a risk of electric shock!

NOTICE
The KTY temperature sensor must be connected with the correct polarity. If the polarity is reversed, the sensor will not be able to detect if the motor overheats.


NOTICE
The function of the EP terminals is only available when Safety Integrated Basic Functions are enabled.

Note

The temperature sensor input is not needed if the motors feature an integrated DRIVE-CLiQ interface or if temperature values are detected by means of a different module (SMC, SME).

3.3.7 X200-X205 DRIVE-CLiQ interfaces

Table 3- 11 X200-X205 DRIVE-CLiQ interfaces

	PIN	Signal name	Technical specifications
	1	TXP	Transmit data +
	2	TXN	Transmit data -
	3	RXP	Receive data +
	4	NC	
	5	NC	
	6	RXN	Receive data -
	7	NC	
	8	NC	
	A	+ (24 V)	Power supply
	B	M (0 V)	Electronics ground
Connector type	RJ45 socket		

The blanking covers for the DRIVE-CLiQ interfaces are included in the scope of delivery.

Blanking covers (50 pieces) Order number: 6SL3066-4CA00-0AA0

Note

DRIVE-CLiQ interface X204

For 3 axes Power Modules of the S120 Combi, there is no DRIVE-CLiQ interface X204.

Inserting and removing the DRIVE-CLiQ blanking covers

The blanking covers should not be inserted in the DRIVE-CLiQ interfaces that are not required until the wiring work has been completed.

To remove the blanking covers, we recommend that the guiding frame is dismantled. For this purpose unscrew the Torx slotted screw (see below).





Figure 3-7 Dismantling the guiding frame of the DRIVE-CLiQ interfaces

As an alternative to dismantling the guiding frame, flat-nosed pliers can be used to remove the blanking covers.

3.3.8 X220 TTL encoder

Table 3- 12 Encoder interface X220

	Pin	Signal name	Technical specifications
	1	+ Temp	Motor temperature sensing KTY84-1C130 (KTY+) Temperature sensor KTY84-1C130 / PTC
	2	Clock	Clock
	3	Clock*	Inverse clock
	4	P encoder 5 V	Encoder power supply
	5	P encoder 5 V	
	6	P sense	Sense input of encoder power supply
	7	M encoder (M)	Ground for encoder power supply
	8	- Temp	Motor temperature sensing KTY84-1C130 (KTY+) Temperature sensor KTY84-1C130 / PTC
	9	M sense	Ground sense input
	10	R	Reference signal R
	11	R*	Inverse reference signal R
	12	B*	Inverse incremental signal B
	13	B	Incremental signal B
	14	A*	Inverse incremental signal A
	15	A	Incremental signal A

Type: Sub-D socket, 15-pin; TTL encoder; max. cable length 100 m

Note

Only 5 V TTL encoders are supported.


 DANGER
Risk of electric shock! Only temperature sensors that meet the safety isolation specifications contained in EN 61800-5-1 may be connected to terminals "+Temp" and "-Temp". If these instructions are not complied with, there is a risk of electric shock!

Table 3- 13 Technical data of the encoder system supply

Encoder system supply	Unit	Value
Voltage	V_{encoder}	5 V DC (with or without Remote Sense) ¹⁾
Current	A_{encoder}	0.35
Encoder frequency that can be evaluated (f_{encoder})	kHz	≤ 300

- 1) A controller compares the encoder system supply voltage - sensed via the Remote Sense cables - with the reference supply voltage of the encoder system, and adjusts the supply voltage for the encoder system at the output of the drive module until the required supply voltage is obtained directly at the encoder system.

Table 3- 14 Specification of TTL encoder systems that can be connected

Parameter	Designation	Threshold	Min.	Max.	Unit
Signal level, high ¹⁾	V_{Hdiff}		2	5	V
Signal level, low ¹⁾	V_{Ldiff}		-5	-2	V
Signal frequency	f_{s}		-	300	kHz
Edge clearance	t_{min}		100	-	ns
"Zero pulse inactive time" (before and after A=B=high)	t_{Lo}		640	$(t_{\text{ALo-BHi}} - t_{\text{Hi}})/2$ ²⁾	ns
"Zero pulse active time" (while A=B=high and beyond) ³⁾	t_{Hi}		640	$t_{\text{ALo-BHi}} - 2 \cdot t_{\text{Lo}}$ ²⁾	ns

- 1) Other signal levels according to the RS 422 standard.
- 2) $t_{\text{ALo-BHi}}$ is not a specified value, but is the time between the falling edge of track A and the next but one rising edge of track B.
- 3) Further information on setting the "Zero pulse active time" can be found in the following:
References: SINAMICS S120 Function Manual (FH1), tolerant encoder monitoring for SMC30

Cable length as a function of the encoder current for encoders with 5 V supply (valid for cable cross-sections with 0.5 mm²):




Figure 3-8 Max. cable length as a function of the encoder current drawn

For encoders without Remote Sense the permissible cable length is restricted to 100 m (reason: the voltage drop depends on the cable length and the encoder current).




Figure 3-9 Signal characteristic of track A and track B between two edges: Time between two edges with pulse encoders





Figure 3-10 Position of the zero pulse to the track signals

3.3.9 X224 24 V connector

Table 3- 15 X224 24 V connector

	Terminal	Designation	Technical specifications
	+	24 V power supply	24 V DC supply voltage
	M	Ground	Electronics ground

The 24 V connector is supplied as standard.
Max. connectable cross-section: 6 mm²
Type: Screw terminal 5 (see Chapter "Control cabinet installation and EMC / connection system")

3.4 Connection examples




Figure 3-11 Connection example for an S120 Combi 3 axis Power Module with a motor holding brake




Figure 3-12 Connection example for an S120 Combi 4 axis Power Module with 3 motor holding brakes

Motor holding brake for servo 1

Brake control for servo 1 via internal brake interface (SBC possible)

Motor holding brake for servo 2 and servo 3 (parameterizable in the expert list)

- Settings in the Expert list
 - Servo2-p1215=3 and Servo3-p1215=3
(3: Motor holding brake as for the sequence control, connection via BICO, no SBC possible)
- BiCo connections from the sequence control to digital outputs on the Control Unit
 - BICO interconnection to "open servo holding brake"
 - BiCo in CU_I-p0744: Servo2-r0899.12
 - BiCo in CU_I-p0745: Servo3-r0899.12
 - Output definition in CU_I
 - CU_I-p0728.14 =1
 - CU_I-p0728.15 =1

Note

The circuit shown above is only an example.

A wiring diagram of the digital inputs/outputs on the PPU can be found in the SINUMERIK 828D Manual PPU Edition 11/2010 in Point 6 "Connecting".

3.5 Meaning of the LEDs on the S120 Combi


The SINAMICS S120 Combi has two LEDs to display the status of the components. The software assigns a priority to the status signals from the individual components. The most important and/or most informative status is output for the complete S120 Combi.

The status is immediately output if any component develops a fault. The ready to run indication is only issued if all of the components have signaled that they are ready to run.

The LED statuses for the S120 Combi are described in the table below. The status display always refers to the complete S120 Combi.

Table 3- 16 Meaning of the LEDs on the S120 Combi

Status		Description, cause	Remedy
RDY	DC LINK		
Off	Off	Electronics power supply is missing or outside permissible tolerance range.	Connect/test the electronics power supply
Green	Off	The component is ready for operation and cyclic DRIVE-CLiQ communication is taking place.	-
	Orange	The component is ready for operation and cyclic DRIVE-CLiQ communication is taking place. The DC link voltage is present.	-
	Red	The component is ready for operation and cyclic DRIVE-CLiQ communication is taking place. The DC link voltage is too high.	Check the line supply voltage.
Orange	Orange	DRIVE-CLiQ communication is being established.	-
Red	-	This component has at least one fault. Note: The LED is activated regardless of whether the corresponding messages have been reconfigured.	Remedy and acknowledge fault
Green/Red (0.5 Hz)	-	Firmware is being downloaded.	
Green/Red (2 Hz)	-	Firmware has been downloaded. Wait for POWER ON.	Carry out a POWER ON
Green/Orange or Red/Orange	-	Detection of the component via LED is activated (p0124) Note Both options depend on the LED state when activated via p0124 = 1.	-

 WARNING
Hazardous DC link voltages may be present at any time regardless of the state of the "DC LINK" LED. The warning information on the components must be carefully observed!

Cause and rectification of faults

The following reference material contains information about the cause of faults and how they are rectified:

SINAMICS S120 Function Manual Drive Functions (FH1)

SINUMERIK 828D Turning and Milling Commissioning Manual

3.6 Dimension drawings




Figure 3-13 Dimension drawing of the S120 Combi 3 axes Power Module, all dimensions in mm and (inches)

3.7 Installation




Figure 3-14 Dimension drawing of the S120 Combi 4 axes Power Module, all dimensions in mm and (inches)

3.7 Installation

3.7.1 Drilling patterns and installation cut-outs

Preparing the mounting panel

The installation cut-outs shown below are for any S120 Combi Power Module and the external fan unit.

The drilling patterns differ by the number and width of the expansion axes. Select the appropriate drilling pattern corresponding to your individual design.




Figure 3-15 Dimensions for the installation cut-outs and drilling patterns for an S120 Combi Power Module with external fan unit, reinforcement plates and expansion axes, all dimensions in mm and (inches)

3.7.2 Installing an S120 Combi Power Module

An S120 Combi Power Module is installed after the reinforcement plates have been installed.

Installation steps

1. Mount the M6 self-clinching flush head studs
2. Locate the S120 Combi Power Module
3. Initially tighten the M6 nuts by hand (0.5 Nm).
4. Tighten the nuts in the specific sequence (1 to 4) with 10 Nm




Figure 3-16 Installing an S120 Combi Power Module

3.8 Electrical connection

Non-assembled MOTION-CONNECT power cables must be appropriately prepared before being connected to the S120 Combi.

Cables without connection cables for the motor holding brake

1. Cut the cable jacket to dimension A from the table below
2. Strip the single cores U, V, W and PE and crimp on end sleeves according to DIN 46228

Cables with connection cables for the motor holding brake

1. Cut the cable jacket to 250 ± 5 mm
2. Cut the single cores U, V, W and PE to dimension A from the table below, strip and crimp on end sleeves according to DIN 46228
3. Strip the connection cables for the motor holding brake and screw to the brake connector





Figure 3-17 Stripped lengths for power cables

Cable cross-section in mm ²	A in mm and (inches)
4 x 1.5	55 ⁺³ (2.17 ^{+0.12})
4 x 2.5	55 ⁺³ (2.17 ^{+0.12})
4 x 4	55 ⁺³ (2.17 ^{+0.12})
4 x 6	55 ⁺² (2.17 ^{+0.08})
4 x 10	55 ⁺² (2.17 ^{+0.08})

3.8.1 Line supply cable

Shielded MOTION-CONNECT 500 and 800 line supply cables are recommended in order to maintain the EMC limit values. The line supply cable is connected at interface X1 (INPUT). The single cores of the cable are labeled with U, V, W and PE. Cables are connected at the S120 Combi corresponding to the terminal labeling. The cable shield should be connected and fixed using the shield clamp.



- 1 Shield connection clamp
- 2 Line supply cable

Figure 3-18 Line supply cable connected at the S120 Combi

NOTICE

The shield clamp does **not** provide strain relief. Strain relief for the power cable must be separately realized using a suitable measure.

CAUTION


When using unshielded power cables, the shield clamp must **not** be used, as otherwise the unshielded single cores could be damaged.

3.8.2 Power cables for motors

The motor power cables are connected at interfaces X2 to X5. The single cores of the cable are labeled with U, V, W and PE. The cables are connected corresponding to the terminal labels at the S120 Combi.

When using a power cable with connection cables for the motor holding brake, the cores for the motor holding brake are connected at interface X11 (see the diagram below). In this case, connect the cable shield of all cable cores. Fix the cable shield using the shield clamp.

When using a separate cable for the motor holding brake, the cable shield should be connected to a shield support of a motor power cable that is free. If there is no longer a free shield support, connect the cable shield of the brake cable to the connection at the outer right together with the cable shield of the motor power cable.



- 1 Shield connection clamp
- 2 Power cables with connection cables for the motor holding brake
- 3 Connector for the motor holding brake

Figure 3-19 Power cable connected at the S120 Combi

NOTICE

The shield clamp does **not** provide strain relief. Strain relief for the power cable must be separately realized using a suitable measure.

3.8.3 Signal cables at the EP terminals

The shields of the signal cables at the EP terminals X21 and X22 are connected using the shield clamp ① from the Completion Kit (Weidmüller: KLBÜ 4-13.5). The connection involves the following steps:

- Mount the shield clamp at the S120 Combi using an SW3 wrench with a tightening torque of 1.8 Nm
- Strip the insulation from the signal cables and crimp on end sleeves to the individual cores
- Connect the cores to the EP terminals (screw terminals)
- Connect the signal cable shields as shown below.




Figure 3-20 Signal cables connected with the correct shield support

3.9 Technical data

Table 3- 17 Technical data of the S120 Combi 3 axes Power Modules

3 axes Power Modules	6SL3111-	3VE21-6FA0	3VE21-6EA0	3VE22-0HA0
		16 kW / 18 A / 5 A / 5 A	16 kW / 24 A / 9 A / 9 A	20 kW / 30 A / 9 A / 9 A
Infeed				
Infeed				
Rated power (S1) ¹⁾	kW (P _n)	16	16	20
Infeed power (S6-40%) ¹⁾	kW (P _{s6})	21	21	26.5
Peak infeed power ¹⁾	kW (P _{max})	35	35	40
Regenerative feedback				
Rated power (S1)	kW (P _n)	16	16	20
Peak regenerative power	kW (P _{max})	35	35	40
Supply voltages				
Line voltage	V _{AC}	3-ph. 380 – 10 % up to 3-ph. 480 V AC + 10 %		
Line frequency	Hz	45 to 66		
Electronics power supply	V _{DC}	24 (20.4 – 28.8)		
Rated input current				
at 400 V _{AC}	A _{AC}	28	28	34
at 380 V _{AC} / 480 V _{AC}	A _{AC}	29 / 25	29 / 25	35 / 30
at 400 V; S6-40%	A _{AC}	35.5	35.5	44
at 400 V _{AC} peak current	A _{AC}	56	56	63.5
Spindle				
Output current				
Rated current (I _n)	A _{ACrms}	18	24	30
Base-load current (I _H)	A _{ACrms}	15.3	20.4	25.5
Intermittent duty current (I _{s6}) 40%	A _{ACrms}	24	32	40
Peak current (I _{max})	A _{ACrms}	36	48	56
Rated power				
at 540 V DC link voltage	kW	8.7	11.7	14.4
at 600 V DC link voltage	kW	9.7	13	16
Pulse frequency spindle	kHz	4		
Output voltage	V _{ACrms}	0 - 0.7 x DC link voltage		
Feedrate 1				
Output current				
Rated current (I _n)	A _{ACrms}	5	9	9
Base-load current (I _H)	A _{ACrms}	4.3	7.7	7.7
Intermittent duty current (I _{s6}) 40%	A _{ACrms}	6.5	12	12
Peak current (I _{max})	A _{ACrms}	10	18	18
Rated power				
at 540 V DC link voltage	kW	2.4	4.3	4.3
at 600 V DC link voltage	kW	2.7	4.8	4.8
Pulse frequency feedrate 1	kHz	4		
Output voltage	V _{ACrms}	0 - 0.7 x DC link voltage		

3.9 Technical data

3 axes Power Modules	6SL3111-	3VE21-6FA0	3VE21-6EA0	3VE22-0HA0
Feedrate 2				
Output current				
Rated current (I_n)	A_{ACrms}	5	9	9
Base-load current (I_H)	A_{ACrms}	4.3	7.7	7.7
Intermittent duty current (I_{S6}) 40%	A_{ACrms}	6.5	12	12
Peak current (I_{max})	A_{ACrms}	10	18	18
Rated power				
at 540 V DC link voltage	kW	2.4	4.3	4.3
at 600 V DC link voltage	kW	2.7	4.8	4.8
Pulse frequency feedrate 2	kHz	4		
Output voltage	V_{ACrms}	0 - 0.7 x DC link voltage		
Output for expansion axis				
DC link voltage	V_{DC}	460 – 720		
DC link output current (I_n)	A_{DC}	40		
Max. electronics output current for expansion axis	A_{24Vmax}	20		
General data				
Electronics current consumption at 24 V DC				
without external fan unit	A	1.5	1.5	1.5
with external fan unit	A	2.3	2.3	2.3
Total power loss ²⁾ (including electronics losses ³⁾)				
internal	W	81	91	102
external	W	344	446	532
Max. ambient temperature				
Without derating	°C	45	45	45
With derating	°C	55	55	55
DC link voltage	V_{DC}	460 – 720		
DC link capacitance	μF	1645	1880	2115
Overvoltage tripping	V_{DC}	820 ± 2 %		
Undervoltage tripping	V_{DC}	380 ± 2 %		
Circuit breaker (UL)				
Type designation		3VL2105-2KN30	3VL2105-2KN30	3VL2106-2KN30
Rated current:	A	50	50	60
Resulting rated short-circuit current SCCR at 480 V _{AC}	kA	65	65	65
Fuses (UL)				
Type AJT Class J⁴⁾				
Rated current	A	AJT 35	AJT 35	AJT 60
Resulting rated short-circuit current SCCR				
at 480 V _{AC}	kA	65	65	65
at 600 V _{AC}	kA	200	200	200

3 axes Power Modules	6SL3111-	3VE21-6FA0	3VE21-6EA0	3VE22-0HA0
Cooling method		External air cooling		
Cooling air requirement	m ³ /h	160	160	160
Weight	kg	18.35	18.4	18.5

- 1) The specified power ratings apply for the line supply voltage range from 380 V to 480 V
- 2) The external fan unit 6SL3161-0EP00-0AA0 has been taken into account for the specified losses - also refer to the power loss calculation for partial load operation in Chapter "Control cabinet installation".
- 3) For an overview, see the power loss tables in the chapter titled "Control cabinet installation"
- 4) Source of supply: Ferraz Shawmut, <http://de.ferrazshawmut.com>

Table 3- 18 Technical data of the S120 Combi 4 axes Power Modules

4 axes Power Modules	6SL3111-	4VE21-6FA0	4VE21-6EA0	4VE22-0HA0
		16 kW / 18 A / 9 A / 5 A / 5 A	16 kW / 24 A / 9 A / 9 A / 9 A	20 kW / 30 A / 12 A / 9 A / 9 A
Infeed				
Infeed				
Rated power (S1) ¹⁾	kW (P _n)	16	16	20
Infeed power (S6-40%) ¹⁾	kW (P _{s6})	21	21	26.5
Peak infeed power ¹⁾	kW (P _{max})	35	35	40
Regenerative feedback				
Rated power (S1)	kW (P _n)	16	16	20
Peak regenerative power	kW (P _{max})	35	35	40
Supply voltages		3-ph. 380 – 10 % up to 3-ph. 480 V AC + 10 %		
Line voltage	V _{AC}	45 to 66		
Line frequency	Hz	24 (20.4 – 28.8)		
Electronics power supply	V _{DC}			
Rated input current				
at 400 V _{AC}	A _{AC}	28	28	34
at 380 V _{AC} / 480 V _{AC}	A _{AC}	29 / 25	29 / 25	35 / 30
at 400 V; S6-40%	A _{AC}	35.5	35.5	44
at 400 V _{AC} peak current	A _{AC}	56	56	63.5
Spindle				
Output current				
Rated current (I _n)	A _{ACrms}	18	24	30
Base-load current (I _H)	A _{ACrms}	15.3	20.4	25.5
Intermittent duty current (I _{s6}) 40%	A _{ACrms}	24	32	40
Peak current (I _{max})	A _{ACrms}	36	48	56
Rated power				
at 540 V DC link voltage	kW	8.7	11.7	14.4
at 600 V DC link voltage	kW	9.7	13	16
Pulse frequency spindle	kHz	4		
Output voltage	V _{ACrms}	0 - 0.7 x DC link voltage		

3.9 Technical data

4 axes Power Modules	6SL3111-	4VE21-6FA0	4VE21-6EA0	4VE22-0HA0
Feedrate 1				
Output current				
Rated current (I_n)	A _{ACrms}	9	9	12
Base-load current (I_H)	A _{ACrms}	7.7	7.7	10.3
Intermittent duty current (I_{S6}) 40%	A _{ACrms}	12	12	16
Peak current (I_{max})	A _{ACrms}	18	18	24
Rated power				
at 540 V DC link voltage	kW	4.3	4.3	5.8
at 600 V DC link voltage	kW	4.8	4.8	6.5
Pulse frequency feedrate 1	kHz	4		
Output voltage	V _{ACrms}	0 - 0.7 x DC link voltage		
Feedrate 2				
Output current				
Rated current (I_n)	A _{ACrms}	5	9	9
Base-load current (I_H)	A _{ACrms}	4.3	7.7	7.7
Intermittent duty current (I_{S6}) 40%	A _{ACrms}	6.5	12	12
Peak current (I_{max})	A _{ACrms}	10	18	18
Rated power				
at 540 V DC link voltage	kW	2.4	4.3	4.3
at 600 V DC link voltage	kW	2.7	4.8	4.8
Pulse frequency feedrate 2	kHz	4		
Output voltage	V _{ACrms}	0 - 0.7 x DC link voltage		
Feedrate 3				
Output current				
Rated current (I_n)	A _{ACrms}	5	9	9
Base-load current (I_H)	A _{ACrms}	4.3	7.7	7.7
Intermittent duty current (I_{S6}) 40%	A _{ACrms}	6.5	12	12
Peak current (I_{max})	A _{ACrms}	10	18	18
Rated power				
at 540 V DC link voltage	kW	2.4	4.3	4.3
at 600 V DC link voltage	kW	2.7	4.8	4.8
Pulse frequency feedrate 3	kHz	4		
Output voltage	V _{ACrms}	0 - 0.7 x DC link voltage		
Output for expansion axis				
DC link voltage	V _{DC}	460 – 720		
DC link output current (I_n)	A _{DC}	40		
Max. electronics output current for expansion axis	A _{24Vmax}	20		
General data				
Electronics current consumption at DC 24 V				
without external fan unit	A	1.6	1.6	1.6
with external fan unit	A	2.4	2.4	2.4
Total power loss ²⁾ (including electronics losses ³⁾)				
internal	W	87	100	113
external	W	405	507	620

4 axes Power Modules	6SL3111-	4VE21-6FA0	4VE21-6EA0	4VE22-0HA0
Max. ambient temperature				
Without derating	°C	45	45	45
With derating	°C	55	55	55
DC link voltage	V _{DC}	460 – 720		
DC link capacitance	µF	1645	2115	2520
Overvoltage tripping	V _{DC}	820 ± 2 %		
Undervoltage tripping	V _{DC}	380 ± 2 %		
Circuit breaker (UL)				
Type designation		3VL2105-2KN30	3VL2105-2KN30	3VL2106-2KN30
Rated current:	A	50	50	60
Resulting rated short-circuit current SCCR at 480 V _{AC}	kA	65	65	65
Fuses (UL)				
Type AJT Class J⁴⁾		AJT 35	AJT 35	AJT 60
Rated current	A	35	35	60
Resulting rated short-circuit current SCCR at 480 V _{AC}	kA	65	65	65
at 600 V _{AC}	kA	200	200	200
Cooling method		External air cooling		
Cooling air requirement	m ³ /h	160	160	160
Weight	kg	18.9	18.95	19.05

- 1) The specified power ratings apply for the line supply voltage range from 380 V to 480 V
- 2) The external fan unit 6SL3161-0EP00-0AA0 has been taken into account for the specified losses - also refer to the power loss calculation for partial load operation in Chapter "Control cabinet installation".
- 3) For an overview, see the power loss tables in the chapter titled "Control cabinet installation"
- 4) Source of supply: Ferraz Shawmut, <http://de.ferrazshawmut.com>

3.9.1 Characteristics

Rated duty cycles, infeed




Figure 3-21 Rated duty cycles, infeed

Rated duty cycles, spindle and feedrate




Figure 3-22 Rated duty cycles, spindle and feedrate

Derating characteristics




Figure 3-23 Rated power as a function of the temperature




Figure 3-24 Output current as a function of the installation altitude

At installation altitudes >2000 m, an insulating transformer must be used (see "System overview/Derating as a function of the installation altitude and ambient temperature"). The design of the secondary line supply system must be as follows:

- TN system with grounded star point (no grounded outer conductor)
- IT system

A reduction of the line supply voltage phase-phase is not necessary.

Reinforcement plates

4.1 Description

The reinforcement plates for the S120 Combi fulfill the following functions:

- Air is routed in a specific way to dissipate the heat of the external heat sink
- They stabilize the mounting panel

The reinforcement plates must always be mounted. They should be installed at the rear of the mounting panel or the control cabinet **before** installing the S120 Combi Power Module and the external fan unit.

Note

The reinforcement plates are not included in the scope of delivery of the S120 Combi. They must be separately ordered (order number 6SL3161-1LP00-0AA0).

4.2 Installation

The reinforcement plates for the S120 Combi must be mounted in each case. For mounting, holes that correspond to the drilling pattern below must be drilled in the mounting panel.




Figure 4-1 Drilling pattern for mounting the reinforcement plates

Holes:

4 X Ø 4.8 mm







Screws to be used:

M4 x 10 (ISO 7045 (DIN 7965), ISO 7380, DIN EN ISO 1207, ISO 1580M4)

Tightening torques:

Initially tighten by hand (0.5 Nm), then tighten with 1.8 Nm

Table 4- 1 Installing the reinforcement plates

		
<p>Guide the lefthand reinforcement plate into the mounting cut-out</p>	<p>Locate the reinforcement plate on the mounting panel</p>	<p>Screw the reinforcement plate at the top and bottom</p>
		
<p>Guide the righthand reinforcement plate into the mounting cut-out</p>	<p>Locate the reinforcement plate on the mounting panel</p>	<p>Screw the reinforcement plate at the top and bottom</p>

When installing the reinforcement plates, it is important to observe alignment.





Figure 4-2 Alignment of the reinforcement plates

4.3 Technical data



- ① Reinforcement plates
- ② Holes to remove/tighten the screws on the air baffle plate of the S120 Combi
- ③ M4x10 screws

Figure 4-3 Installed reinforcement plates: View from the front and from the rear

CAUTION

The reinforcement plates must be installed so that the openings between the S120 Combi Power Module and the external fan unit are closed.

If the reinforcing plates are incorrectly fixed, this can result in an excessively high heat sink temperature and cause the S120 Combi Power Module to prematurely trip.

4.3 Technical data

6SL3161-1LP00-0AA0	Unit	Value
Weight (2 units)	kg	1.5
Dimensions (W x H x D)	mm	150 x 57.5 x 750

External fan unit

5.1 Description

The S120 Combi provides an integrated fan control and supply for an external 24 V fan unit. The fan unit is connected via interface X12/X13. The output is designed for a maximum current of 2 A and is short-circuit and ground-fault proof.

The following functions are available when using the external fan unit:

- Operating hours counter (p0251)
- Setting the maximum operation time (P0252)
- Evaluating fault signals

5.2 Overview

The external fan unit comprises the following components:

- Fan cradle with seal for installation in the control cabinet
- Connection cables with 4-pin connector
- Double fan
- Fan support plate
- Air baffle plate




Figure 5-1 External fan unit

When a fan fails, the complete external fan unit must be replaced.

5.3 Dimension drawing




Figure 5-2 Dimension drawing of the external fan unit, all dimensions in mm and (inches)

5.4 Installation

Preparation

The external fan unit is always installed above the S120 Combi in the control cabinet.

Make an installation cut-out in the control cabinet panel. The position depends on the installation cut-out for the S120 Combi Power Module (for details, see Chapter "S120 Combi Power Modules / Installation").





Figure 5-3 Cut-out from the drilling pattern and installation cut-out S120 Combi for the external fan unit

The zero line shown above runs at the height of the upper bolts used to mount the S120 Combi Power Module.

Installation

1. Mount the self-clinching flush head studs - position 1) in the diagram above.
2. Mount the fan unit as shown below.
3. Connect the power supply cables of the fan unit to the S120 Combi Power Module.
 - Cable A to terminal X12
 - Cable B to terminal X13



Initially, tighten the nuts by hand:
0.5 Nm
Then tighten the nuts with a tightening torque
of 1.8 Nm in the specified mounting sequence
1 to 5.

Table 5- 1 Mounting accessories


Number	Designation	Specification
5	Self-clinching flush head studs	M4, steel, strength class 8.8, zinc-plated, length: 15 mm
5	Nut	M4, steel, strength class 8, zinc-plated

5.5 Technical data

The reinforcement plates must always be installed when operating the S120 Combi with the external fan unit.

CAUTION

Operation without the reinforcement plates is not permissible. If the reinforcement plates are incorrectly fixed, this can result in an excessively high heat sink temperature and cause the S120 Combi to prematurely trip.



5.5 Technical data

Table 5- 2 Technical data of the external fan unit

6SL3161-0EP00-0AA0	Unit	Value
Input voltage	V	20.4 - 28.8
Power consumption	W	18
Electronics current consumption at 24 V DC	A	0.8
Volumetric rate of air flow	m ³ /h	290
Service life	h	50000 at 55 °C 20000 at 70 °C
Dimensions (W x H x D)	mm	258 x 104 x 86
Weight	kg	1.5
Degree of protection		IP54

Topology rules for DRIVE-CLiQ

Topology rules for DRIVE-CLiQ

There are fixed DRIVE-CLiQ topology rules for the S120 Combi. These rules must be observed. If violated, then a corresponding alarm is displayed.

Assigning the DRIVE-CLiQ interfaces

Table 6- 1 Assigning the DRIVE-CLiQ interfaces on the S120 Combi

DRIVE-CLiQ interface	Connection with
X200	X100 of the PPU
X201	Motor encoder, spindle
X202	Motor encoder, feedrate 1
X203	Motor encoder, feedrate 2
X204	Motor encoder, feedrate 3 -> only for 4 axes Power Module remains empty for 3 axes Power Module
X205	Optional: 2. Direct sin/cos encoder for spindle (via SMx20) ¹⁾ remains empty when a direct TTL spindle encoder is connected via X220

1) in this case, the TTL encoder interface X220 remains free

Table 6- 2 Assigning the DRIVE-CLiQ interfaces to the SINUMERIK 828D (PPU)

DRIVE-CLiQ interface	Connection with
X100	X200 of the S120 Combi
X101	X200 of a Single Motor Module or Double Motor Module
X102	X500 of the Terminal Module TM54F X500 of the Hub Modules (DMx20) ¹⁾

1) when using a TM54F, the DMx20 is connected in series at the TM54F via the DRIVE-CLiQ interface X501

Table 6- 3 Assigning the DRIVE-CLiQ interfaces of the expansion axes

DRIVE-CLiQ interface	Connection with
First Single Motor Module	
X200	X101 of the PPU
X201 ¹⁾	X200 of the second Single Motor Module
X202	Motor encoder for feedrate 1st expansion axis (via Sensor Module)
Second Single Motor Module	
X200	X201 of the first Single Motor Module
X201	Remains empty
X202	Motor encoder for feedrate 2nd expansion axis (via Sensor Module)
Double Motor Module	
X200	X101 of the PPU
X201	Remains empty
X202	Motor encoder for feedrate 1st expansion axis
X203	Motor encoder for feedrate 2nd expansion axis

1) remains empty, if only one Single Motor Module is used

Table 6- 4 Assigning the DRIVE-CLiQ interfaces at the TM54F

DRIVE-CLiQ interface	
X500	X102 of the control (PPU)
X501	X500 of the DMx20 if a DMx20 is not used, then this interface remains empty

Table 6- 5 Assigning the DRIVE-CLiQ interfaces at the DMx20 to assign a direct measuring system to the feed axes.

DRIVE-CLiQ interface	Feed axis
X500	X501 of the TM54F X102 of the PPU ¹⁾
X501	Feedrate 1 at the S120 Combi
X502	Feedrate 2 at the S120 Combi
X503	Feedrate 3 at the S120 Combi (4 axes Power Modules)
X504	Feedrate 1st expansion axis at the Motor Module
X505	Feedrate 2nd expansion axis at the Motor Module

1) only if a TM54F is not being used

6.1 Connection examples

6.1.1 Operation with a 3 axes Power Module




Figure 6-1 DRIVE-CLiQ wiring with TTL encoder for an S120 Combi 3 axes Power Module and two Single Motor Modules

6.1 Connection examples




Figure 6-2 DRIVE-CLiQ wiring with TTL encoder for an S120 Combi 3 axes Power Module and two Single Motor Modules without TM54F

6.1.2 Operation with a 4 axes Power Module




Figure 6-3 DRIVE-CLiQ wiring with TTL encoder for an S120 Combi 4 axes Power Module and two Single Motor Modules

6.1 Connection examples




Figure 6-4 DRIVE-CLiQ wiring with TTL encoder for an S120 Combi 4 axes Power Module and a Double Motor Module




Figure 6-5 DRIVE-CLiQ wiring with angular encoder for an S120 Combi 4 axes Power Module and two Single Motor Modules

Motor Modules Booksize Compact as expansion axes

7

7.1 Description

A Motor Module Booksize Compact is an inverter that provides the power for the connected motor(s). The power is supplied from the DC link of the S120 Combi. The Motor Modules must be connected to the SINUMERIK 828D control via DRIVE-CLiQ (see Chapter "Topology rules for DRIVE-CLiQ").


One motor can be connected to Single Motor Modules and two motors can be connected to Double Motor Modules.


The Motor Modules Booksize Compact are operated in combination with the S120 Combi using the "internal air cooling" cooling method.

Note

For the dimensioning of the expansion axes, the infeed power must be taken into account (demand factor).

7.2 Safety information

 DANGER
Risk of electric shock A hazardous voltage is still present for up to 5 minutes after the power supply has been switched off. It is only permissible to open the protective cover after this time has expired. When opening the protective cover for the DC link, you must press the release catch. A suitable tool (e.g. screwdriver or supplied unlocking tool) must be used for this purpose. The components must only be operated when the protective cover of the DC link is closed. Damaged components must not be used further, Secondary damage or accidents can otherwise result.

 DANGER
DC-link discharge voltage A DC-link discharge voltage danger notice in the relevant national language must be attached to all of the components. A set of labels in 16 languages is supplied with the component.

 **DANGER**

The drive components generate high leakage currents in the protective conductor. The components must only be operated in control cabinets or in closed electrical operating areas and must be connected with the protective conductor. To protect against electric shock, the protective conductor connection at the control cabinet or machine must be implemented in accordance with one of the following measures:

- Stationary connection and protective conductor connection by means of $\geq 10 \text{ mm}^2$ Cu or $\geq 16 \text{ mm}^2$ Al
- stationary connection and installation of a second protective conductor with the same cross-section as the first protective conductor
- stationary connection and automatic shutdown of the line supply if the protective conductor is interrupted
- Connection with a plug connector for industrial applications in accordance with EN 60309 and a minimum protective conductor cross-section of $\geq 2.5 \text{ mm}^2$ Cu as part of a multi-core supply cable with appropriate strain relief

 **DANGER**

It is essential to apply the shield for the motor holding brake. Furthermore, only MOTION-CONNECT cables must be used for integrated motor holding brakes, as otherwise insulation of the cores is not guaranteed. Risk of electric shock.

 **WARNING**

Cable shields and unused power cable cores (e.g. brake cores) must be connected to PE potential to prevent capacitive cross-talk charges.

Non-observance can cause lethal shock voltages.

 **CAUTION**

The cooling clearances of 80 mm above and below the components must be observed.

CAUTION

The tightening torque of the DC-link busbar screws (1.8 Nm, tolerance +30 %) must be checked before commissioning. After transportation, the screws must be tightened.

CAUTION

Only cables from SIEMENS may be used for DRIVE-CLiQ connections.

CAUTION

Connecting cables to temperature sensors must always be installed with shielding. The cable shield must be connected to the ground potential at both ends through a large surface area. Temperature sensor cables that are routed together with the motor cable must be twisted in pairs and shielded separately.

CAUTION

DC-link lateral covers are supplied with the components as standard and must be attached to the last component in the drive line-up. They can also be ordered separately, if required (Order No.: 6SL3162-5AA00-0AA0).
--

Note

A regulated DC power supply is required to operate motors with a built-in holding brake. The voltage is supplied via the internal 24 V busbars. The voltage tolerances of the motor holding brakes (24 V \pm 10%) and the voltage drops of the connecting cables must be taken into account.

The DC power supply should be set to 26 V. This ensures that the supply voltage for the brake remains within the permissible range when the following conditions are fulfilled:

- Use of Siemens three-phase motors
 - Use of Siemens MOTION-CONNECT power cables
 - Motor cable lengths: max. 70 m
-

7.3 Interface description

7.3.1 Overview




Figure 7-1 Interface overview, Single Motor Module Booksize Compact (example: 5 A)







Figure 7-2 Interface overview, Double Motor Module Booksize Compact (example: 2 x 5 A)

7.3 Interface description

7.3.2 X1/X2 motor connection


Table 7- 1 X1/X2 motor connection

	Terminal	Technical specifications
	U2	Max. connectable cross-section: 6 mm ² Type: Screw terminal 5 (see Chapter "Control cabinet installation and EMC / connection system") Tightening torque: 1.2 - 1.5 Nm
	V2	
	W2	
	PE connection	Single Motor Modules 3 A to 18 A Threaded hole M5/3 Nm ¹
		

1) For ring cable lugs in accordance with DIN 46234

7.3.3 X11/X12 motor brake connection

Table 7- 2 X11/X12 brake connection

	Terminals	Designation	Technical specifications
	BR+	Brake connection +	Voltage 24 V DC Max. load current 2 A Min. load current 0.1 A Max. connectable cross-section 2.5 mm ² Type: Spring-loaded terminal 1 (see Chapter "Control cabinet installation and EMC / connection system") Manufacturer: Wago; order number: 721-102/026-000/56-000 The brake connector is included in the scope of delivery.
	BR-	Brake connection -	

The circuit for protecting the brake against overvoltage is integrated in the Motor Module and does not need to be installed externally.

Note

The motor brake must be connected via connector X11 on Single Motor Modules, and X11 and X12 on Double Motor Modules. The BR- cable must not be connected directly to electronics ground (M).


WARNING

Only protective extra-low voltages (DVC A) that comply with EN 60204-1 must be connected to all connections and terminals between 0 and 48 V DC.

The voltage tolerances of the motor holding brakes (24 V ± 10 %) must be taken into account.

7.3.4 X21/X22 EP terminals / temperature sensor Motor Module

Table 7- 3 X21/X22 EP terminals/temperature sensor

	Terminal	Function	Technical specifications
	1	+ Temp	Temperature sensors: KTY84-1C130 / PTC / bimetallic switch with NC contact
	2	- Temp	
	3	EP +24 V (Enable Pulses)	Supply voltage: 24 V DC (20.4 V - 28.8 V) Current consumption: 10 mA Isolated input Signal propagation times: L → H: 100 μs H → L: 1000 μs The pulse inhibit function is only available when Safety Integrated Basic Functions are enabled.
	4	EP M1 (Enable Pulses)	
Max. connectable cross-section 1.5 mm ² Type: Screw terminal 1 (see Chapter "Control cabinet installation and EMC / connection system")			

NOTICE

The function of the EP terminals is only available when Safety Integrated Basic Functions are enabled.


Parameters p9651 and p9851 are used to set the filter times for the debouncing of terminals X21.3 and X21.4, as well as X22.3 and X22.4. Additional parameter settings are also required in order to prevent discrepancy errors when performing bit pattern tests (light/dark tests). For comprehensive information, see the SINAMICS S120 Safety Integrated Function Manual, Chapter 6 "Controlling the safety functions".

NOTICE

The KTY temperature sensor must be connected with the correct polarity. If the polarity is reversed, the sensor will not be able to detect if the motor overheats.

Note

The temperature sensor input is not needed if the motors feature an integrated DRIVE-CLiQ interface or if temperature values are detected by means of a different module (SMC, SME).

 **DANGER**

Risk of electric shock!


Only temperature sensors that meet the safety isolation specifications contained in EN 61800-5-1 may be connected to terminals "+Temp" and "-Temp".

If these instructions are not complied with, there is a risk of electric shock!

7.3.5 X200-X203 DRIVE-CLiQ interface

Table 7-4 X200-X202: DRIVE-CLiQ interfaces for Single Motor Modules


X200-X203: DRIVE-CLiQ interfaces for Double Motor Modules

	Pin	Name	Technical specifications
	1	TXP	Transmit data +
	2	TXN	Transmit data -
	3	RXP	Receive data +
	4	Reserved, do not use	
	5	Reserved, do not use	
	6	RXN	Receive data -
	7	Reserved, do not use	
	8	Reserved, do not use	
	A	+ (24 V)	Power supply
	B	M (0 V)	Electronics ground

The blanking covers for the DRIVE-CLiQ interfaces are included in the scope of delivery.

Blanking cover (50 pcs.) Order number: 6SL3066-4CA00-0AA0

7.4 Connection example



- 1) Required for Safety
- 2) SMC required for motors without DRIVE-CLiQ interface
- 3) 24 V to the next module
- 4) An alternative possibility of the motor temperature evaluation

Figure 7-3 Connection example, Single Motor Modules Booksize Compact 3 A to 18 A and Double Motor Modules Booksize Compact 1.7 A to 5 A

7.5 Meaning of the LEDs on the Motor Module Booksize Compact

Table 7- 5 Meaning of the LEDs on the Single Motor Module/Double Motor Module

Status		Description, cause	Remedy
RDY	DC LINK		
OFF	OFF	Electronics power supply is missing or outside permissible tolerance range.	–
Green	--	The component is ready for operation and cyclic DRIVE-CLiQ communication is taking place.	–
	Orange	The component is ready for operation and cyclic DRIVE-CLiQ communication is taking place. The DC link voltage is present.	–
	Red	The component is ready for operation and cyclic DRIVE-CLiQ communication is taking place. The DC link voltage is too high.	Check the line supply voltage.
Orange	Orange	DRIVE-CLiQ communication is being established.	–
Red	--	This component has at least one fault. Note: The LED is activated regardless of whether the corresponding messages have been reconfigured.	Remedy and acknowledge fault
Green / Red (0.5 Hz)	--	Firmware is being downloaded.	–
Green / Red (2 Hz)	--	Firmware download is complete. Wait for POWER ON.	Carry out a POWER ON
Green/Orange or Red/Orange	--	Detection of the components via LED is activated (p0124). Note: Both options depend on the LED state when activated via p0124 = 1.	–

 **DANGER**

Hazardous DC link voltages may be present at any time regardless of the state of the "DC LINK" LED.

The warning information on the component must be carefully observed!

7.6 Dimension drawings

7.6 Dimension drawings




Figure 7-4 Dimension drawing of 3 A, 5 A, and 9 A Motor Modules Booksize Compact, all dimensions in mm and (inches); example: 5 A Single Motor Module

Table 7- 6 Motor Modules Booksize Compact 3 A, 5 A, and 9 A

Motor Module	Order number
3 A Single Motor Module	6SL3420-1TE13-0AAx
5 A Single Motor Module	6SL3420-1TE15-0AAx
9 A Single Motor Module	6SL3420-1TE21-0AAx




Figure 7-5 Dimension drawing of 18 A Motor Module Booksize Compact, all dimensions in mm and (inches)

Table 7-7 Motor Module Booksize Compact 18 A

Motor Module	Order number
18 A Single Motor Module	6SL3420-1TE21-8AAx

7.6 Dimension drawings





Figure 7-6 Dimension drawing of 2 x 1.7 A, 2 x 3 A, and 2 x 5 A Double Motor Modules Compact, all dimensions in mm and (inches); example: 2 x 5 A Double Motor Module

Table 7- 8 2 x 1.7 A, 2 x 3 A, and 2 x 5 A Double Motor Modules Booksize Compact

Double Motor Module	Order number
2 x 1.7 A Double Motor Module	6SL3420-2TE11-0AAx
2 x 3 A Double Motor Module	6SL3420-2TE13-0AAx
2 x 5 A Double Motor Module	6SL3420-2TE15-0AAx

7.7 Installation

Installing a Motor Module Booksize Compact



- 1 Mounting wall
 2 M6 x 16 screw
 Hex combination screw or hex screw with spring washer and plain washer

Figure 7-7 Installing a Motor Module Booksize Compact with internal air cooling

Tightening torques:

- Initially, tighten by hand (0.5 Nm)
- Then tighten with 6 Nm (in the specific sequence 1 to 4)

7.8 Technical data

Table 7-9 Technical data Single Motor Modules Booksize Compact (3 A to 18 A)

Single Motor Modules Booksize Compact	6SL3420-	1TE13-0AAx	1TE15-0AAx	1TE21-0AAx	1TE21-8AAx
Output current					
Rated current (I_n)	A_{ACrms}	3	5	9	18
Base-load current (I_H)	A	2.6	4.3	7.7	15.3
Intermittent duty current (I_{s6}) 40%	A_{ACrms}	3.5	6	10	24
Peak current (I_{max})	A_{ACrms}	9	15	27	54
Output voltage	V_{ACrms}	0 - 0.717 x DC link voltage			
DC link current I_d	A_{DC}	3.6	6	11	22
DC link voltage (up to 2000 m above sea level)	V_{DC}	510 – 720			
DC link capacitance	μF	110	110	110	235
Overvoltage tripping	V_{DC}	820 ± 2 %			
Undervoltage tripping¹⁾	V_{DC}	380 ± 2 %			
Electronics power supply	V_{DC}	24 (20.4 - 28.8)			
Electronics current consumption at 24 V DC	A_{DC}	0.85	0.85	0.85	0.85
Current carrying capacity					
DC link busbar	A_{DC}	100	100	100	100
Reinforced DC link busbars	A_{DC}	150	150	150	150
24 V busbar	A_{DC}	20	20	20	20
Max. current motor brake	A	2	2	2	2
Unit rating					
Based on I_n (600 V_{DC} ; 4 kHz)	kW	1.6	2.7	4.8	9.7
Based on I_H	kW	1.4	2.3	4.1	13.7
Total power loss (including electronics losses) ²⁾	W	68 at 8 kHz	98 at 8 kHz	100.4 at 4 kHz	185.4 at 4 kHz
Max. pulse frequency					
Without derating	kHz	8	8	4	4
With derating	kHz	16	16	16	16
Max. ambient temperature					
Without derating	°C	40			
With derating	°C	55			
Sound pressure level	dB(A)	<60	<60	<60	<60
Cooling method		Internal air cooling			
Cooling air requirement	m^3/h	29.6	29.6	29.6	29.6
Weight	kg	2.7	2.7	2.7	3.4

1) Default for 400 V line supplies; undervoltage trip threshold can be reduced by a maximum of 80 V and is adjusted to the parameterized line voltage.

2) For an overview, see the power loss tables in chapter Control cabinet installation

Table 7- 10 Technical data Double Motor Modules Booksize Compact (2 x 1.7 A to 2 x 5 A)

Double Motor Modules Booksize Compact	6SL3420-	2TE11-0AAx	2TE13-0AAx	2TE15-0AAx
Output current				
Rated current (I_n)	A_{ACrms}	2 x 1.7	2 x 3	2 x 5
Base-load current (I_H)	A	2 x 1.5	2 x 2.6	2 x 4.3
Intermittent duty current (I_{S6}) 40%	A_{ACrms}	2 x 2	2 x 3.5	2 x 6
Peak current (I_{max})	A_{ACrms}	2 x 5.1	2 x 9	2 x 15
Output voltage	V_{ACrms}	0 - 0.717 x DC link voltage		
DC link current I_d	A_{DC}	4.1	7.2	12
DC link voltage (up to 2000 m above sea level)	V_{DC}	510 – 720		
DC link capacitance	μF	165	165	165
Overvoltage tripping	V_{DC}	820 \pm 2 %		
Undervoltage tripping¹⁾	V_{DC}	380 \pm 2 %		
Electronics power supply	V_{DC}	24 (20.4 - 28.8)		
Electronics current consumption at 24 V DC	A_{DC}	1.15	1.15	1.15
Current carrying capacity				
DC link busbar	A	100	100	100
Reinforced DC link busbars	A	150	150	150
24 V busbar	A	20	20	20
Max. current motor brake	A	2 x 2	2 x 2	2 x 2
Unit rating				
Based on I_n (600 V, 8 kHz)	kW	2 x 0.9	2 x 1.6	2 x 2.7
Based on I_H	kW	2 x 0.8	2 x 1.4	2 x 2.3
Total power loss (including electronics losses) ²⁾ at 8 kHz	W	114	134	194
Max. pulse frequency				
Without derating	kHz	8	8	8
With derating	kHz	16	16	16
Max. ambient temperature				
Without derating	$^{\circ}C$	40		
With derating	$^{\circ}C$	55		
Sound pressure level	dBA	<60	<60	<60
Cooling method		Internal air cooling using an integrated fan		
Cooling air requirement	m^3/h	29.6	29.6	29.6
Weight	kg	3.4	3.4	3.4

1) Default for 400 V line supplies; undervoltage trip threshold can be reduced by a maximum of 80 V and is adjusted to the parameterized line voltage.

2) For an overview, see the power loss tables in chapter Control cabinet installation

7.8.1 Characteristics

Rated duty cycles Motor Modules Booksize Compact




Figure 7-8 Duty cycle with initial load




Figure 7-9 Duty cycle without initial load




Figure 7-10 S6 duty cycle with initial load with a duty cycle duration of 600 s




Figure 7-11 S6 duty cycle with initial load with a duty cycle duration of 60 s




Figure 7-12 Peak current duty cycle with initial load




Figure 7-13 Duty cycle with 60 s overload with a duty cycle duration of 300 s




Figure 7-14 Duty cycle with 30 s overload with a duty cycle duration of 300 s

Derating characteristics for Motor Modules Booksize Compact




Figure 7-15 Output current as a function of the ambient temperature




Figure 7-16 Output current as a function of the pulse frequency for the Motor Module ≤ 5 A




Figure 7-17 Output current as a function of the pulse frequency for the Motor Module ≥ 9 A




Figure 7-18 Output current as a function of the installation altitude




Figure 7-19 Current derating as a function of the output frequency

At installation altitudes >2000 m, an insulating transformer must be used (see "System overview/Derating as a function of the installation altitude and ambient temperature"). The design of the secondary line supply system must be as follows:

- TN system with grounded star point (no grounded outer conductor)
- IT system

A reduction of the line supply voltage phase-phase is not necessary.

DC link components

8.1 Braking Module Booksize

8.1.1 Description

The Braking Module is used together with a braking resistor to

- be able to stop the S120 Combi and expansion axes in a controlled fashion when the power fails (e.g. emergency retraction or EMERGENCY OFF Category 1).
- limit the DC link voltage for brief generator operation, if e.g. the energy recovery function is deactivated or is not adequately dimensioned.

The Braking Module includes the necessary power electronics and control. When the Braking Module is in operation, the power which is fed back into the DC link is dissipated via an external braking resistor.

External braking resistors

On the Braking Module, braking resistors can be operated without thermostatic switches 6SN1113-1AA00-0DA0 ($P_N = 0.3$ kW) and 6SL3100-1BE31-0AA0 ($P_N = 1.5$ kW). The cable length between the Braking Module and the braking resistor is limited to a maximum of 10 m.

A shielded connection cable (3 m, 3 x 1.5 mm²) is supplied with braking resistor 6SN1113-1AA00-0DA0.

Rapid discharge




Furthermore, the Braking Module can be used with a braking resistor to quickly discharge the DC link capacitors. The DC link is discharged in a controlled manner via the braking resistor once the infeed unit has been switched off and the line-up has been disconnected from the line supply (e.g. via the main switch or line contactor). The function can be activated via a digital input on the braking module. A quick discharge makes sense, for example, when maintenance tasks are to be performed at the S120 Combi and/or motor installation (reduction of the discharge time).

CAUTION
The drive system must be completely disconnected from the line supply in order for rapid discharge to take place. The motors must be at a standstill.

Monitoring functions

- Automatic detection of braking resistors and braking power monitoring
- I²t monitoring of the braking resistors
- Temperature monitoring of the Braking Module
- Short circuit and overload detection
- Ground fault detection

8.1.2 Safety information

 DANGER
Risk of electric shock A hazardous voltage is present for up to 5 minutes after the power supply has been disconnected. Only after this time has expired may the protective cover be opened using a suitable tool. The components must only be operated when the protective cover of the DC link is closed. Damaged components must not be used further, Secondary damage or accidents can otherwise result.
 DANGER
DC link discharge time The hazard warning for the DC link discharge time must be attached to the component in the local language. A set of labels in 16 languages is supplied with the component. With a connected braking resistor, the Braking Module is ground-fault proof.
 WARNING
The cooling clearances of 80 mm above and below the components must be observed.
CAUTION
The connection to the braking resistors must be made using a shielded cable. The tightening torque of the DC-link busbar screws (1.8 Nm, tolerance +30 %) must be checked before commissioning. After transportation, the screws must be tightened.
CAUTION
DC link side covers are supplied with the components as standard and must be attached to the last component in the S120 Combi drive line-up. They can also be ordered separately, if required (order no.: 6SL3162-5AA00-0AA0).

Note

If braking resistors other than 6SN1113-1AA00-0DA0 and 6SL3100-01BE31-0AAx as described in Chapter "Braking resistors", are used then these could be destroyed.

8.1.3 Interface description

8.1.3.1 Overview




Figure 8-1 Interface overview, Braking Module Booksize

8.1.3.2 X1 braking resistor connection

Table 8-1 X1 braking resistor connection


	Terminal	Designation	Technical specifications
	1	Braking resistor connection R1	Continued-short-circuit-proof
	2	Braking resistor connection R2	
Max. connectable cross-section: 4 mm ² Type: Screw terminal 4 (see Chapter "Control cabinet installation and EMC / connection system")			

Table 8-2 Braking resistors without a thermostatic switch for Braking Modules


Braking resistor	R in Ω	P _N in kW	P _{max} in kW
6SN1113-1AA00-0DA0	17	0.3	25
6SL3100-1BE31-0AA0	5.2	1.5	100

Note

For detailed technical information on the braking resistors, see the chapter titled "DC link components/braking resistors".

8.1.3.3 X21 digital inputs/outputs

Table 8-3 X21 digital inputs/outputs

	Terminal	Designation ¹⁾	Technical specifications
	1	DI low: enable Braking Module DI high: Inhibit/acknowledge Edge change high -> low: fault acknowledgement	Voltage: -3 V to +30 V Typical current consumption: 10 mA at 24 V DC
	2	DI low: braking resistor not activated manually DI high: Braking resistor controlled manually (quick discharge) ²⁾ If X21.1 and 2 are activated simultaneously, the Braking Module inhibit has priority.	Level (incl. ripple) High level: 15 V to 30 V Low level: -3 V to 5 V
	3	DO high: no prewarning DO low: Prewarning, disconnection imminent	Max. load current per output: 100 mA Continued-short-circuit-proof
	4	DO high: ready for operation, no fault DO low: Fault (1→0)	Voltage: 24 V DC
	5	Ground	
	6		
Max. connectable cross-section 1.5 mm ² Type: Screw terminal 1 (see Chapter "Control cabinet installation and EMC / connection system")			

1) DI: digital input; DO: digital output; M: Electronics ground

2) The fast discharge function is used for discharging the capacitors in the DC link after interruption of the line supply and may be used a maximum of 1-2 times per week.

Terminal X21.1 - inhibit/acknowledge

Applying a high signal to terminal X21.1 inhibits the Braking Module. On a falling edge, pending error signals are acknowledged.

Terminal X21.3 - prewarning

When a prewarning is sent, disconnection of the braking module is imminent.

This may be due to the following causes:

- The temperature of the Braking Module is 80% of the maximum value.
- 80% of the maximum ON time of the braking resistor has been reached (I²t monitoring).
- 80% of the maximum braking energy of the braking resistor has been reached.
- An incorrect braking resistor is connected (only braking resistors approved by Siemens for this component are identified automatically).

Terminal X21.4 - fault

In the event of an overtemperature, the error cannot be acknowledged until after a cooling phase.

8.1.4 Connection example




Figure 8-2 Connection example of a Braking Module Booksize

8.1.5 Meaning of LEDs

Table 8- 4 Meaning of the LEDs on the Braking Module Booksize

LED	Color	Status	Description, cause	Remedy
READY	-	Off	Electronics power supply is missing or outside permissible tolerance range. Component deactivated via terminal.	-
	Green	Continuous light	Component is ready to operate.	-
	Red	Continuous light	Enable missing (input terminal) Overtemperature Overcurrent trip I ² t monitoring activated Ground fault/short circuit Note: In the event of an overtemperature, the error cannot be acknowledged until a cooling time has elapsed.	Diagnose fault (via output terminals) and acknowledge it (via input terminal)
DC LINK	-	Off	Only braking resistors approved by Siemens for this component are identified automatically. Component not active.	-
	Green	Flashing light	Component active (DC link discharge via braking resistor in progress).	-

8.1.6 Dimension drawing





Figure 8-3 Dimension drawing of Braking Module, all dimensions in mm and (inches)

8.1.7 Installation



- ① Delivery condition with spacer - mounting depth for drive line-up in booksize format with internal air cooling
- ② Spacer removed - mounting depth for drive line-up in booksize format with external air cooling

Figure 8-4 Methods of installing Braking Modules with/without spacer elements

8.1.8 Technical data

Table 8- 5 Technical data

6SL3100-1AE31-0AB0		
DC link voltage	V _{DC}	510 - 720
ON threshold	V	770
Electronics power supply	V _{DC}	24 (20.4 – 28.8)
Electronics current consumption (at 24 V DC)	A _{DC}	0.5
Current carrying capacity		
DC link busbar	A _{DC}	100
24 V busbar	A _{DC}	20
Rated power		
max.	kW	100
Continuous braking power	kW	1.5
Power loss ¹⁾	W	20
Cooling method		Natural convection
Weight	kg	4.1

1) For an overview, see the power loss tables in chapter Control cabinet installation

8.1.8.1 Characteristic curves

Duty cycle for braking resistors without a thermostatic switch




Figure 8-5 Duty cycle for braking resistors without a thermostatic switch

T [s] time period of braking duty cycle

A [s] load duration

P_N [W] rated power (continuous power) of braking resistor

P_{max} [W] peak power of braking resistor ($6 \times P_N$)

Table 8- 6 Duty cycles

	6SN1113-1AA00-0DA0		6SL3100-1BE31-0AAx	
	Short duty cycle	Long duty cycle	Short duty cycle	Long duty cycle
A [s]	0.1	0.4	1	2
T [s]	11.5	210	68	460

The following applies when connecting Braking Modules in parallel:

$P_{N \text{ total}} = 0.9 \times \text{total } P_N \text{ of single devices}$

$P_{max \text{ total}} = \text{total } P_{max} \text{ of single devices}$

8.1.8.2 Configuration instructions

DC link capacitance

To operate the Braking Modules, a minimum capacitance is required in the DC link. The DC link voltage of braking resistors is 440 μ F each.

The capacitance of the Braking Module of 110 μ F is included in the total capacitance value.

When booksize format Braking Modules are connected in parallel, the DC link capacitance specified above must be available for each Braking Module.

Note

Only the components that are connected to each other via the DC link busbar can be included in the total capacitance.

DC link cable

When using a Braking Module in the drive line-up, this DC link cable must not be longer than 10 m. In all cases, the DC link cable must have low impedance and a cross-section of at least 10 mm².

8.2 Control Supply Module CSM

8.2.1 Description

The Control Supply Module provides an output voltage of 24 V - 28.8 V DC. The output voltage can be adjusted using an integrated potentiometer.

In normal operation, the Control Supply Module is supplied from the line voltage. In the event of a power failure, the module automatically changes over to supply from the DC link. This makes it possible, for example, to execute retraction movements in the event of a failure of the line supply.

The Control Supply Module has safe electrical separation between the line potential and the DC-link potential. This therefore ensures that the DC link is not unintentionally charged. The Control Supply Module can therefore remain connected to the line supply if the S120 Combi is electrically isolated from the line supply, for example via a line contactor.

The 24 V ground of the Control Supply Module is internally grounded.
The Control Supply Module is cooled using an internal fan.

Temperature and voltages are internally monitored.

Temperature monitoring:

In the event of an overtemperature in the Control Supply Module, a temperature advance warning is issued via a signaling contact. If the temperature falls below the limit value within the advance warning time, then the module remains operational and the signaling contact is de-energized. If the overtemperature condition persists, the module is switched off and restarted.

Voltage monitoring:

When the monitoring threshold (32 V) of the output voltage is exceeded for > 20 ms, the control supply module switches off and attempts a restart after 10 s. This is supplemented by a hardware-based overvoltage limiting. This prevents that more than 35 V can be output in the case of a fault.




The Control Supply Module can either be operated individually or in a parallel connection with a maximum of 10 devices. The switchover between single and parallel operation is realized in a no-current state using a DIP switch on the upper side of the module.

Note

Compatibility

The new Control Supply Module 6SL3100-1DE22-0AA1 with extended functions described here replaces Control Supply Module 6SL3100-1DE22-0AA0. The modules are spare-part-compatible.

8.2.2 Safety information

 DANGER
Risk of electric shock This component is equipped with two supply circuits! A hazardous voltage is still present for up to 5 minutes after the power supply has been switched off. Only after this time has expired may the protective cover be opened using a suitable tool. The components must only be operated when the protective cover of the DC link is closed. Damaged components (e.g. with a defective lock on the protective cover) must not be operated further. Secondary damage or accidents can otherwise result.
 DANGER
DC link discharge time The hazard warning for the DC link discharge time must be attached to the component in the local language. A set of labels in 16 languages is supplied with the component.
 WARNING
The cooling clearances of 80 mm above and below the components must be observed.
CAUTION
The tightening torque of the DC link busbar screws (1.8 Nm, tolerance +30 %) must be checked before commissioning. After transportation, the screws must be tightened.
CAUTION
DC link side covers are supplied with the components as standard and must be attached to the last component in the S120 Combi drive line-up. They can also be ordered separately, if required (order no.: 6SL3162-5AA00-0AA0).
CAUTION
Use of the 24 V terminal adapter When using the 24 V terminal adapter, it must be screwed onto the Control Supply Module using the EJOT PT K30 x 16 screw supplied (tightening torque: 0.5 Nm).

8.2.3 Interface description

8.2.3.1 Overview






Figure 8-6 Interface overview, Control Supply Module


8.2.3.2 X1 line connection

Table 8-7 X1 line connection

	Terminal	Technical specifications
	U1 V1 W1	Supply voltage: 3-ph. 380 V - 480 V AC, 50 / 60 Hz Max. connectable cross-section: 4 mm ² Type: Screw terminal 4 (see Chapter "Control cabinet installation and EMC / connection system") Tightening torque: 0.5 - 0.6 Nm
	PE connection	M5 screw / 3 Nm at the housing

8.2.3.3 X21 signaling contact

Table 8- 8 X21 signaling contact



	Terminal	Technical specifications
	1	Voltage 24 V DC max. load current 0.5 A (ohmic load)
	2	
Max. connectable cross-section 1.5 mm ² Type: Screw terminal 2 (see Chapter "Control cabinet installation and EMC / connection system")		

The 2-pole terminal connector for the signaling contact is included in the Completion Kit provided.

The signaling contact can be wired to a digital input (DI) of the Control Unit to indicate the failure of a Control Supply Module.


The signaling contact operates as an isolated NO contact. When the switch is closed, the Control Supply Module is "OK" and provides the output voltage. The switch opens in the event of a fault "Not OK" – when the overtemperature condition is still present, after a pre-warning, wire breakage, short-circuit etc. The Control Supply Module is correspondingly switched off.

Table 8- 9 Installing the signaling contact

	
Signaling contact without terminal connector in the delivery condition	Signaling contact, complete with terminal connector


8.2.3.4 X24 24 V terminal adapter

Table 8- 10 X24 24 V terminal adapter

	Terminal	Designation	Technical specifications
	+	24 V power supply	Supply voltage 24 - 28.8 V DC
	M	Ground	Electronics ground
<p>The 24 V terminal adapter is supplied as standard. Max. connectable cross-section: 6 mm² Type: Screw terminal 5 (see Chapter "Control cabinet installation and EMC / connection system")</p>			

8.2.3.5 S1 DIP switch

Table 8- 11 DIP switch S1

	Terminal	Designation	Technical specifications
	1	Changeover switch, single operation / parallel operation	Left: Single operation Right: Parallel operation Changing over the output characteristic
	2	Dummy contact (not used)	

The changeover is only made in the no-voltage state.




Figure 8-7 DIP switch on the upper side of the component

When delivered, "single operation" is set. Both switches are set to the left.

Note

The DIP switch must be set to "single operation" when operating the Control Supply Module on the S120 Combi.

8.2.4 Connection example

The Control Supply Module is connected to the line supply (3-ph. 380 V AC –10 % to 480 V AC +10 %) via interface X1 (screw terminals 0.2 to 4 mm²) This connection should preferably be made without using an isolating device (e.g. contactor).

The CSM has an internal line filter (Class A for TN line supplies), and the pre-charging circuit for the DC link inside the unit is electrically isolated from the 24 V supply.

The CSM also features a current limitation function. When using cables with a cross-section of 2.5 mm², no additional protection is required on the 24 V side if a type XLPE or EPR cable, or a cable with a similar quality and with a thermal stability of up to 90 °C is used.

Note

If a selectively tripping, AC/DC-sensitive RCCB is used for the drive line-up, the Control Supply Module must always be connected to the line supply downstream of this circuit breaker.

Note

Connecting to the line supply

When configuring the line supply for the Control Supply Module, it should be noted that the CSM must not be connected to the line supply after the S120 Combi has been connected to the line supply. When charging, this prevents the DC link from being immediately loaded by the CSM.

The DIP switch must be set to "single operation" to connect the Control Supply Module to the S120 Combi drive line-up. The connection can be established as shown below.

The CSM must be connected to the S120 Combi Power Module and the expansion axes via the DC link busbars as well as also via the 24 V busbars. It imperative to insert the red 24 V connector from the accessories pack provided.




Figure 8-8 Connection example of Control Supply Module CSM in single operation

8.2.5 Meaning of the LEDs on the Control Supply Module

Table 8- 12 Meaning of the LEDs on the Control Supply Module

LED	Color	Status	Description
READY	-	Off	Electronics power supply outside the permissible tolerance range or temperature advance warning active
	Green	Continuous light	Ready for operation. Output voltage in the tolerance range and temperature advance warning inactive
DC LINK	-	Off	DC input voltage $V_{E\ DC} < 280...300\ V$ Buffer operation not possible
	Yellow	Continuous light	DC input voltage in the range $360...380 < V_{E\ DC} < 820\ V \pm 3\ \%$ Buffer operation possible
	Red	Continuous light	DC input voltage outside the tolerance range: $V_{E\ DC} < 360...380\ V$ or $V_{E\ DC} > 820\ V \pm 3\ \%$

8.2.6 Dimension drawing





Figure 8-9 Dimension Control Supply Module, all dimensions in mm and (inches)

8.2.7 Installation



- ① Delivery condition with spacer - mounting depth for drive line-up in booksize format with internal air cooling
- ② Spacer removed - mounting depth for drive line-up in booksize format with external air cooling

Figure 8-10 Methods of installing the Control Supply Module with and without spacer

The Control Supply Module can be attached to the control cabinet panel with or without spacers.

8.2.8 Technical data

Table 8- 13 Technical data

6SL3100-1DE22-0AA1		
Input data, AC input		
Line voltage	V _{AC}	3-ph. 380 - 480 V _{AC} ± 15 %
Line frequency	Hz	45 to 66
Rated input current		
Rated value (at V _{E rated})	A _{AC}	≤ 2
Starting current inrush	A _{AC}	≤ 28 at > 5 ms
Input data, DC input		
Rated input voltage	V _{DC}	600
Input voltage range	V _{DC}	300 - 882
DC link voltage (continuous input voltage)	V _{DC}	430 to 800 300 - 430 < 1 min 800 - 853 < 1 min 853 - 882 < 10 s
Supply current (at 600 V)	A _{DC}	1.1
Overvoltage trip	V _{DC}	> 882
Undervoltage trip	V _{DC}	280 ± 3 %
Output data		
Rated output voltage V _{A rated} :	V _{DC}	24 - 28.8 V
Rated output current I _{A rated} ¹⁾	A _{DC}	20
Rated output power P _{A rated}	W	520
Overcurrent limitation for short-circuit	A _{DC}	approx. 23
Surge suppression	V	< 35
Current carrying capacity of the 24 V busbar	A _{DC}	20
Residual ripple (clock frequency approx. 50 kHz)	mV _{pp}	< 100
Cycle peaks (bandwidth 20 MHz)	mV _{pp}	< 200
Power loss ride-through (at 400 V _{AC})	ms	5
Power loss ²⁾		
Line	W	70
DC link		65
Efficiency	%	>83
Cooling method		
		Internal air cooling
Max. ambient temperature		
Without derating	°C	≤40
With derating as of 26 V output voltage	°C	>40 to 55
Weight	kg	4.8

1) Upwards 40°C, a linear derating of the output current for 26 V output voltage and higher must be observed

2) For an overview, see the power loss tables in the chapter titled Control cabinet installation

8.3 Braking resistors

8.3.1 Description

A braking resistor is used to dissipate the excess DC link energy in generator operation. One braking resistor is connected to one Braking Module.

Resistors without thermostatic switch are available with various rated powers.

Mounting

The braking resistors can be mounted standing on the floor of the control cabinet or suspended. You must ensure that the braking resistors do not obstruct the flow of cooling air to the drive line-up.

Positioning the braking resistor outside the control cabinet or switchgear room enables the resulting thermal losses to be routed away. This reduces the level of air conditioning required.

Connection cables

A shielded connection cable (3 m, 3 x 1.5 mm²) is supplied with braking resistor 6SN1113-1AA00-0DA0.


Other braking resistors are supplied without connecting cable. The maximum conductor cross-sections are listed in the technical data.

The maximum cable length for all braking resistors is 10 m.

8.3.2 Safety information

 DANGER

The cables to the braking resistor must be installed in such a way that they are inherently short-circuit and ground-fault-proof.

 CAUTION
--

The braking resistor can become very hot. Consequently, it must be installed so that it cannot be touched or, if this is not possible, an appropriate warning notice must be attached to it.
--

CAUTION

The cooling clearances of 100 mm above and below the components must be observed.

8.3.3 Dimension drawings




Figure 8-11 Dimension drawing of braking resistor 0.3 kW/25 kW, all dimensions in mm and (inches)




Figure 8-12 Dimension drawing of braking resistor 1.5 kW/100 kW, all dimensions in mm and (inches)

8.3.4 Technical data

Table 8- 14 Technical data for braking resistors that have no thermostatic switch

	Unit	6SN1113-1AA00-0DA0	6SL3100-1BE31-0AAx
Rated power P_n	kW	0.3	1.5
Peak power P_{max}	kW	25	100
Max. energy consumption E_{max}	kWs	7.5	200
Power cable connection		Included in scope of delivery; length 3 m, 3 x 1.5 mm ²	Screw terminal, 4 mm ²
Weight	kg	3.4	5.6
Dimensions (W x H x D)	mm	80 x 210 x 53	193 x 410 x 240
Degree of protection according to EN 60529		IP54B	IP20

Duty cycle




Figure 8-13 Duty cycle for braking resistors

T [s] period duration of braking duty cycle

A [s] load duration

P_n [W] continuous braking power of braking resistor

P_{max} [W] peak power of braking resistor ($6 \times P_N$)

Table 8- 15 Duty cycles for Braking Module Booksize

	6SN1113-1AA00-0DA0		6SL3100-1BE31-0AAx	
	Short duty cycle	Long duty cycle	Short duty cycle	Long duty cycle
A [s]	0.1	0.4	1	2
T [s]	11.5	210	68	460

Electrically connecting Motor Modules and DC link components

9

9.1 Introduction

The S120 Combi offers the possibility of connecting the following expansion axes and DC link components to the DC link and the 24 V electronics power supply:

- Motor Modules Booksize Compact
- Braking Module
- Control Supply Module


For the S120 Combi, the DC link connection and the 24 V busbars are located at the front behind the front plate. Signal and power cables of the additional components must be connected corresponding to Chapter "Motor Modules Booksize Compact" and "DC link components". The specified cooling clearances of 80 mm for the S120 Combi also apply when operating the additional components.

9.2 Removing the front cover and opening the DC link cover on the S120 Combi

To electrically connect additional components, the front cover of the S120 Combi must be removed. The DC link busbars are located under the DC link cover.


Tool:

Torx T20 or slotted 1.2 x 6 screwdriver

 DANGER
Risk of electric shock A hazardous voltage is present for up to 5 minutes after the power supply has been switched off. The front cover may only be removed after this time has expired.

9.2 Removing the front cover and opening the DC link cover on the S120 Combi





9.3 Connection of DC link busbars and 24 V busbars

The following steps are necessary to connect a component to the DC link and the 24 V busbars of the S120 Combi:

1. Use a suitable tool to open the protective cover of the component to be connected
2. Remove the DC link side cover at the connection location






Figure 9-1 S120 Combi and Motor Module without DC link covers

3. Install the lower and upper DC link busbars

Install the lower DC link busbar	Install the upper DC link busbar
	
<ul style="list-style-type: none"> • Release the screws • Turn the DC link bridge • Observe the sequence when tightening the screws! 	<ul style="list-style-type: none"> • Release the screws • Remove the plastic cap on the DC link bridge • Turn the DC link bridge • Observe the sequence when tightening the screws!
Screwdriver	Torx T20 or slotted 1.2 x 6
Tightening torque	1.8 Nm

4. Installing the red 24 V connector (accessories pack of the component to be connected)




Figure 9-2 S120 Combi and Motor Module with installed 24 V connector

5. Close the protective cover of the connected component

6. Install the front cover on the S120 Combi

CAUTION

Before commissioning the drive line-up, it must be ensured, that:

- The outer DC link side cover is inserted at the connected component.
- The protective cover of the connected component is closed.
- The front cover of the S120 Combi is reinstalled.


CAUTION

After removing the additional components, before recommissioning the system, the touch protection of the DC link busbars on the S120 Combi power module must be reinstalled. The touch protection can be ordered as a spare part.

9.4 Connecting an additional component



An additional component is connected as follows to the DC link busbars and the 24 V busbars:

1. Use a suitable tool to open the protective cover of the component to be connected
2. Remove the DC link side covers of both components at the connection location



3. Prepared Motor Modules to connect the DC link busbars

4. Install the lower and upper DC link busbars

Install the lower DC link busbar	Install the upper DC link busbar
	
<ul style="list-style-type: none"> • Release the screws • Turn the DC link bridge • Observe the sequence when tightening the screws 	<ul style="list-style-type: none"> • Release the screws • Turn the DC link bridge • Observe the sequence when tightening the screws
Screwdriver	Torx T20 or slotted 1.2 x 6
Tightening torque	1.8 Nm

5. Installing the red 24 V connector (accessories pack of the component to be connected)




Figure 9-3 Motor Modules with 24 V connector installed

6. Close the protective covers of both components

CAUTION
<p>Before commissioning the drive line-up, it must be ensured, that:</p> <ul style="list-style-type: none"> • The DC link side cover is inserted at the outer component (touch protection). • The protective covers of all of the components are closed.

Additional system components

10.1 Terminal Module TM54F

10.1.1 Description

The Terminal Module TM54F is a terminal expansion for snapping on to an EN 60715 DIN rail. The TM54F offers safe digital inputs and outputs for controlling SINAMICS Safety Integrated functions.

The TM54F must be directly connected to the PPU of SINUMERIK 828D via DRIVE-CLiQ. In so doing, the topology rules must be observed.

TM54F features the following interfaces:

Table 10- 1 Interface overview of the TM54F

Type	Number
Fail-safe digital outputs (F-DO)	4
Fail-safe digital inputs (F-DI)	10
Sensor ¹⁾ power supplies, dynamization supported ²⁾	2
Sensor ¹⁾ power supply, no dynamization	1
Digital inputs to check F_DO for a test stop	4

1) Sensors: Fail-safe devices to issue commands and sense - for example, emergency stop buttons and safety locks, position switches and light arrays/light curtains.

2) Dynamization: The sensor power supply is cycled on and off by the TM54F when the forced checking procedure is active for the sensors, cable routing, and the evaluation electronics.

The TM54F has 4 fail-safe digital outputs and 10 fail-safe digital inputs. A fail-safe digital output consists of a 24 V switching output, a ground switching output, and a digital input for checking the switching state. A fail-safe digital input comprises two digital inputs.

Note


The rated values of the F-DO meet the requirements of EN 61131-2 for digital DC outputs with 0.5 A rated current.

The operating ranges of the F-DI meet the requirements of EN 61131-2 for Type 1 digital inputs.

Note

Please note that the F-DIs must take the form of shielded cables if they are > 30 m in length.

10.1.2 Safety information

 WARNING
The ventilation spaces of 50 mm above and below the component must be observed.

10.1.3 Interface description

10.1.3.1 Overview





Figure 10-1 TM54 interface overview

10.1.3.2 X500/X501 DRIVE-CLiQ interfaces

Table 10-2 X500/X501 DRIVE-CLiQ interfaces


	Pin	Signal name	Technical specifications
	1	TXP	Transmit data +
	2	TXN	Transmit data -
	3	RXP	Receive data +
	4	Reserved, do not use	
	5	Reserved, do not use	
	6	RXN	Receive data -
	7	Reserved, do not use	
	8	Reserved, do not use	
	A	+ (24 V)	Power supply
	B	M (0 V)	Electronics ground

The blanking covers for the DRIVE-CLiQ interfaces are included in the scope of delivery.

Blanking covers (50 pieces) order number: 6SL3066-4CA00-0AA0

10.1.3.3 X514 power supply for digital outputs and sensors

Table 10- 3 Terminals for the power supply X514

	Terminal	Designation	Technical specifications
	+	Power supply	Voltage: 24 V DC (20.4 V – 28.8 V) Current consumption: max. 4 A ¹⁾ Max. current via jumper in connector: 20 A
	+	Power supply	
	M1	Electronics ground	
	M1	Electronics ground	
Max. connectable cross-section: 2.5 mm ² Type: Screw terminal 3 (see the chapter titled "Control cabinet installation and EMC/Connection system")			


Note

The two "+" and "M1" terminals are jumpered in the connector. This ensures that the supply voltage is looped through.

¹⁾ including the current consumption for the digital outputs and to supply the sensor.

10.1.3.4 X520 sensor power supply


Table 10- 4 X520 sensor power supply

	Terminal	Designation	Technical specifications
	1	L3	Voltage: +24 V DC Max. total load current: 500 mA,
	2	M1	

Without forced dormant error detection

10.1.3.5 X521 fail-safe digital inputs + power supply with forced dormant error detection

Table 10- 5 Terminal block X521

	Terminal	Designation ¹⁾		Technical specifications
	1	L1+		Voltage: +24 V DC Max. total load current: 500 mA
	2	DI 0	F-DI 0	Voltage: -3 V to +30 V DC Typical current consumption: 3.2 mA at 24 V Electrical isolation: Reference potential, refer to terminals 6, 7, 8 All digital inputs are electrically isolated. Level (incl. ripple) High level: 15 V to 30 V Low level: -3 V to +5 V Input delay: ²⁾ For "0" → "1": 30 μs (100 Hz) For "1" to "0": 60 μs (100 Hz)
	3	DI 1+		
	4	DI 2	F-DI 1	
	5	DI 3+		
	6	DI 1-	F-DI 0	Reference potential for DI 1+
	7	DI 3-	F-DI 1	Reference potential for DI 3+
	8	M1	Reference potential for DI 0, DI 2, L1+	
An F-DI comprises a digital input and a 2nd digital input where, in addition, the cathode of the optocoupler is fed-out. F-DI 0 = terminals 2, 3 and 6 F-DI 1 = terminals 4, 5 and 7				
Max. connectable cross-section: 1.5 mm ² Type: Screw terminal 1 (see "Control cabinet installation and EMC/Connection system")				

1) DI: Digital input, F-DI: Fail-safe digital input

2) Pure hardware delay

NOTICE


For the digital inputs DIx+ to function, the reference potential must be connected to input DIx in each case.

This is achieved by:

- 1) Routing the ground reference of the digital inputs as well, or
- 2) A jumper between DIx and terminal M1.

10.1.3.6 X522 fail-safe digital inputs

Table 10- 6 Terminal block X522

	Terminal	Designation 1)		Technical specifications	
	1	DI 4	F-DI 2	Voltage: -3 V to +30 V DC Typical current consumption: 3.2 mA at 24 V Electrical isolation: Reference potential, refer to terminals 7, 8, 9, 10 All digital inputs are electrically isolated. Level (incl. ripple) High level: 15 V to 30 V Low level: -3 V to +5 V Input delay: 2) For "0" → "1": 30 μs (100 Hz) For "1" to "0": 60 μs (100 Hz)	
	2	DI 5+			
	3	DI 6	F-DI 3		
	4	DI 7+			
	5	DI 8	F-DI 4		
	6	DI 9+			
	7	DI 5-	F-DI 2		Reference potential for DI 5+
	8	DI 7-	F-DI 3		Reference potential for DI 7+
	9	DI 9-	F-DI 4		Reference potential for DI 9+
	10	M1	Reference potential for DI 4, DI 6 and DI 8		
An F-DI comprises a digital input and a 2nd digital input where, in addition, the cathode of the optocoupler is fed-out. F-DI 2 = terminals 1, 2 and 7 F-DI 3 = terminals 3, 4 and 8 F-DI 4 = terminals 5, 6 and 9					
Max. connectable cross-section: 1.5 mm ² Type: Screw terminal 1 (see "Control cabinet installation and EMC/Connection system")					

1) DI: Digital input, F-DI: Fail-safe digital input

2) Pure hardware delay

NOTICE


For the digital inputs DIx+ to function, the reference potential must be connected to input DIx in each case.

This is achieved by:

- 1) Routing the ground reference of the digital inputs as well, or
- 2) A jumper between DIx and terminal M1.

10.1.3.7 X523 fail-safe digital output

Table 10- 7 Terminal block X523


	Terminal	Designation ¹⁾	Technical specifications	
	1	DI 20	F-DO 0 Voltage: -3 V to +30 V DC Typical current consumption: 3.2 mA at 24 V Electrical isolation: Reference potential is terminal M1 The digital input is electrically isolated. Level (incl. ripple) High level: 15 V to 30 V Low level: -3 V to +5 V Input delay: ²⁾ For "0" → "1": 30 μs (100 Hz) For "1" to "0": 60 μs (100 Hz)	
	2	DO 0+		0.5 A Reference potential is terminal M1 0.5 A Reference potential is terminal L1+, L2+ or L3+ Output delay: ²⁾ For "0" → "1": 300 μs For "1" → "0": 350 μs Total current consumption of all DOs: 2 A Max. leakage current: < 0.5 mA Switching frequency: For resistive load: Max. 100 Hz For inductive load: Max. 0.5 Hz For lamp load: Max. 10 Hz Maximum lamp load: 5 W
	3	DO 0-		
An F-DO comprises two digital outputs and a digital input for the feedback signal F-DO 0 = terminals 1, 2 and 3 Max. connectable cross-section: 1.5 mm ² Type: Screw terminal 1 (see "Control cabinet installation and EMC/Connection system")				

1) DI: digital input; DO: digital output F-DO: Fail-safe digital output

2) Pure hardware delay

10.1.3.8 X524 Electronics power supply

Table 10- 8 Terminals for the electronics power supply

	Terminal	Designation	Technical specifications
	+	Electronics power supply	Voltage: 24 V DC (20.4 V – 28.8 V) Current consumption: Max. 0.7 A Max. current via jumper in connector: 20 A
	+	Electronics power supply	
	M	Electronics ground	
	M	Electronics ground	
Max. connectable cross-section: 2.5 mm ² Type: Screw terminal 3 (see "Control cabinet installation and EMC/Connection system")			


Note

The two "+" and "M" terminals are jumpered in the connector. This ensures that the supply voltage is looped through.

The current consumption increases by the value for the DRIVE-CLiQ node.

10.1.3.9 X525 fail-safe digital output

Table 10-9 Terminal block X525


	Terminal	Designation ¹⁾	Technical specifications	
	1	DI 21	F-DO 1 Voltage: -3 V to +30 V DC Typical current consumption: 3.2 mA at 24 V Electrical isolation: Reference potential is terminal M1 The digital input is electrically isolated. Level (incl. ripple) High level: 15 V to 30 V Low level: -3 V to +5 V Input delay: ²⁾ For "0" → "1": 30 μs (100 Hz) For "1" to "0": 60 μs (100 Hz)	
	2	DO 1+		0.5 A Reference potential is terminal M1 0.5 A Reference potential is terminal L1+, L2+ or L3+ Output delay: ²⁾ For "0" → "1": 300 μs For "1" → "0": 350 μs Total current consumption of all DOs: 2 A Max. leakage current: < 0.5 mA Switching frequency: For resistive load: Max. 100 Hz For inductive load: Max. 0.5 Hz For lamp load: Max. 10 Hz Maximum lamp load: 5 W
	3	DO 1-		
An F-DO comprises two digital outputs and a digital input for the feedback signal F-DO 1 = terminals 1, 2 and 3 Max. connectable cross-section: 1.5 mm ² Type: Screw terminal 1 (see "Control cabinet installation and EMC/Connection system")				

1) DI: digital input; DO: digital output F-DO: Fail-safe digital output

2) Pure hardware delay

10.1.3.10 X531 fail-safe digital inputs + power supply with forced dormant error detection

Table 10- 10 Terminal block X531

	Terminal	Designation ¹⁾		Technical specifications	
	1	L 2+		Voltage: 24 V DC Max. total load current: 500 mA	
	2	DI 10	F-DI 5	Voltage: -3 V to +30 V DC Typical current consumption: 3.2 mA at 24 V Electrical isolation: Reference potential, refer to terminals 6, 7, 8 All digital inputs are electrically isolated. Level (incl. ripple) High level: 15 V to 30 V Low level: -3 V to +5 V Input delay: ²⁾ For "0" → "1": 30 μs (100 Hz) - For "1" to "0": 60 μs (100 Hz)	
	3	DI 11+			
	4	DI 12	F-DI 6		
	5	DI 13+			
	6	DI 11-	F-DI 5		Reference potential to DI 11+
	7	DI 13-	F-DI 6		Reference potential to DI 13+
	8	M1	Reference potential to DI 10, DI 12, L2+		
An F-DI comprises a digital input and a 2nd digital input where, in addition, the cathode of the optocoupler is fed-out. F-DI 5 = terminals 2, 3 and 6 F-DI 6 = terminals 4, 5 and 7					
Max. connectable cross-section: 1.5 mm ² Type: Screw terminal 1 (see "Control cabinet installation and EMC/Connection system")					

1) DI: Digital input, F-DI: Fail-safe digital input

2) Pure hardware delay

NOTICE


For the digital inputs DIx+ to function, the reference potential must be connected to input DIx in each case.

This is achieved by:

- 1) Routing the ground reference of the digital inputs as well, or
- 2) A jumper between DIx and terminal M1.

10.1.3.11 X532 fail-safe digital inputs

Table 10- 11 Terminal block X532

	Terminal	Designation ¹⁾		Technical specifications	
	1	DI 14	F-DI 7	Voltage: -3 V to +30 V DC Typical current consumption: 3.2 mA at 24 V Electrical isolation: Reference potential, refer to terminals 7, 8, 9, 10 All digital inputs are electrically isolated. Level (incl. ripple) High level: 15 V to 30 V Low level: -3 V to +5 V Input delay: ²⁾ For "0" → "1": 30 μs (100 Hz) For "1" to "0": 60 μs (100 Hz)	
	2	DI 15+			
	3	DI 16	F-DI 8		
	4	DI 17+			
	5	DI 18	F-DI 9		
	6	DI 19+			
	7	DI 15-	F-DI 7		Reference potential for DI 15+
	8	DI 17-	F-DI 8		Reference potential for DI 17+
	9	DI 19-	F-DI 9		Reference potential for DI 19+
	10	M1			Reference potential for DI 14, DI 16 and DI 18
An F-DI comprises a digital input and a 2nd digital input where, in addition, the cathode of the optocoupler is fed-out. F-DI 7 = terminals 1, 2 and 7 F-DI 8 = terminals 3, 4 and 8 F-DI 9 = terminals 5, 6 and 9					
Max. connectable cross-section: 1.5 mm ² Type: Screw terminal 1 (see "Control cabinet installation and EMC/Connection system")					

1) DI: Digital input, F-DI: Fail-safe digital input

2) Pure hardware delay

NOTICE


For the digital inputs DIx+ to function, the reference potential must be connected to input DIx in each case.

This is achieved by:

- 1) Routing the ground reference of the digital inputs as well, or
- 2) A jumper between DIx and terminal M1.

10.1.3.12 X533 fail-safe digital output

Table 10- 12 Terminal block X533


	Terminal	Designation ¹⁾	Technical specifications	
	1	DI 22	F-DO 2 Voltage: -3 V to +30 V DC Typical current consumption: 3.2 mA at 24 V Electrical isolation: Reference potential is terminal M1 The digital input is electrically isolated. Level (incl. ripple) High level: 15 V to 30 V Low level: -3 V to +5 V Input delay: ²⁾ For "0" → "1": 30 μs (100 Hz) For "1" to "0": 60 μs (100 Hz)	
	2	DO 2+		0.5 A Reference potential is terminal M1 0.5 A Reference potential is terminal L1+, L2+ or L3+ Output delay: ²⁾ For "0" → "1": 300 μs For "1" → "0": 350 μs Total current consumption of all DOs: 2 A Max. leakage current: < 0.5 mA Switching frequency: For resistive load: Max. 100 Hz For inductive load: Max. 0.5 Hz For lamp load: Max. 10 Hz Maximum lamp load: 5 W
	3	DO 2-		
An F-DO comprises two digital outputs and a digital input for the feedback signal F-DO 2 = terminals 1, 2 and 3 Max. connectable cross-section: 1.5 mm ² Type: Screw terminal 1 (see "Control cabinet installation and EMC/Connection system")				

1) DI: digital input; DO: digital output F-DO: Fail-safe digital output

2) Pure hardware delay

10.1.3.13 X535 fail-safe digital output

Table 10- 13 Terminal block X535

	Terminal	Designation ¹⁾	Technical specifications	
	1	DI 23	F-DO 3 Voltage: -3 V to +30 V DC Typical current consumption: 3.2 mA at 24 V Electrical isolation: Reference potential is terminal M1 The digital input is electrically isolated. Level (incl. ripple) High level: 15 V to 30 V Low level: -3 V to +5 V Input delay: ²⁾ For "0" → "1": 30 μs (100 Hz) For "1" to "0": 60 μs (100 Hz)	
	2	DO 3+		0.5 A Reference potential is terminal M1 0.5 A Reference potential is terminal L1+, L2+ or L3+ Output delay: ²⁾ For "0" → "1": 300 μs For "1" → "0": 350 μs Total current consumption of all DOs: 2 A Max. leakage current: < 0.5 mA Switching frequency: For resistive load: Max. 100 Hz For inductive load: Max. 0.5 Hz For lamp load: Max. 10 Hz Maximum lamp load: 5 W
	3	DO 3-		
An F-DO comprises two digital outputs and a digital input for the feedback signal F-DO 3 = terminals 1, 2 and 3 Max. connectable cross-section: 1.5 mm ² Type: Screw terminal 1 (see "Control cabinet installation and EMC/Connection system")				

1) DI: digital input; DO: digital output F-DO: Fail-safe digital output

2) Pure hardware delay

10.1.4 Connection example




Figure 10-2 Connection example off TM54F

10.1.5 Meaning of LEDs

Table 10- 14 Meaning of the LEDs on the Terminal Module TM54F

LED	Color	Status	Description, cause	Remedy	
READY	-	Off	Electronics power supply is missing or outside the permissible tolerance range.	-	
	Green	Continuous light	The component is ready for operation and cyclic DRIVE-CLiQ communication is taking place.	-	
	Orange	Continuous light	DRIVE-CLiQ communication is being established.	-	
	Red	Continuous light	At least one fault is present in this component. Note: The LED is activated irrespective of whether the corresponding messages have been reconfigured.	Remedy and acknowledge fault	
	Green/red	0.5 Hz flashing light	0.5 Hz flashing light	Firmware is being downloaded.	-
			2 Hz flashing light	Firmware download is complete. Wait for POWER ON	Carry out a POWER ON
	Green/orange or Red/orange	Flashing light	Component recognition via LED is activated (p0154). Note: Both options depend on the LED status when component recognition is activated via p0154 = 1.	-	
L1+, L2+,	-	ON	The controllable sensor power supply is functioning fault-free.	-	
	Red	Continuous light	There is a fault in the controllable sensor power supply.	-	
L3+	-	ON	Sensor power supply is functioning fault-free.		
	Red	Continuous light	There is a fault in the sensor power supply.		

LED	Color		Status	Description, cause	Remedy
Fail-safe inputs / double inputs					
F_DI z (input x, (x+1)+, (x+1)-)	LED x	LED x+1	Continuous light	NC contact / NC contact ¹⁾ : (z = 0..9, x = 0, 2, ..18) Different signal states at input x and x+1	-
	-	Red			
	-	Red	Continuous light	NC contact / NO contact ¹⁾ : (z = 0..9, x = 0, 2, ..18) Same signal states at input x and x+1	
	-	-	-	No signal at input x and a signal at input x+1	
LED x	Green	Green	Continuous light	NC contact / NC contact ¹⁾ : (z = 0..9, x = 0, 2, ..18) A signal at input x and a signal at input x+1	-
	Green	Green	Continuous light	NC contact / NO contact ¹⁾ : (z = 0..9, x = 0, 2, ..18) A signal at input x and no signal at input x+1	
¹⁾ Inputs x+1 (DI 1+, 3+, .. 19+) can be set individually via parameter p10040 (TM54F). p10040 (TM54F) = 0: Input x+1 is an NC contact. p10040 (TM54F) = 1: Input x+1 is NO contact. Factory setting: p10040 (TM54F) = 0 for all inputs x+1.					
Single digital inputs, not fail-safe					
DI x	-		Off	No signal at digital input x (x = 20..23)	-
	Green		Continuous light	Signal at digital input x	-
Fail-safe digital outputs with associated readback channel					
F_DO y (0+..3+, 0-..3-)	Green		Continuous light	Output y (y=0 .. 3) carries a signal	-
Readback input DI 2y for output F_DO y (y = 0..3) at test stop. The status of the LEDs also depends on the type of external circuit.					
DI 2y	-		Off	One of the two output lines y+ or y- or both lines of output y carry a signal	-
	Green		Continuous light	Both output lines y+ and y- carry no signal	-

Cause and rectification of faults

The following reference contains information about the cause of faults and how they can be rectified:

SINAMICS S120 Combi List Manual

10.1.6 Dimension drawing




Figure 10-3 Dimension drawing of Terminal Module TM54F, all data in mm and (inches)


10.1.7 Installation

Installation

1. Slightly tilt the component backwards and attach it to the mounting rail using the hook.
2. Swivel the component on the mounting rail until the mounting slide at the rear audibly latches
3. Shift the components on the mounting rail to the left or right until they reach their final position

Removal

1. First shift the mounting slide downwards at the lug to release the interlocking with the mounting rail
2. Swivel the component towards the front and then remove it upwards from the mounting rail




- ① Mounting slide
- ② Mounting rail

Figure 10-4 Removal of a component from a DIN rail

10.1.8 Protective conductor connection and shield support

It is always advisable to shield the digital input and output wiring.

The following diagram shows a typical Weidmüller shield connection clamp for the shield supports.



- ① Protective conductor connection M4/1.8 Nm
- ② Shield connection terminal, Weidmüller company, type: KLBÜ CO1, order number: 1753311001

Figure 10-5 Shield support and protective conductor connection

 DANGER

If the shielding procedures described and the permissible cable lengths are not observed, the machine may malfunction.
--

NOTICE

Only use screws with a permissible insertion depth of 4 - 6 mm.

10.1.9 Technical data

Table 10- 15 Technical data

6SL3055-0AA00-3BAx	Unit	Value
Current requirement (X524 at 24 V DC) without DRIVE-CLiQ supply	mA	160
Current requirement (X514 at 24 V DC) without digital outputs and sensor power supply	mA	38
Sensor power supply with and without forced dormant error detection (L1+, L2+, L3+)		
• Voltage	V	24
• Max. load current per output	A	0.5
- cable length for the 24 V power supply: - For longer cable lengths, the "Weidmüller Type No. PU DS 24 16A" surge protector must be used.	m	< 30
• Fail-safe digital inputs (F-DI) (with electrical isolation)		10
• Fail-safe digital outputs (F-DO) (with electrical isolation)		4
• Standard digital inputs (with electrical isolation)		4
Fail-safe digital inputs (F-DI) and standard digital inputs		
• Voltage	V	0 to 30
• Low-level (an open digital input is interpreted as "low")	V	-3 to +5
• High level		
• Current consumption (at 24 V DC)	V mA	15 to 30
• Input delay ¹⁾ - for "0" to "1"	µs	>2
- for "1" to "0"	µs	approx. 30 (100 Hz) approx. 60 (100 Hz)
Fail-safe digital outputs (F-DO), continuous short-circuit proof		
• Voltage	V	24
• Max. load current per digital output	A	0.5
• Output delay ¹⁾ - for "0" to "1"	µs	300
- for "1" to "0"	µs	350
Power loss	W	4.5 at 24 V
PE/ground connection		On enclosure with M4 screw
Weight	kg	approx. 0.9

¹⁾ Pure hardware delay

10.2 DRIVE-CLiQ Hub Module DMC20

10.2.1 Description


The DRIVE-CLiQ Hub Module DMC20 is a DRIVE-CLiQ component and can be snapped onto a standard mounting rail (EN 60715). It is only used to connect direct measuring systems for the feed axes and expansion axes of the S120 Combi.

Note

The DMC20 should also be used if only one feed axis is coupled with a direct measuring system.

A fixed topology applies when assigning the particular feed axis to a DRIVE-CLiQ interface (see Chapter "Topology rules for DRIVE-CLiQ") and this must be observed.

10.2.2 Safety information

 WARNING
The ventilation spaces of 50 mm above and below the component must be observed.

NOTICE
The unused DRIVE-CLiQ ports must be closed using a rubber plug that is included in the scope of delivery.

Note

All components operated on the DRIVE-CLiQ must be integrated into the equipotential bonding concept.
They should preferably be connected by installing them on bare machine parts and devices, which are all equipotentially bonded to one another.
Alternatively, equipotential bonding can be achieved by means of a conductor (min. 6 mm²), which should be routed parallel to the DRIVE-CLiQ where possible. This involves all distributed DRIVE-CLiQ participants.

10.2.3 Interface description

10.2.3.1 Overview





Figure 10-6 Interface overview of the DMC20

10.2.3.2 X524 Electronics power supply

Table 10- 16 Terminals for the electronics power supply

	Terminal	Designation	Technical specifications
	+	Electronics power supply	Voltage: 24 V DC (20.4 V – 28.8 V) Current consumption: Max. 0.5 A Max. current via jumper in connector: 20 A
	+	Electronics power supply	
	M	Electronics ground	
	M	Electronics ground	
Max. connectable cross-section: 2.5 mm ² Type: Screw terminal 3 (see Chapter "Control cabinet installation and EMC / connection system")			


Note

The two "+" and "M" terminals are jumpered in the connector. This ensures that the supply voltage is looped through.

The current consumption increases by the value for the DRIVE-CLiQ participants.

10.2.3.3 X500 - X505 DRIVE-CLiQ interfaces

Table 10- 17 X500-X505 DRIVE-CLiQ interfaces

	Pin	Signal name	Technical specifications
	1	TXP	Transmit data +
	2	TXN	Transmit data -
	3	RXP	Receive data +
	4	Reserved, do not use	
	5	Reserved, do not use	
	6	RXN	Receive data -
	7	Reserved, do not use	
	8	Reserved, do not use	
	A	+ (24 V)	Power supply
	B	M (0 V)	Electronics ground
Connector type	RJ45 socket		

The blanking covers for the DRIVE-CLiQ interfaces are included in the scope of delivery.

Blanking covers (50 pieces) Order number: 6SL3066-4CA00-0AA0

Note

Only MOTION-CONNECT DRIVE-CLiQ cables may be used to establish connections. The maximum length of MOTION-CONNECT 500 is 100 m and for MOTION-CONNECT 800PLUS cables, 75 m.

10.2.3.4 Meaning of the LED on the DMC20

Table 10- 18 Meaning of the LED on the DMC20

LED	Color	Status	Description
READY	-	Off	Electronics power supply is missing or outside permissible tolerance range.
	Green	Continuous light	The component is ready for operation and cyclic DRIVE-CLiQ communication is taking place.
	Orange	Continuous light	DRIVE-CLiQ communication is being established.
	Red	Continuous light	At least one fault is present in this component. Note: The LED is activated irrespective of whether the corresponding messages have been reconfigured.
	Green / Red	Flashing light 0.5 Hz	Firmware is being downloaded.
		Flashing 2 Hz	Firmware download is complete. Wait for POWER ON
	Green / Orange or Red / Orange	Flashing light	Component recognition via LED is activated (p0154). Note: Both options depend on the LED status when component recognition is activated via p0154 = 1.

Cause and rectification of faults

The following reference contains information about the cause of faults and how they can be rectified:

SINAMICS S120 Function Manual (FH1)

SINAMICS S120 Combi List Manual

10.2.4 Dimension drawing




Figure 10-7 Dimension drawing of the DRIVE-CLiQ Hub Module DMC20, all data in mm and (inches)


10.2.5 Installation

Installation

1. Tilt the component backwards slightly and attach it to the DIN rail using the hook.
2. Push the component towards the DIN rail until you hear the mounting slide at the rear latch into position.
3. You can now move the component to the left or right along the DIN rail, until it reaches its final position.

Removal

1. The lug on the mounting slide first needs to be pushed down to unlock the slide from the DIN rail.
2. The component can now be tilted forwards and pulled up and off the DIN rail.



- ① Mounting slide
- ② Mounting rail

Figure 10-8 Removal of a component from a DIN rail

10.2.6 Technical data

Table 10- 19 Technical data of the DMC20

6SL3055-0AA00-6AAx	Unit	Value
Electronics power supply		
Voltage	V _{DC}	24 DC (20.4 – 28.8)
Current (without DRIVE-CLiQ node)	A _{DC}	0.15
PE/ground connection	At the housing with M4/1.8 Nm screw	
Weight	kg	0.8

10.3 DRIVE-CLiQ Hub Module External DME20

10.3.1 Description

The DRIVE-CLiQ Hub Module External DME20, just like the DRIVE-CLiQ Hub Module DMC20, is only used to connect direct measuring systems for the feed axes and expansion axes of the S120 Combi.

The component has degree of protection IP67.

Note

The DME20 should also be used if only one feed axis is coupled with a direct measuring system.

A fixed topology applies when assigning the particular feed axis to a DRIVE-CLiQ interface (see Chapter "Topology rules for DRIVE-CLiQ") and this must be observed.

10.3.2 Safety information

NOTICE

In order to guarantee degree of protection IP67, all of the plug connectors must be correctly screwed into place and appropriately locked.
--

NOTICE

The unused DRIVE-CLiQ ports must be closed using a blanking cover that is included in the scope of delivery.
--

Note

All components operated on the DRIVE-CLiQ must be integrated into the equipotential bonding concept.

They should preferably be connected by installing them on bare metal parts of electrically interconnected machines and systems.

Alternatively, equipotential bonding can be achieved with a conductor (min. 6 mm²) routed parallel to the DRIVE-CLiQ where possible. This applies to all distributed DRIVE-CLiQ participants.

For the DME20 this also applies to the 24 V power supply.

10.3.3 Interface description

10.3.3.1 Overview





Figure 10-9 Interface overview of the DME20

10.3.3.2 X524 Electronics power supply

Table 10- 20 X524 electronics power supply

	Pin	Designation	Technical specifications
	1	Electronics power supply	The connection voltage of 20.4 V – 28.8 V refers to the (terminal) voltage at the DME20. This must be taken into account when selecting the cable cross-section and supply cable lengths. Pins 1 and 2: jumpered internally Pins 3 and 4: jumpered internally
	2	Electronics power supply	
	3	Electronics ground	
	4	Electronics ground	
	5	not connected	
5-pin socket, max. connectable cross-section: 4 x 0.75 mm ²			

Note

The maximum cable length for the P24 supply of the DME20 is 100 m.

In case no UL-compliant design is required, is the use of the following cables and connectors from Siemens is recommended:

Pre-assembled cables

Connecting cable for power supply with M12 plug and M12 socket, A-coded, 4-pin, order number: 6XV1801-5D..

Cables to be assembled by the user

Cable	Connector
24 V DC cable, 2-wire, 2 x 0.75 mm ² , order number: 6XV1812-8A	M12 plug connector, 4-pin, A-coded, order number: 6GK1907-0DC10-6AA3


Table 10- 21 Cable length P24 supply cable

connected loads ¹⁾	1	2	3	4	5
Cross section					
0.34 mm ²	75 m	45 m	30 m	25 m	20 m
2 x 0.34 mm ²	100 m	90 m	65 m	50 m	40 m
0.75 mm ²	100 m	100 m	75 m	60 m	50 m
2 x 0.75 mm ²	100 m	100 m	100 m	100 m	100 m
T _a = 55 °C 100 m DRIVE-CLiQ					

1) Connected motors with DRIVE-CLiQ encoder, DRIVE CLiQ mounted encoder SME

10.3.3.3 X500-X505 DRIVE-CLiQ interfaces

Table 10- 22 X500-X505 DRIVE-CLiQ interfaces

	Pin	Signal name	Technical specifications
	1	TXP	Transmit data +
	2	TXN	Transmit data -
	3	RXP	Receive data +
	4	Reserved, do not use	
	5	Reserved, do not use	
	6	RXN	Receive data -
	7	Reserved, do not use	
	8	Reserved, do not use	
	A	+ (24 V)	Power supply
	B	M (0 V)	Electronics ground
Connector type	RJ45 socket		

The blanking covers for the DRIVE-CLiQ interfaces are included in the scope of delivery.

Blanking covers (50 pieces) Order number: 6SL3066-4CA00-0AA0

Note

Only MOTION-CONNECT DRIVE-CLiQ cables may be used to establish connections. The maximum length of MOTION-CONNECT 500 is 100 m and for MOTION-CONNECT 800PLUS cables, 75 m.

10.3.4 Dimension drawing





Figure 10-10 Dimension drawing of the DRIVE-CLiQ Hub Module External DME20, all data in mm and (inches)

10.3.5 Installation



① Contact surface

Figure 10-11 Mounting dimensions DME20

Installation

1. Transfer the drilling pattern to the contact surface - the contact surfaces must be bare unpainted metal.
2. Holes $\varnothing 5.3$ or threads M5
3. Tighten with a tightening torque of 6.0 Nm.

10.3.6 Technical data

Table 10- 23 Technical data of the DME20

6SL3055-0AA00-6ABx	Unit	Value
Electronics power supply		
Voltage	V_{DC}	24 DC (20.4 – 28.8)
Current (without DRIVE-CLiQ node)	A_{DC}	0,15
PE/ground connection	Fastened to housing M5 / 6 Nm	
Degree of protection	IP67	
Weight	kg	0,8

10.3.7 Specifications for use with UL approval

Pre-assembled cables

Sensor/actuator cable, 5-pin, variable cable,
 free cable end at straight socket M12-SPEEDCON,
 cable length: 2, 5, 10, 15 m
 SAC-5P-xxx-186/FS SCO
 Up to 100 m on request

Phoenix Contact

Cables to be assembled by the user

Cable	Connector
Cable coil, black PUR/PVC, 5-pin Conductor colors: brown/white/blue/black/gray Cable length: 100 m SAC-5P-100.0-186/0.75 Order number: 1535590	Sensor/actuator connector, socket, straight, 5-pin, M12, A-coded Screw connection, metal knurl, cable gland Pg9 SACC-M12FS-5CON-PG9-M Order number: 1681486
Phoenix Contact	

Power supply

The DME20 must be connected to a 24 V power supply with voltage limitation.

- SITOP 6EP1x.. or 6ES7307..
- SINAMICS Control Supply Module 6SL3100-1DE22-0Axx

Pin assignment of the cable

Table 10- 24 Connection to X524 electronics power supply

	Pin	Designation	Technical specifications
	1 (brown) ¹⁾	Electronics power supply	The connection voltage of 20.4 V – 28.8 V refers to the (terminal) voltage at the DME20. This must be taken into account when selecting the cable cross-section and supply cable lengths. Pins 1 and 2: jumpered internally Pins 3 and 4: jumpered internally
	2 (white) ¹⁾	Electronics power supply	
	3 (black) ¹⁾	Electronics ground	
	4 (blue) ¹⁾	Electronics ground	
	5 (gray) ¹⁾	Not connected internally	

1) The colors stated refer to the cable specified above

Encoder system connection

11.1 Sensor Module Cabinet-Mounted SMC20

11.1.1 Description

The Sensor Module Cabinet-Mounted SMC20 evaluates encoder signals and transmits the speed, actual position value, rotor position and, if necessary, the motor temperature and reference point via DRIVE-CLiQ to the S120 Combi.

The SMC20 is used to evaluate encoder signals from incremental encoders with SIN/COS (1 Vpp) or absolute encoders with EnDat 2.1 or SSI.

11.1.2 Safety information

 WARNING
--


The ventilation spaces of 50 mm above and below the component must be observed.

NOTICE

Only one encoder system may be connected per Sensor Module.

Note

There must be no electrical connection between the encoder system housing and the signal cables, or the encoder system electronics. If this is not carefully observed, under certain circumstances the system will not be able to reach the required interference immunity level (there is then a danger of equalization currents flowing through the electronics ground).

 CAUTION
--

Connecting cables to temperature sensors must always be installed with shielding. The cable shield must be connected to the ground potential at both ends over a large surface area. Temperature sensor cables that are routed together with the motor cable must be twisted in pairs and shielded separately.
--

11.1.3 Interface description

11.1.3.1 Overview





Figure 11-1 Interface description of the SMC20

11.1.3.2 X500 DRIVE-CLiQ interface

Table 11- 1 X500 DRIVE-CLiQ interface


	Pin	Signal name	Technical specifications
	1	TXP	Transmit data +
	2	TXN	Transmit data -
	3	RXP	Receive data +
	4	Reserved, do not use	
	5	Reserved, do not use	
	6	RXN	Receive data -
	7	Reserved, do not use	
	8	Reserved, do not use	
	A	Reserved, do not use	
	B	M (0 V)	Electronics ground
Connector type	RJ45 socket		

The blanking cover for the DRIVE-CLiQ port is included in the scope of delivery.

Blanking covers (50 pieces) Order number: 6SL3066-4CA00-0AA0


11.1.3.3 X520 encoder system interface

Table 11- 2 X520 encoder system interface

	Pin	Signal name	Technical specifications
	1	P encoder	Encoder power supply
	2	M encoder	Ground for encoder power supply
	3	A	Incremental signal A
	4	A*	Inverse incremental signal A
	5	Ground	Ground (for internal shield)
	6	B	Incremental signal B
	7	B*	Inverse incremental signal B
	8	Ground	Ground (for internal shield)
	9	Reserved, do not use	
	10	Clock	Clock, EnDat interface, SSI clock
	11	Reserved, do not use	
	12	Clock*	Inverted clock, EnDat interface, inverted SSI clock
	13	+Temp	Motor temperature measurement KTY84-1C130 (KTY+) Temperature sensor KTY84-1C130 / PTC
	14	P sense	Sense input encoder power supply
	15	Data	Data, EnDat interface, SSI data
	16	M sense	Ground sense input encoder power supply
	17	R	Reference signal R
	18	R*	Inverse reference signal R
	19	C	Absolute track signal C
	20	C*	Inverse absolute track signal C
	21	D	Absolute track signal D
	22	D*	Inverse absolute track signal D
	23	Data*	Inverse data, EnDat interface, Inverse SSI data
	24	Ground	Ground (for internal shield)
	25	-Temp	Motor temperature measurement KTY84-1C130 (KTY-) Temperature sensor KTY84-1C130 / PTC
Connector type:	25-pin SUB D connector		
Measuring current via temperature sensor connection: 2 mA			


NOTICE

The KTY temperature sensor must be connected with the correct polarity
If the sensor is connected with the incorrect polarity, it cannot detect if a motor overheats.

 DANGER
Risk of electric shock!
Only temperature sensors that meet the safety isolation specifications contained in EN 61800-5-1 may be connected to terminals "+Temp" and "-Temp".
If these instructions are not complied with, there is a risk of electric shock!

11.1.3.4 X524 Electronics power supply

Table 11- 3 X524 terminal strip

	Terminal	Function	Technical specifications
	+	Electronics power supply	Voltage: 24 V (20.4 V – 28.8 V) Current consumption: Max. 0.35 A Maximum current via jumper in connector: 20 A
	+	Electronics power supply	
	M	Electronics ground	
	M	Electronics ground	
Max. connectable cross-section: 2.5 mm ² Type: Screw terminal 3 (see Chapter "Control cabinet installation and EMC / connection system")			

Note

The two "+" and "M" terminals are jumpered in the connector. This ensures that the supply voltage is looped through.

11.1.3.5 Meaning of LEDs on the Sensor Module Cabinet-Mounted SMC20

Table 11- 4 Meaning of LEDs on the Sensor Module Cabinet-Mounted SMC20

LED	Color	Status	Description, cause	Remedy
RDY READY	-	Off	Electronics power supply is missing or outside the permissible tolerance range.	-
	Green	Continuous light	The component is ready for operation and cyclic DRIVE-CLiQ communication is taking place.	-
	Orange	Continuous light	DRIVE-CLiQ communication is being established.	-
	Red	Continuous light	At least one fault is present in this component. Note: The LED is activated regardless of whether the corresponding messages have been reconfigured.	Remedy and acknowledge fault
	Green/red	0.5 Hz flashing light	Firmware is being downloaded.	-
		2 Hz flashing light	Firmware download is complete. Wait for POWER ON	Carry out a POWER ON
	Green/ orange or Red/ orange	Flashing light	Component recognition via LED is activated (p0144). Note: Both options depend on the LED status when component recognition is activated via p0144 = 1.	-

Cause and rectification of faults

Further information about the causes of faults and how to remedy them may be found in the manual: SINAMICS S120 Commissioning Manual.

11.1.4 Dimension drawing




Figure 11-2 Dimension drawing of the Sensor Module Cabinet SMC20, all data in mm and (inches)


11.1.5 Installation

Installation

1. Slightly tilt the component backwards and attach it to the mounting rail using the hook.
2. Swivel the component on the mounting rail until the mounting slide at the rear audibly latches
3. Shift the components on the mounting rail to the left or right until they reach their final position

Removal

1. First shift the mounting slide downwards at the lug to release the interlocking with the mounting rail
2. Swivel the component towards the front and then remove it upwards from the mounting rail



- ① Mounting slide
- ② Mounting rail

Figure 11-3 Removal of a component from a DIN rail

11.1.6 Technical data

Table 11- 5 Technical data

6SL3055-0AA00-5BAx	Unit	Value
Electronics power supply		
Voltage	V_{DC}	24 DC (20.4 – 28.8)
Current (without encoder system)	A_{DC}	≤ 0.20
Current (with encoder system)	A_{DC}	≤ 0.35
Power loss	W	≤ 10
Encoder system power supply		
Voltage	$V_{encoder}$	5 V DC (with Remote Sense) ¹⁾
Current	$A_{encoder}$	0.35
Encoder frequency that can be evaluated ($f_{encoder}$)	kHz	≤ 500
SSI baud rate ²⁾	kHz	100 - 250
Max. encoder cable length	m	100
PE/ground connection		At the housing with M4/1.8 Nm screw
Weight	kg	0.45
Degree of protection		IP20 or IPXXB

1) A controller compares the encoder system supply voltage - sensed via the Remote Sense cables - with the reference supply voltage of the encoder system, and adjusts the supply voltage for the encoder system at the output of the sensor module until the required supply voltage is obtained directly at the encoder system (only for 5 V encoder system power supply).

2) Only possible for SSI encoders with 5 V supply

Note

Current controller clock cycle

For a current controller clock cycle of 31.25 μ s, an SMC20 with order number 6SL3055-0AA00-5BA3 must be used.

11.2 Sensor Module External SME20

11.2.1 Description

Direct encoder systems outside the cabinet can be connected to the Sensor Module External SME20. The SME20 evaluates these encoder systems and converts the calculated values to DRIVE-CLiQ.

Incremental direct encoder systems with SIN/COS (1 Vpp) and reference signal can be connected.

It is possible to connect a motor with a 17-pole circular connector for the encoder to the 12-pole circular connector of the SME20 using adapter cable 6FX 8002-2CA88-xxxx.

- KTY/PTC temperature sensors can be used for evaluation of the motor temperature.
- The Sensor Module is only suitable for motors without absolute track signals (C/D track):
 - Induction motors (e.g. 1PH)
 - Synchronous motors with pole position identification (e.g. 1FN, 1FW, 1FE)

Neither motor nor encoder data are saved in the SME20.

11.2.2 Safety Information

CAUTION
Connecting cables to temperature sensors must always be installed with shielding. The cable shield must be connected to the chassis potential at both ends over a large surface area. Temperature sensor cables that are routed together with the motor cable must be twisted in pairs and shielded separately.

11.2.3 Interface description

11.2.3.1 Overview




Figure 11-4 Interface description SME20

11.2.3.2 Connection example





Figure 11-5 Connection of a direct encoder system via a Sensor Module External (SME)

11.2.3.3 DRIVE-CLiQ interface

Table 11- 6 DRIVE-CLiQ interface

	Pin	Signal name	Technical specifications
	1	TXP	Transmit data +
	2	TXN	Transmit data -
	3	RXP	Receive data +
	4	Reserved, do not use	
	5	Reserved, do not use	
	6	RXN	Receive data -
	7	Reserved, do not use	
	8	Reserved, do not use	
	A	+ (24 V)	Power supply
	B	M (0 V)	Electronics ground
	Connector type	RJ45 socket	
Current consumption	max. 0.25 A		

The blanking cover for the DRIVE-CLiQ port is included in the scope of delivery.


Blanking covers (50 pieces) Order number: 6SL3066-4CA00-0AA0

Note

Only MOTION-CONNECT DRIVE-CLiQ cables may be used for connections. The maximum cable length is 100 m for MOTION-CONNECT 500, and 75 m for MOTION-CONNECT 800PLUS cables.


11.2.3.4 Encoder system interface

Table 11- 7 Encoder system interface SME20

	Pin	Signal name	Technical specifications
	1	B*	Inverse incremental signal B
	2	P5	Encoder power supply
	3	R	Reference signal R
	4	R*	Inverse reference signal R
	5	A	Incremental signal A
	6	A*	Inverse incremental signal A
	7	-Temp ¹⁾	Temperature sensor connection ²⁾ KTY84-1C130 or PTC
	8	B	Incremental signal B
	9	+Temp ¹⁾	Temperature sensor connection ²⁾ KTY84-1C130 or PTC
	10	M	Ground for encoder power supply
	11	M	Ground for encoder power supply
	12	P5	Encoder power supply
Connector kit:	12-pin, order number: 6FX2003-0SA12		
Measuring current via temperature sensor connection: 2 mA Blanking cover for encoder system interface: Pöppelmann GmbH & Co. KG, Lohne, Order No.: GPN 300 F211			

- 1) These connections do not have protective separation!
 2) Connection cable: Order number 6FX8002-2CA88-xxxx

NOTICE
The KTY temperature sensor must be connected with the correct polarity. A sensor connected up with the incorrect polarity cannot detect if the motor overheats

 DANGER
Risk of electric shock!
Only temperature sensors that meet the safety isolation specifications contained in EN 61800-5-1 may be connected to terminals "+Temp" and "-Temp".
If these instructions are not complied with, there is a risk of electric shock!

11.2.4 Dimension drawing





Figure 11-6 Dimension drawing of Sensor Module External SME20, all data in mm and (inches), order number 6SL3055-0AA00-5EA3

11.2.5 Installation



① Contact surface

Figure 11-7 Drilling pattern for installing the SME20/SME25

Installation

1. Place the drilling pattern on the mounting surface. Make sure that the contact surface is bare, unpainted metal.
2. Drill two holes with $\varnothing 5.3$ or M5 threaded holes according to the drilling pattern.
3. Fix the Sensor Module to the mounting surface. The tightening torque is 6 Nm.

11.2.6 Technical data

Table 11- 8 Technical data

6SL3055-0AA00-5EA3	Unit	Value
Electronics power supply		
Voltage	V_{DC}	24 DC (20.4 – 28.8)
Current (without encoder system)	A_{DC}	≤ 0.15
Current (with encoder system)	A_{DC}	≤ 0.25
Power loss	W	≤ 4
Encoder system power supply		
Voltage	$V_{encoder}$	5 VDC
Current	$A_{encoder}$	0.35
Encoder frequency that can be evaluated ($f_{encoder}$)	kHz	≤ 500
PE/ground connection		On enclosure with M4/1.8 Nm screw
Weight	kg	0.31
Degree of protection		IP67

The maximum cable length at the encoder system interface depends on the current consumption of the encoder system and the cross-section of the supply cores in the cable. However, the maximum length is 10 m.

For encoder systems that operate in a supply voltage range from 4.75 V to 5.25 V, the following diagram is obtained. The sample parameters shown are 0.28 mm² cross-section (0.14 mm² supply cores plus 0.14 mm² Remote Sense cores) and 0.64 mm² (0.5 mm² supply cores plus 0.14 mm² Remote Sense cores).




Figure 11-8 Max. cable length as a function of the current drawn by the encoder system

In addition to the encoder systems for a supply voltage range of 4.75 V to 5.25 V in the figure above, encoder systems are also available for an extended range down to 3.6 V. These can be generally operated using encoder system cables up to 10 m long provided that the total cross-section of the supply core plus Remote Sense cores does not fall below 0.14 mm².

11.3 Sensor Module External SME25

11.3.1 Description

Direct encoder systems outside the cabinet can be connected to the Sensor Module External SME25. The SME25 evaluates these encoder systems and converts the calculated values to DRIVE-CLiQ.

Direct encoder systems with EnDat 2.1 or SSI with SIN/COS (1 Vpp) incremental signals can be connected, however without reference signal.

Neither motor nor encoder data are saved in the SME25.

11.3.2 Interface description

11.3.2.1 Overview




Figure 11-9 Interface description SME25

11.3.2.2 Connection example




Figure 11-10 Connection of a direct encoder system via a Sensor Module External (SME)

11.3.2.3 DRIVE-CLiQ interface

Table 11- 9 DRIVE-CLiQ interface

	Pin	Signal name	Technical specifications
	1	TXP	Transmit data +
	2	TXN	Transmit data -
	3	RXP	Receive data +
	4	Reserved, do not use	
	5	Reserved, do not use	
	6	RXN	Receive data -
	7	Reserved, do not use	
	8	Reserved, do not use	
	A	+ (24 V)	Power supply
	B	M (0 V)	Electronics ground
Connector type	RJ45 socket		
Current consumption	max. 0.25 A		

The blanking cover for the DRIVE-CLiQ port is included in the scope of delivery.


Blanking covers (50 pieces) Order number: 6SL3066-4CA00-0AA0

Note

Only MOTION-CONNECT DRIVE-CLiQ cables may be used for connections. The maximum cable length is 100 m for MOTION-CONNECT 500, and 75 m for MOTION-CONNECT 800PLUS cables.

11.3.2.4 Encoder system interface

Table 11- 10 Encoder system interface SME25

	Pin	Signal name	Technical specifications
	1	P5	Encoder power supply
	2	Reserved, do not use	
	3	Reserved, do not use	
	4	M	Ground for encoder power supply
	5	+Temp	Temperature sensor connection KTY84-1C130 or PTC
	6	-Temp	
	7	P5	Encoder power supply
	8	Clock	Clock, EnDat interface, SSI clock ¹⁾
	9	Clock*	Inverse clock, EnDat interface, Inverse SSI clock ¹⁾
	10	M	Ground for encoder power supply
	11	Enclosure potential	
	12	B	Incremental signal B
	13	B*	Inverse incremental signal B
	14	Data	Data, EnDat interface, SSI data ¹⁾
	15	A	Incremental signal A
	16	A*	Inverse incremental signal A
	17	Data*	Inverse data EnDat interface, Inverse SSI data ¹⁾

Blanking plate for encoder system interface: Pöppelmann GmbH & Co. KG, Lohne,
Order No.: GPN 300 F211
connector kits, 17-pin, Order No.: 6FX2003-0SA17

NOTICE

The KTY temperature sensor must be connected with the correct polarity.

⚠ DANGER

Risk of electric shock!

Only temperature sensors that meet the safety isolation specifications contained in EN 61800-5-1 may be connected to terminals "+Temp" and "-Temp".

If these instructions are not complied with, there is a risk of electric shock!

11.3.3 Dimension drawing





Figure 11-11 Dimension drawing of Sensor Module External SME25, all data in mm and (inches), order number 6SL3055-0AA00-5HA3

11.3.4 Installation



① Contact surface

Figure 11-12 Drilling pattern for installing the SME20/SME25

Installation

1. Place the drilling pattern on the mounting surface. Make sure that the contact surface is bare, unpainted metal.
2. Drill two holes with Ø 5.3 or M5 threaded holes according to the drilling pattern.
3. Fix the Sensor Module to the mounting surface. The tightening torque is 6 Nm.

11.3.5 Technical data

Table 11- 11 Technical data

6SL3055-0AA00-5HA3	Unit	Value
Electronics power supply		
Voltage	V_{DC}	24 DC (20.4 – 28.8)
Current (without encoder system)	A_{DC}	≤ 0.15
Current (with encoder system)	A_{DC}	≤ 0.25
Power loss	W	≤ 4
Encoder system power supply		
Voltage	$V_{encoder}$	5 VDC
Current	$A_{encoder}$	0.35
Encoder frequency that can be evaluated ($f_{encoder}$)	kHz	≤ 500
SSI/EnDat 2.1 baud rate	kHz	100
PE/ground connection		On enclosure with M4/1.8 Nm screw
Weight	kg	0.31
Degree of protection		IP67

The maximum cable length at the encoder system interface depends on the current consumption of the encoder system and the cross-section of the supply cores in the cable. However, the maximum length is 10 m.

11.3 Sensor Module External SME25

For encoder systems that operate in a supply voltage range from 4.75 V to 5.25 V, the following diagram is obtained. The sample parameters shown are 0.28 mm² cross-section (0.14 mm² supply cores plus 0.14 mm² Remote Sense cores) and 0.64 mm² (0.5 mm² supply cores plus 0.14 mm² Remote Sense cores).




Figure 11-13 Max. cable length as a function of the current drawn by the encoder system

In addition to the encoder systems for a supply voltage range of 4.75 V to 5.25 V in the figure above, encoder systems are also available for an extended range down to 3.6 V. These can be generally operated using encoder system cables up to 10 m long provided that the total cross-section of the supply core plus Remote Sense cores does not fall below 0.14 mm².

Accessories

12.1 DRIVE-CLiQ cabinet bushing

12.1.1 Description

The DRIVE-CLiQ cabinet bushing is used in a control cabinet panel, and serves to connect the DRIVE-CLiQ cables between the inside and the outside of the control cabinet. The data lines and the voltage supply contacts of the DRIVE-CLiQ are also routed through the bushing.

The DRIVE-CLiQ cabinet bushing has degree of protection IP54 according to EN 60529 from the outside towards the inside. Inside the control cabinet, a connection is established according to degree of protection IP20 or IPXXB acc. to EN 60529. So that the complete outside of the cabinet bushing, including the DRIVE-CLiQ interface, has degree of protection IP54, a DRIVE-CLiQ cable must be used, which as a minimum must also have degree of protection IP54.

12.1.2 Safety Information


Note

Only cables from Siemens may be used for DRIVE-CLiQ connections.

12.1 DRIVE-CLiQ cabinet bushing

12.1.3 Interface description

12.1.3.1 Overview



- ① Protective cap, Yamaichi, order number: Y-ConAS-24-S
- ② DRIVE-CLiQ interface on the outside (to connect DRIVE-CLiQ signal cables MOTION-CONNECT with IP67 degree of protection)
- ③ Mounting holes
- ④ Flange-type seal to ensure degree of protection IP54 on the outside of the control cabinet
- ⑤ DRIVE-CLiQ interface on the inside (to connect DRIVE-CLiQ signal cables MOTION-CONNECT with IP20 degree of protection)

Figure 12-1 Interface overview, DRIVE-CLiQ cabinet bushing

12.1.4 Dimension drawing




Figure 12-2 Dimension drawing of the DRIVE-CLiQ cabinet gland, all dimensions in mm and (inches)

12.1.5 Installation

In order to install the DRIVE-CLiQ cabinet gland, you must make a cutout in the control cabinet panel as shown in the diagram below.





Figure 12-3 Cut-out for the cabinet

Installation

1. Insert the component from the outside of the control cabinet through the opening in the control cabinet.
2. Fix the DRIVE-CLiQ cabinet gland to the outer control cabinet panel using two M3 screws and two nuts. In order to ensure good electromagnetic compatibility, a good electrical connection must be established between the DRIVE-CLiQ cabinet gland and the cabinet panel over a large surface area.



- ① Control cabinet panel
- ② M3 screw, tightening torque 0.8 Nm
- ③ DRIVE-CLiQ cabinet gland

Figure 12-4 Installing the DRIVE-CLiQ cabinet gland

12.1.6 Technical data

Table 12- 1 Technical data

DRIVE-CLiQ cabinet bushing 6SL3066-2DA00-0AA0	Unit	
Weight	kg	0,165
Degree of protection	IP20 or IPXXB acc. to EN 60529 in the electrical cabinet IP54 to EN 60529 outside the electrical cabinet	

12.2 DRIVE-CLiQ coupling

12.2.1 Description

The DRIVE-CLiQ coupling is used to connect two DRIVE-CLiQ cables in accordance with degree of protection IP67 acc. to EN 60529.

In addition to the data lines, the power supply contacts of DRIVE-CLiQ are also routed via the coupling.

You can find information on the permissible cable length in the chapter "DRIVE-CLiQ signal cables".


12.2.2 Safety information

Note

Only cables from Siemens may be used for DRIVE-CLiQ connections.

12.2.3 Interface description

12.2.3.1 Overview



- ① Rating plate
- ② Protective cap, Yamaichi, order number: Y-ConAS-24-S

Figure 12-5 Interface overview, DRIVE-CLiQ coupling

12.2.4 Dimension drawing





Figure 12-6 Dimension drawing of the DRIVE-CLiQ coupling, all dimensions in mm and (inches)

12.2.5 Installation



① Contact surface

Figure 12-7 Hole drilling pattern for installation

Installation

1. Attach the DRIVE-CLiQ coupling to the mounting surface as shown in the drilling pattern.
2. Remove the protective caps of the DRIVE-CLiQ coupling.
3. Latch the DRIVE-CLiQ connectors at both sides of the DRIVE-CLiQ coupling.

12.2.6 Technical data

Table 12-2 Technical data

DRIVE-CLiQ coupling 6SL3066-2DA00-0AB0	Unit	
Weight	kg	0.272
Degree of protection	IP67 acc. to EN 60529	

Cabinet design and EMC

13.1 General information

The S120 Combi Power Modules fulfill the requirements according to degree of protection IP20 in compliance with EN 60529. This provides protection against electric shock for built-in units. As far as UL 50 is concerned, the components are classified and certified as open type.

Protection against mechanical and climatic stressing must be ensured by installing the modules in enclosures, cabinets or electrical rooms that can be closed and locked. Higher-level enclosures must, as a minimum, have degree of protection IP54 according to EN 60529 or be classified as enclosure type 12 in compliance with UL 50.

Prefabricated MOTION-CONNECT cables are recommended.

Note

Functional safety of SINAMICS components

The components must be protected against conductive pollution. This can be achieved e.g. by installing them in a control cabinet with degree of protection IP54B acc. to EN 60529. Provided that conductive pollution can be prevented at the installation site, the degree of protection for the cabinet can be decreased accordingly.

Low-voltage switchgear and controlgear assemblies

If the S120 Combi is used for the electrical equipment of machines, the applicable requirements of EN 60204-1 must also be adhered to.

Safety of machinery


Electrical equipment of machines


All information for device selection in this section applies to

- Operation on TN and TT line supply systems with grounded neutral point and grounded phase conductor
- Operation on IT line supply systems

13.2 Safety information

CAUTION
<p>The voltage drop between the start of the consumer's installation and the consuming equipment being supplied should generally not exceed 4% in operation with rated values.</p> <p>The relevant tables in Supplement 5 of the standard DIN VDE 0100 should be consulted. The following note must be included in the technical user documentation: The machine manufacturer must ensure that the voltage drop between the start of the load system and the PDS in operation with rated values does not exceed 4 %." (VDE 0100-520)</p> <p>Checking the documented development stipulations regarding the above requirement, implementation in the production documentation and execution in the device.</p>

 DANGER
<p>When installing the cabinet, you must cover the ventilation slots to prevent drill swarf, end sleeves, and so on from falling into the enclosure, which could result in short-circuits or damage the insulation.</p> <p>Safety regulations governing shock protection must be observed. See also EN 60204-1.</p>

 WARNING
<p>If static discharge occurs on surfaces or interfaces that cannot be easily accessed, this can cause malfunctions and/or defects.</p>

13.3 Directives

The product satisfies the protection targets of the following EU Directives applicable within the European Economic Area (EEA):

Table 13- 1 Directives

Directive	Description
2006/95/EC	Directive of the European Parliament and Council of December 12, 2006, on the approximation of the laws of the member states relating to electrical equipment designed for use within certain voltage limits (Low-Voltage Directive).
2004/108/EC	Directive of the European Parliament and Council of December 15, 2004, which repeals directive 89/336/EEC, on the approximation of laws of the member states relating to electromagnetic compatibility (EMC Directive).

13.4 Notes on electromagnetic compatibility (EMC)

Requirements to implement the EMC are listed in EN 61000-6-2, EN 61000-6-4, EN 61800-3, EN 60204-1 and in the Configuration Manual EMC Installation Guideline (order number 6FC5297-0AD30-0□P□). Conformance with the EMC Directive of the EC can be ensured by following the measures described in the Configuration Manual, EMC installation guideline. When mounting components in cabinets, in order to fulfill the EMC Directive, the following conditions must be additionally observed:

- Connected to TN and TT line supplies with grounded neutral point and grounded phase conductor as well as to IT line supplies.
- Observance of information about cable shielding and equipotential bonding.
- Use of the recommended power and signal cables from Siemens.
- Only cables from Siemens may be used for DRIVE-CLiQ connections.

CAUTION

If couplings or cabinet glands are needed for the DRIVE-CLiQ connections, only the DRIVE-CLiQ coupling and DRIVE-CLiQ cabinet gland, described in the Chapter Accessories, may be used.



DANGER

If the shielding procedures described and the specified cable lengths are not observed, the machine may not operate properly.

13.5 Cable shielding and routing

In order to comply with the EMC requirements, certain cables must be routed apart from other cables and from certain components. To full EMC requirements, the following cables must be used with shields:

- Line supply cables from the line filter via the line reactor to the S120 Combi Power Module
- All motor cables (if necessary, including cables for motor holding brake)
- Cables for analog direct voltage/current signals
- Signal cables for sensors
- Cables for temperature sensors

Alternative measures (e.g. routing behind mounting plates, suitable clearances) can also be used provided they have similar results. This excludes measures that relate to the design, installation, and routing of motor power cables and signal cables.

If unshielded cables are used between the line connection point and line filter, make sure that no interfering cables are routed in parallel.

Power and signal cables must always be routed separately. For this purpose, it is practical to arrange the various cables according to cable groups. Cables belonging to a group can be combined in a bundle. The various cable groups must be routed with the necessary clearance between them. A minimum clearance of 20 cm has proven itself in practice. As an alternative, shielding plates with the appropriate contacts at several locations can be used between the cable bundles.

All cables inside the cabinet should be laid as closely as possible to parts connected with cabinet ground, such as a mounting plate or cabinet wall. Ducts made of sheet steel or cables routed between steel sheets (e.g. between the mounting plate and back wall) should provide adequate shielding.

All cables must be kept as short as possible, to minimize the antenna effect.

Signal and power cables may cross each other (if absolutely necessary), but must never be routed closely to one and other in parallel over longer distances.

Signal cables must be routed with a minimum clearance of 20 cm from strong magnetic fields (motors, transformers). Alternatively, shield plates with the appropriate contacts at several locations along their length can be used to provide appropriate clearance.

Note: Cables for the 24 V supply should be treated just like signal cables.

Avoid, where possible, routing non-shielded cables in the immediate vicinity of noise sources, e.g. transformers. Signal cables (shielded and unshielded) must be routed far away from strong external magnetic fields (e.g. transformers, line reactors). In both cases, a distance of ≥ 300 mm is usually sufficient.



A suitable PE conductor must be connected to all devices in protection class I. The PE conductor connection of the individual components must have at least 4 mm².

Shield support

The cable shields must be connected as close to the conductor terminal connections as possible to ensure a low-impedance connection with cabinet ground. For power cables from Siemens in which the shield is connected to the connector shell (see relevant catalog), this is a sufficiently good shield support.

For components that do not have any special shield connection or where the shield connection is not sufficient, the cable shields can be connected to the metal mounting plate using hose clamps and toothed rails. The cable length between the shield contact point and the terminals for cable cores must be kept as short as possible.

Routing 24 V cables

When routing 24 V cables, the following must also be observed:

- A maximum of 1 conductor pair may be bundled together.
- 24 V conductors must be routed separately from other cables and conductors that could carry the operating current.
- 24 V cables must never be routed parallel to power cables.
- 24 V cables as well as power cables should be routed to the components so that they never cover ventilation slots.

Conditions of use for 24 V cables

- Ambient temperature 55 °C
- Limit conductor temperature, ≤ 70 °C for operation with the rated load current
- Cable length max.:
 - 10 m for the 24 V supply cables
 - 30 m for signal cables without a supplementary RC circuit

13.6 24 V DC supply

13.6.1 General information

The 24 V DC voltage is required to supply the

1. electronics of the S120 Combi and the expansion axes (Motor Modules) via the integrated 24 V busbar
2. Electronics of the SINUMERIK 828D PPU, the Sensor Modules, the Terminal Module, the Braking Module as well as the process voltage of its digital inputs
3. Load voltage of the digital outputs
4. Motor holding brake

Other loads can be connected to these power supply units if they are separately protected from overcurrent.

Note

The electronic power supply has to be supplied by the user as described in the System Data chapter of this documentation.

When connecting to a "DC power supply" in the sense of EN 60204-1:1997, Chapter 4.3.3, functional faults can occur due to the voltage interruptions that are permitted there.

 DANGER

Only motors with a safe electrically isolated holding brake may be connected. The brake cores must also be safely electrically isolated.
--

If the motor power cable is connected to intermediate terminals, the power cables and brake cables must be routed separately (≥ 300 mm).
--

 DANGER

Only safety extra-low voltages (DVC A) that comply with EN 61800-5-1 must be connected to the connections and terminals with ratings of between 0 and 48 V DC.
--

Note

A regulated DC power supply is required to operate motors with a built-in holding brake. The voltage is supplied via the internal 24 V busbars. The voltage tolerances of the motor holding brakes ($24\text{ V} \pm 10\%$) and the voltage drops of the connecting cables must be taken into account.

The DC power supply should be set to 26 V. The Control Supply Module supplies 26 V. This ensures that the supply voltage for the brake remains within the permissible range when the following conditions are fulfilled:

- Use of Siemens three-phase motors
- Use of Siemens MOTION-CONNECT power cables
- Motor cable lengths, max. 50 m

NOTICE

If other consumers are connected to the power supply, connected inductance devices (contactors, relays) must be fitted with suitable overvoltage protection circuits.

13.6.2 24 V power supply and connection of components

The S120 Combi with the expansion axes (Motor Modules) and DC link components are connected to the 24 V DC via the integrated 24 V busbars. The current carrying capacity of these busbars is 20 A.

The power can be supplied in two ways:

1. When using an external 24 V power supply, e.g. SITOP, the 24 V connector must be used. The external power supply should be located very close to the load (max. cable length 10 m). Miniature circuit breakers with tripping characteristic D are recommended as overcurrent. The ground potential M must be connected to the protective conductor system (DVC A).




Figure 13-1 Example of an external 24 V power supply

2. When a Control Supply Module is used, the 24 V supply can be directly established through the busbars. The electronic current limiting function integrated in the Control Supply Module protects the busbar system when a fault occurs. Additional loads can be connected via the 24 V connector.




Figure 13-2 Example of a 24 V supply with Control Supply Module

Note

When using cables with a cross-section of 2.5 mm², no additional protection is required on the 24 V side if a type XLPE or EPR cable, or a cable with a similar quality and with a thermal stability of up to 90 °C is used.

Using the 24 V connector

- A 24 V connector must be plugged onto the 24 V busbar between each S120 Combi, expansion axis and DC-link component
- Insertion and withdrawal are only permissible in a de-energized state
- Only 5 withdrawal and insertion cycles are permissible

13.6.3 Overcurrent protection in the 24 V solid-state circuit

The cables on the primary and secondary sides of the 24 V supply unit must be protected against overcurrent.

The protection on the primary side depends on the instructions of the equipment manufacturer.

The protection on the secondary side depends on the actual conditions. Please note the following:

- Loading from loads, possibly the demand factor against the operation of the machine
- Current carrying capacity of the conductors used and cables in normal and short-circuit conditions
- Ambient temperature
- Cable bundling (laying cables in a common duct)
- Cable laying method to EN 60204-1

The overcurrent protection devices can be used according to EN 60204-1, Section 14.

Circuit breakers from the Siemens NSK catalog are recommended as overcurrent protection devices on the primary side.

Miniature circuit breakers or SITOP select (order number 6EP1961-2BA00) are recommended as overcurrent protection devices on the secondary side. The MCBs can be selected according to Siemens catalog "BETA Modular Installation Devices - ET B1".

When selecting the miniature circuit breakers, the following standards must be observed:

- EN 61800-5-1
- EN 60204-1
- IEC 60364-5-52
- IEC 60287-1 to -3
- EN 60228
- UL 508C

Table 13- 2 MCBs by core cross-section and temperature

Core cross-section	Max. value up to 40 °C	Max. value up to 55°C
1.5 mm ²	10 A	6 A
2.5 mm ²	16 A	10 A
4 mm ²	25 A	16 A
6 mm ²	32 A	20 A
24 V busbar	20 A	20 A

The trip characteristic of the MCBs must be selected to match the loads to be protected and the max. current provided by the power supply unit in the event of a short-circuit.

13.6.4 Typical 24 V current consumption of the components

A separate 24 V power supply must be used for the SINAMICS S120 drive line-up.

The following table can be used to calculate the 24 V DC power supply. The values for typical current consumption are used as a basis for configuration.

Table 13- 3 Overview of 24 V DC current consumption

Component	Typical current consumption [A _{DC}]
Controller	
SINUMERIK 828D - PPU without load	1.2
SINUMERIK 828D - PPU with full load (USB, handwheel...)	2.5
Sensor Modules	
SMC20 without/with encoder system	0.20 / 0.355
SME20 without/with encoder system	0.15 / 0.25
SME25 without/with encoder system	0.15 / 0.25
Terminal Modules	
TM54F (without digital outputs, without DRIVE-CLiQ)	0.2
Per digital output/DRIVE-CLiQ	0.5
Additional system components	
DMC20 (without DRIVE-CLiQ)	0.15
per DRIVE-CLiQ	0.5
DME20 (without DRIVE-CLiQ)	0.15
per DRIVE-CLiQ	0.5
S120 Combi 3 axes Power Module	
16 kW / 18 A / 5 A / 5 A	1.5
16 kW / 24 A / 9 A / 9 A	1.5
20 kW / 30 A / 9 A / 9 A	1.5
S120 Combi 4 axes Power Module	
16 kW / 18 A / 9 A / 5 A / 5 A	1.6
16 kW / 24 A / 9 A / 9 A / 9 A	1.6
20 kW / 30 A / 12 A / 9 A / 9 A	1.6
DRIVE-CLiQ and brake	
DRIVE-CLiQ (e.g. motors with DRIVE-CLiQ interface)	0.19
Brake (e.g. motor holding brake)	max. 1
Single Motor Modules Booksize Compact	
3 A (+1 x DRIVE-CLiQ; +1 x brake)	0.75
5 A (+1 x DRIVE-CLiQ; +1 x brake)	0.75
9 A (+1 x DRIVE-CLiQ; +1 x brake)	0.75
18 A (+1 x DRIVE-CLiQ; +1 x brake)	0.75

Component	Typical current consumption [A _{DC}]
Double Motor Modules Booksize Compact	
2 x 1.7 A (+2 x DRIVE-CLiQ; +2 x brake)	1
2 x 3 A (+2 x DRIVE-CLiQ; +2 x brake)	1
2 x 5 A (+2 x DRIVE-CLiQ; +2 x brake)	1
External fan unit	0.8
Braking Module	0.5
Motor encoder	0.25

Example: calculating 24 V DC current requirements

Table 13- 4 Example of 24 V DC current requirements

Component	Number	Current consumption [A]	Total current consumption [A]
SINUMERIK 828D	1	2.5	2.5
S120 Combi 4 axes Power Module with external fan unit	1	2.4	2.4
Motor Module 9 A	1	0.75	0.75
Motor Module 18 A	1	0.75	0.75
Motor encoder	6	0.25	1.50
Brake	1	1	1
Total:			8.9

13.6.5 Selecting power supply units

You are advised to use the devices in the following table. These devices meet the applicable requirements of EN 60204-1.

Table 13- 5 Recommended SITOP Power

Rated output current [A]	Phases	Rated input voltage [V] Working voltage range [V]	Short-circuit current [A]	Order number
5	1 / 2	120 - 230/230 - 500 85 - 264/176 - 550 AC	Approx. 5.5 (power up), typ. 15 for 25 ms (operation)	6EP1333-3BA00-8AC0
10	1 / 2	120 - 230/230 - 500 85 - 264/176 - 550 AC	Approx. 12 (power up), typ. 30 for 25 ms (operation)	6EP1334-3BA00-8AB0
20	1 / 2	120/230 85 - 132/176 - 264 AC	Approx. 23 (power up), typ. 60 for 25 ms (operation)	6EP1336-3BA00-8AA0
	3	3-ph. 230/400 to 288/500 320 - 550 AC		6EP1436-3BA00-8AA0
40	1 / 2	120/230 85 - 132/176 - 264 AC	Approx. 46 (power up), typ. 120 for 25 ms (operation)	6EP1337-3BA00-8AA0
	3	3-ph. 230/400 to 288/500 320 - 550 AC		6EP1437-3BA00-8AA0

Note

When using an external 24 V power supply with a continuous current > 20 A, an overcurrent protection device must be used for the S120 Combi Power Module, the cables and the busbars. A circuit breaker is recommended as overcurrent protection device.


The tripping characteristic of the circuit breaker depends on

- the loads to be protected and
- the maximum current provided by the power supply unit in the case of a short-circuit.

Table 13- 6 Recommendation for Control Supply Module

Rated output current [A]	Phases	Input voltage range [V]	Short-circuit current [A]	Order number
20	3	380 V AC -10% (-15% < 1 min) to 480 V AC +10% DC 300 – 800	< 24	6SL3100-1DE22-0AA1

See also catalog NC61.

 WARNING
When an external power supply is used, e.g. SITOP, the ground potential must be connected to the protective conductor system (DVC A).

13.7 Connection system

13.7.1 DRIVE-CLiQ signal cables

Note

Only MOTION-CONNECT 500 and MOTION-CONNECT 800PLUS DRIVE-CLiQ cables are permitted for the connection. The maximum cable length for MOTION-CONNECT 500 cables is 100 m, for MOTION-CONNECT 800PLUS cables 75 m.

The maximum permissible cable length for the use of DRIVE-CLiQ couplings is calculated as follows:

$$\Sigma MC500 + 4/3 \times \Sigma MC800PLUS + n_c \times 5 \text{ m} \leq 100 \text{ m}$$

$\Sigma MC500$: Total length of all MC500 cable segments (fixed routing)

$\Sigma MC800PLUS$: Total length of all MC800PLUS cable segments (tow chain)

n_c : Number of DRIVE-CLiQ connectors (max. 0...3)

Table 13- 7 Comparison between MOTION-CONNECT 500 and MOTION-CONNECT 800PLUS DRIVE-CLiQ cables

DRIVE-CLiQ signal cable	MOTION-CONNECT 500	MOTION-CONNECT 800PLUS
Approvals		
VDE cURus or UR/CSA UR-CSA File No. ¹⁾ in conformance with RoHS	Yes UL STYLE 2502/CSA-N.210.2-M90 Yes Yes	Yes UL STYLE 2502/CSA-N.210.2-M90 Yes Yes
Rated voltage V_0/V in accordance with EN 50395	30 V	30 V
Test voltage, rms	500 V	500 V
Operating temperature at the surface		
Permanently installed Moveable	-20 to +80°C 0 to 60°C	-20 to +80°C -20 to +60°C
Tensile load, max.		
Permanently installed Moveable	80 N/mm ² 30 N/mm ²	50 N/mm ² 20 N/mm ²
Smallest bending radius		
Permanently installed Moveable	35 mm 125 mm	35 mm 75 mm
Torsional stress	30°/m absolute	30°/m absolute
Bending operations	100000	10 million
Max. traversing speed	30 m/min	300 m/min
Max. acceleration	2 m/s ²	Up to 50 m/s ² (3 m)
insulation material	CFC/silicone-free	CFC/halogen-free/silicon-free
Oil resistance	EN 60811-2-1 (mineral oil only)	EN 60811-2-1
Protective jacket	PVC	PUR, HD22.10 S2 (VDE 0282, Part 10)
Flame retardant	EN 60332-1-1 to 1-3	EN 60332-1-1 to 1-3

1) The file number is printed on the cable jacket.

13.7.2 Power cables for motors

13.7.2.1 Approved power cables

Note

Only MOTION-CONNECT 500 and MOTION-CONNECT 800 power cables are permissible for the S120 Combi.

Table 13- 8 Approved power cables for motors connected to the S120 Combi - pre-assembled

Motor	Order number 6FX□002-	Description	D _{max}	
			6FX5	6FX8
1PH8 with terminal box	5CE02	Power cable 1PH808 4 x 2.5	10.0	12.1
1PH8 with terminal box	5CE04	Power cable 1PH810 4 x 4	11.4	13.2
1PH8 with terminal box	5CE06	Power cable 1PH813 4 x 6	13.6	16.0
1FT7/1FK7 with fast release	5CF10	Power cable 4 x 1.5 GR.1 SC	8.4	10.4
	5DF10	Power cable 4 x 1.5 + 2 x 1.5 GR.1 SC	10.8	12.9
1PH8 with connector with fast release	5DF11	Power cable 4 x 2.5 GR.1.5 SC	10.0	12.1
1PH8 with connector with fast release	5CF12	Power cable 4 x 4 GR.1.5 SC	11.4	13.2
1PH8 with connector without fast release	5CF13	Power cable 4 x 10 GR.3	20	19.4

□... 5 = MC500, 8 = MC800

Note

If the connecting cables for a 24 V motor holding brake are included in the power cable, then only the specified cables must be used. These cables must have a separate shield for the 24 V and must be suitable for safe electrical separation.

The cable shield of the motor holding brake cores must be connected at both ends.

Note

In order that the specified EMC limit values (EN 61800-3) are maintained, only shielded type MC500 and MC800 power cables must be used. The permissible cable length is 25 m for rated output currents I_n from 5 A to 30 A.

The total cable length for the complete drive line-up is 175 m.

Comparison of MOTION-CONNECT power cables

MOTION-CONNECT 500 power cables are mainly suitable for permanent routing. The MOTION-CONNECT 800PLUS power cables fulfill all high mechanical requirements for the use in tow chains. They are resistant to cutting oils.

Table 13-9 Comparison of the MOTION-CONNECT 500 and MOTION-CONNECT 800PLUS power cables

Power cable	MOTION-CONNECT 500	MOTION-CONNECT 800PLUS
Approvals		
VDE ¹⁾ cURus or UR/CSA UR-CSA File No. ²⁾ in conformance with RoHS	Yes UL758-CSA-C22.2-N.210.2-M90 Yes Yes	Yes UL758-CSA-C22.2-N.210.2-M90 Yes Yes
Rated voltage V_0/V in accordance with EN 50395		
Supply cores Signal cores	600 V / 1000 V 24 V (EN) 1000 V (UL/CSA)	600 V / 1000 V 24 V (EN) 1000 V (UL/CSA)
Test voltage, rms		
Supply cores Signal cores	4 kV 2 kV	4 kV 2 kV
Operating temperature at the surface		
Permanently installed Moveable	-20 to +80°C 0 to 60°C	-20 to +80°C -20 to +60°C
Tensile load, max.		
Permanently installed Moveable	50 N/mm ² 20 N/mm ²	50 N/mm ² 20 N/mm ²
Smallest bending radius		
Permanently installed Moveable	5 x D _{max} approx. 18 x D _{max}	4 x D _{max} approx. 8 x D _{max}
Torsional stress	30°/m absolute	30°/m absolute
Bending operations	100000	10 million
Max. traversing speed	30 m/min	Up to 300 m/min
Max. acceleration	2 m/s ²	50 m/s ² (3 m)
insulation material	CFC/silicone-free	CFC/halogen/silicone-free IEC 60754-1 / DIN VDE 0472-815
Oil resistance	EN 60811-2-1 (mineral oil only)	EN 60811-2-1
Protective jacket	PVC	PUR, HD22.10 S2 (VDE 0282, Part 10)
Flame retardant	EN 60332-1-1 to 1-3	EN 60332-1-1 to 1-3

1) The registration number is printed on the cable jacket.

2) The file number is printed on the cable jacket.

13.7.3 Current-carrying capacity and derating factors for power cables and signal cables

The current-carrying capacity of PVC/PUR-insulated copper cables is specified for routing types B1, B2 and C under continuous operating conditions in the table with reference to an ambient air temperature of 40°C. For other ambient temperatures, the values must be corrected by the factors listed in the "Derating factors for deviating conditions" table.

Table 13- 10 Current-carrying capacity according to EN 60204-1 for 40°C ambient temperature

Cross section mm ²	Current-carrying capacity, effective; AC 50/60 Hz or DC for routing type		
	B1 A	B2 A	C A
Electronics			
0.20	–	4.3	4.4
0.50	–	7.5	7.5
0.75	–	9	9.5
Power			
0.75	8.6	8.5	9.8
1.00	10.3	10.1	11.7
1.50	13.5	13.1	15.2
2.50	18.3	17.4	21
4	24	23	28
6	31	30	36
10	44	40	50
16	59	54	66

Installation types

B1 cables in conduits or installation ducts

B2 multi-core cables in conduits or installation ducts

C cables along walls/panels without conduits and installation ducts

Table 13- 11 Derating factors for deviating conditions

Ambient temperature [°C]	Derating factor according to EN 60204-1 Table D1
30	1.15
35	1.08
40	1.00
45	0.91
50	0.82
55	0.71
60	0.58

Example for dimensioning a power cable

Boundary conditions:

Module: S120 Combi 4 axes Power Module with 20 kW infeed

Rated input current at 400 V_{AC}: 34 A (from the technical data)

Ambient temperature: 45°C

Installation type: B2

Calculation/dimensioning:

With installation type B2 and a rated input current of 34 A_{AC}, from the table showing the current-carrying capacity, a cable cross-section of 10 mm² is obtained.

With a derating factor of 0.91 for 45°C ambient temperature, the current-carrying capacity of the selected power cable decreases to 36.4 A.

Result:

Under the given boundary conditions, a power cable with a cross-section of 10 mm² can be used.

13.7.4 Connectable conductor cross-sections for spring-loaded terminals

Table 13- 12 Spring-loaded terminals

Spring-loaded terminal type			
1	Connectable conductor cross-sections	Flexible	0.08 mm ² to 2.5 mm ²
	Stripped length	8 to 9 mm	
	Tool	Screwdriver 0.4 x 2.0 mm	

13.7.5 Connectable conductor cross-sections for screw terminals

The type of screw terminal can be taken from the interface description of the particular module.

Table 13- 13 Screw terminals

Screw terminal type			
1	Connectable conductor cross-sections	Rigid, flexible With end sleeve, without plastic sleeve With end sleeve, with plastic sleeve	0.08 mm ² to 1.5 mm ² 0.25 mm ² to 1.5 mm ² 0.25 mm ² to 0.5 mm ²
	Stripped length	7 mm	
	Tool	Screwdriver 0.4 x 2.0 mm	
	Tightening torque	0.22 to 0.25 Nm	
2	Connectable conductor cross-sections	Rigid, flexible With end sleeve, without plastic sleeve With end sleeve, with plastic sleeve	0.14 mm ² to 1.5 mm ² 0.25 mm ² to 1.5 mm ² 0.25 mm ² to 0.5 mm ²
	Stripped length	7 mm	
	Tool	Screwdriver 0.4 x 2.5 mm	
	Tightening torque	0.22 to 0.25 Nm	
3	Connectable conductor cross-sections	Rigid, flexible With end sleeve, without plastic sleeve With end sleeve, with plastic sleeve	0.08 mm ² to 2.5 mm ² 0.5 mm ² to 2.5 mm ² 0.5 mm ² to 1.5 mm ²
	Stripped length	7 mm	
	Tool	Screwdriver 0.6 x 3.5 mm	
	Tightening torque	0.5 to 0.6 Nm	
4	Connectable conductor cross-sections	Flexible With end sleeve, without plastic sleeve with end sleeve, with plastic sleeve	0.2 mm ² to 4 mm ² 0.25 mm ² to 4 mm ² 0.25 mm ² to 4 mm ²
	Stripped length	7 mm	
	Tool	Screwdriver 0.6 x 3.5 mm	
	Tightening torque	0.5 to 0.6 Nm	

Screw terminal type			
5	Connectable conductor cross-sections	Flexible With end sleeve, without plastic sleeve with end sleeve, with plastic sleeve	1 mm ² to 6 mm ² 1 mm ² to 6 mm ² 1 mm ² to 6 mm ²
	Stripped length	10 mm	
	Tool	Screwdriver 1.0 x 4.0 mm	
	Tightening torque	1.5 to 1.8 Nm	
6	Connectable conductor cross-sections	Flexible With end sleeve, without plastic sleeve with end sleeve, with plastic sleeve	1 mm ² to 10 mm ² 1 mm ² to 10 mm ² 1 mm ² to 10 mm ²
	Stripped length	10 mm	
	Tool	Screwdriver 1.0 x 4.0 mm	
	Tightening torque	1.5 to 1.8 Nm	
7	Connectable conductor cross-sections	Flexible With end sleeve, without plastic sleeve with end sleeve, with plastic sleeve	1.5 mm ² to 16 mm ² 1.5 mm ² to 16 mm ² 1.5 mm ² to 16 mm ²
	Stripped length	11 mm	
	Tool	Screwdriver 1.0 x 4.0 mm	
	Tightening torque	1.5 to 1.8 Nm	

13.8 Protective connection and equipotential bonding

Protective connections

The S120 Combi is designed for use in control cabinets with a protective conductor connection.

The protective conductor connection of the S120 Combi must be connected to the protective conductor connection of the control cabinet as follows:

Table 13- 14 Cross-section for copper protective conductors

Line supply cable in mm ²	Protective connection in mm ² copper
Up to 16 mm ²	The same as the line supply cable
From 16 mm ² to 35 mm ²	16 mm ²
From 35 mm ²	0.5 * line supply cable

For materials other than copper, the cross-section should be increased so that as a minimum, the same conductivity is attained.

All plant and machine parts must be incorporated in the protective concept.

The protective ground connection of the motors used must be established through the motor cable. For EMC reasons, these protective ground connections should be connected at the S120 Combi.

In order to maintain the EMC limit values, the S120 Combi drive line-up - including the expansion axes and DC link components - must be arranged together on a bare metal mounting plate. The mounting plate serves as an equipotential bonding surface. This means that no additional equipotential bonding is required within the drive line-up. The mounting plate must be connected to the protective conductor connection of the control cabinet through a low impedance.

Equipotential bonding

A mounting plate serves simultaneously as an equipotential bonding surface. This means that no additional equipotential bonding is required within the drive line-up.

If a common bare metal mounting plate is not available, then an equally good equipotential bonding must be established using cable cross-sections as listed in the table above or as a minimum with the same conductivity.

When mounting components on standard mounting rails, the equipotential bonding data listed in the table apply. If only smaller connection cross-sections are permissible at the components, then the largest possible cross-section should be used, e.g. 6 mm² for SMC. These requirements also apply to distributed components located outside the control cabinet.

NOTICE

Non-observance of the above guidelines on equipotential bonding can lead to faults on the fieldbus interfaces or to malfunction of the devices.

13.9 Note on control cabinet cooling

13.9.1 General information

The cabinet can be cooled, among others, by using:

- Filter fans
- Heat exchangers
- Refrigerators
- external air cooling

The decision in favor of one of these methods will depend on the prevailing ambient conditions and the cooling power required.

The air routing inside the control cabinet and the cooling clearances specified here, must be carefully observed. Other components or cables must not be installed/routed in these areas.

CAUTION

If you do not observe the guidelines for installing SINAMICS equipment in the cabinet, this can reduce the service life of the equipment and result in premature component failure.

You must take into account the following specifications when installing a SINAMICS drive line-up:

- Ventilation clearance
- Wiring and cabling
- Air guidance, air-conditioner

Table 13- 15 Ventilation clearances above and below the components

Component	Order number	Clearance [mm]
S120 Combi 3 axes Power Module	6SL3111-3VE2x-xxA0	80
S120 Combi 4 axes Power Module	6SL3111-4VE2x-xxA0	80
Motor Modules Booksize Compact	6SL3420-xTExx-xAAx	80
Line filters	6SL3000-0BE21-6DA1	100
Line reactors	6SL3100-0EE2x-xAA0	100
Braking Module	6SL3100-1AE31-0AAx	80
Control Supply Module	6SL3100-1DE22-0AAx	80
SMC20	6SL3055-0AA00-5EAx	50
DMC20	6SL3055-0AA00-6AAx	50
Terminal Module TM54F	6SL3055-0AA00-3BAx	50




Figure 13-3 Cooling clearances for an S120 Combi Power Module with expansion axis




Figure 13-4 Cooling clearances for Motor Modules Booksize Compact

13.9 Note on control cabinet cooling




Figure 13-5 Cooling clearances for modules mounted on standard rails (e.g. SMC, DMC)

13.9.2 Ventilation

The S120 Combi is equipped with an internal fan to circulate the air inside the unit.

The cooling air must flow vertically through the external heat sink of the S120 Combi.

When using filter fans, heat exchangers, or air conditioners to cool the control cabinet, it must be ensured that the air is flowing in the correct direction. You must also ensure that the warm air can escape at the top. A ventilation clearance of at least 80 mm above and below must be observed.

NOTICE
The connected signal and power cables must be routed to the components in such a way that they do not cover the ventilation slots.
Cold air must not be allowed to blow directly onto electronic equipment.

Note

The distance between the discharge opening of the air conditioner and the electronic equipment must be at least 200 mm.

Note

If the components are installed in a sealed cabinet, an internal air cooling system must be installed to circulate the air and prevent hot spots. It is best to install the fan above the components to optimize the air flow (suction).

13.9 Note on control cabinet cooling




Figure 13-6 Examples of cabinet ventilation

CAUTION

The air guidance and arrangement of the cooling equipment must be chosen in such a way that no condensation can form on the components. If necessary, cabinet enclosure heating may have to be installed.

If air conditioners are used, the relative air humidity of the expelled air increases as the air in the air conditioner cools and may exceed the dew point. If the relative humidity of the air entering the SINAMICS equipment is over 80% for an extended period of time, the insulation in the equipment may fail to function properly due to electrochemical reactions (see Chapter "System overview"). Using air baffle plates, for example, you must ensure that the cold air expelled from the air conditioner mixes with warm air in the cabinet before it enters the unit. This reduces the relative air humidity to uncritical values.

13.9.3 Dimensioning Climate Control Equipment

Cabinet manufacturers provide calculation programs for selecting climate control equipment. It is always necessary to know the power loss of the components and equipment installed in the cabinet.

The physical relationship is shown in the following example.

Calculating the thermal power to be dissipated: $q = Q - k \times A \times \Delta T$

with

q = thermal power that has to be dissipated using a cooling unit [W]

Q = power loss [W]

ΔT = difference between the room temperature and the temperature inside the cabinet [K]

k = heat transfer coefficient, e.g. sheet-steel, painted 5.5 [W/(m² * K)]

A = free-standing cabinet surface area [m²]

Table 13- 16 Example, calculating the power loss of a drive configuration

Component	Number	Total power loss [W] (including electronic losses)	Total power loss [W]
SINUMERIK 828D	1	28	28
Line filter	1	16	16
Line reactor	1	98	98
S120 Combi 3 axes Power Module 20 kW	1	634	634
Motor Module 9 A	1	100.4	100.4
Motor Module 18 A	1	185.4	185.4
SMC	2	10	20
SITOP 20	1	53	53
Line contactor	1	12	12
Total:			1146.8

Assumption:

free-standing control cabinet surface $A = 5 \text{ m}^2$

difference between the room temperature and the temperature inside the control cabinet $\Delta T = 10 \text{ K}$

$q = 1644 \text{ W} - 5.5 \text{ W} / (\text{m}^2 \text{ K}) * 5 \text{ m}^2 * 10 \text{ K} = 871.8 \text{ W}$

13.9.4 Power loss of components in rated operation

13.9.4.1 General information

The tables below provide an overview of the power loss of all components during rated operation. The characteristic values apply for the following conditions:

- Line supply voltage 400 V
- Pulse frequency of the Motor Modules 4 kHz
- Operating components at their rated power

The total losses of the relevant components (S120 Combi, Motor Module) are calculated from the power loss and the corresponding losses from the electronics.

13.9.4.2 Power losses for SINUMERIK 828D, DC link components and supplementary system components

Table 13- 17 Overview of power losses at rated operation for SINUMERIK 828D, DC link components and supplementary system components

	Unit	Power loss
SINUMERIK 828D	W	28
SMC20	W	< 10
SME20/25	W	< 4
TM54F	W	4.5
Braking Module	W	20
Control Supply Module		
Line	W	70
DC link	W	65

13.9.4.3 Power losses for S120 Combi Power Modules

Power losses in rated operation

The following table provides an overview of the internal and external losses of the S120 Combi Power Modules for rated operation.

Table 13- 18 Overview of power losses in rated operation for S120 Combi Power Modules

	Unit	Internal power loss	External power loss	Total power loss ¹⁾
S120 Combi 3 axes Power Module				
16 kW / 18 A / 5 A / 5 A	W	81	344	425
16 kW / 24 A / 9 A / 9 A	W	91	446	537
20 kW / 30 A / 9 A / 9 A	W	102	532	634
S120 Combi 4 axes Power Module				
16 kW / 18 A / 9 A / 5 A / 5 A	W	87	405	492
16 kW / 24 A / 9 A / 9 A / 9 A	W	100	507	607
20 kW / 30 A / 12 A / 9 A / 9 A	W	113	620	733

1) The external fan unit has been taken into account in the specified power losses

13.9.4.4 Power loss for line filters and line reactors

Table 13- 19 Overview of power loss during rated operation for line filters and line reactors

	Unit	Power loss
Line filters		
16 kW	W	16
20 kW	W	16
Line reactors		
16 kW	W	75
20 kW	W	98

13.9.4.5 Electronics losses of power units

Table 13- 20 Electronics losses for Motor Modules Booksize Compact and S120 Combi Power Modules

Component		Power loss [W]
Single Motor Module	3 A	20.4
	5 A	20.4
	9 A	20.4
	18 A	20.4
Double Motor Module	1.7 A	27.6
	3 A	27.6
	5 A	27.6
S120 Combi 3 axes Power Module	16 kW / 18 A / 5 A / 5 A	24.0
	16 kW / 24 A / 9 A / 9 A	31.2
	20 kW / 30 A / 9 A / 9 A	26.4
S120 Combi 4 axes Power Module	16 kW / 18 A / 9 A / 5 A / 5 A	24.0
	16 k W 24 A / 9 A / 9 A / 9 A	31.2
	20 kW / 30 A / 12 A / 9 A / 9 A	26.4

13.9.4.6 Losses in partial-load operation

Losses in the partial-load range for the S120 Combi

The losses of the S120 Combi in partial-load operation can be calculated using the following formula:

$$P_V = a + b + IN1 \times P1 + S1 \times I1 + S2 \times I2 + S3 \times I3 + S4 \times I4$$

With:

a: Electronics losses of the S120 Combi

b: Electronics losses of the external fan unit (Order No.: 6SL3161-0EP00-0AA0)

IN1, S1 - S4: Coefficients to calculate the power loss

P1: Infeed power [kW] (LINE X1)

I1: Spindle current [A] (SPINDLE X2)

I2: Current of the 1st feed axis (servo X3)

I3: Current of the 2nd feed axis (servo X4)

I4: Current of the 3rd feed axis (servo X5)

Table 13- 21 Overview of the coefficients to calculate the total power loss P_V in the partial-load range

Power Module	a	b	IN1	S1	S2	S3	S4
3 axes Power Module							
16 kW / 18 A	36	19.2	11.05	7.1	6.5	6.5	
16 kW / 24 A	36	19.2	11.2	7.2	7.2	7.2	
20 kW / 30 A	36	19.2	11.5	7.3	7.2	7.2	
4 axes Power Module							
16 kW / 18 A	38.4	19.2	11.05	7.1	7.2	6.5	6.5
16 kW / 24 A	38.4	19.2	11.4	7.2	7.2	7.2	7.2
20 kW / 30 A	38.4	19.2	11.7	7.3	7.7	7.2	7.2

Table 13- 22 Overview of the coefficients to calculate the power loss P_V in the control cabinet for external cooling

Power Module	a	b	IN1	S1	S2	S3	S4
3 axes Power Module							
16 kW / 18 A	36	0	1.95	0.6	0.4	0.4	
16 kW / 24 A	36	0	2.1	0.6	0.4	0.4	
20 kW / 30 A	36	0	2.03	0.6	0.4	0.4	
4 axes Power Module							
16 kW / 18 A	38.4	0	1.95	0.6	0.4	0.4	0.4
16 kW / 24 A	38.4	0	2.3	0.6	0.4	0.4	0.4
20 kW / 30 A	38.4	0	2.23	0.6	0.4	0.4	0.4

Losses in the partial-load range for line reactors

The losses of the line reactors in partial-load operation can be calculated using the following formula:

$$P_v = D1 \times P1$$

With:

D1: Coefficient to calculate the power loss

P1: Infeed power [kW]

Table 13- 23 Overview of the coefficients to calculate the power loss P_v in the partial-load range

Line reactor	D1
6SL3100-0EE21-6AA0 (16 kW)	4.7
6SL3100-0EE22-0AA0 (20 kW)	4.9

Service and maintenance

14.1 Technical Support

Technical support

If you have any further questions, please call our hotline:

Technical Support

Tel.: +49 (0) 180 5050 – 222

Fax: +49 (0) 180 5050 – 223

E-mail: adsupport@siemens.com

Please send any questions about the documentation (suggestions for improvement, corrections, and so on) to the following fax number or e-mail address:

Fax: +49 (0) 9131 98 – 2176

E-mail: docu.motioncontrol@siemens.com

Internet Address

Up-to-date information about our products can be found on the Internet at the following address:

<http://www.ad.siemens.de/mc>

14.2 Spare parts

S120 Combi spare parts list

An overview of all of the S120 Combi spare parts is provided in the table below

Table 14- 1 List of available spare parts for the S120 Combi

Designation	MLFB
S120 Combi front cover	6SL3161-3FP00-0AA0
S120 Combi guiding frame for DRIVE-CLiQ cables	6SL3161-3EP00-0AA0
S120 Combi DC link lateral cover	6SL3161-3AP00-0AA0
S120 Combi internal fan	6SL3161-0IP00-0AA0
S120 Combi external fan unit	6SL3161-0EP00-0AA0
S120 Combi accessories pack Contents: 24 V connector Terminal for the motor holding brake 4 DRIVE-CLiQ blanking covers 2 terminals (4-pole) for X12/X13 2 terminals (4-pole) for X21/X22 5 shield terminals for motor cables Shield terminal for EP signal cables	6SL3161-8AP00-0AA0

Spare parts list, additional components

You will find spare parts for all of the other components and modules in the Internet under:

<http://support.automation.siemens.com/WW/view/de/16612315>

14.3 Replacing the fan

14.3.1 Safety instructions when replacing a fan

 DANGER

Risk of electric shock

Switch off the power supply (400 V AC) before replacing the fan. A hazardous voltage is still present for up to 5 minutes after the power supply has been switched off. This time must first elapse before it is permissible to remove the cover of the unit or the fan cover.
--

Before removing the component, check that the system is in a voltage-free state!
--

NOTICE

When replacing the fan, you must observe the ESD regulations.


Only qualified personnel are permitted to install spare parts.
--


14.3.2 Replacing the Internal fan on the S120 Combi Power Module

When required, the internal S120 Combi fan can be replaced. It can be ordered as a spare part (order number: 6SL3161-0JP00-0AA0).

Removing the internal fan

1. Remove the S120 Combi front cover (see Chapter "Electrical connection of Motor Modules and DC link components")





Installing the internal fan

1. Before installing the fan, check the air flow direction (arrows on the fan must match the diagram shown below)







Figure 14-1 Arrows on the fan for the air flow direction

2. Installing the fan
The connecting cables must not be crushed!
3. Insert the connector (the connector must audibly click into place)
4. Close the fan cover.
5. Fix the Torx-slotted screw on the fan cover
6. Mount the front cover and tighten the screws at the front

14.3.3 Replacing the fan on the Motor Modules Booksize Compact

Table 14-2 Removing the fan

Size 50 mm	Size 75 mm
<ul style="list-style-type: none">Removing the Motor Module from the drive line-up	
	
<ul style="list-style-type: none">Remove the fan cover at the lower side of the Motor Module by releasing the snap hook	
	
<ul style="list-style-type: none">Carefully remove the fan	




Table 14- 3 Installing a fan

Size 50 mm	Size 75 mm
<ul style="list-style-type: none"> • Before installing the fan, check the air flow direction (the arrow on the fan must point towards the cooling ribs). 	
<ul style="list-style-type: none"> • Insert the connector until it clicks into place • Installing the fan - Notice! Do not crush the connection cables! • Insert the fan cover. 	

14.3.4 Replacing the fan on the Control Supply Module

Replacement fan (order number: 6SL3160-0AB00-0AA0)


 WARNING
This component has more than one supply circuit!

Table 14- 4 Removing the fan

- Remove the component from the drive line-up.
- Release the 6 screws (Torx T10) of the enclosure cover and open the component



- Unlatch and pull out the plug connector



- Release the 2 screws on the fan (Torx T20)



- Remove the fan



Installing a fan

1. Before installing the fan, check the air flow direction (the arrow on the fan must point towards the cooling ribs).
2. Insert the connector until it fully engages.
3. Screw in the 2 screws at the fan (Torx T20); tightening torque 1.2 Nm
4. Close the enclosure cover and tighten the 6 screws (Torx T10); tightening torque 0.8 Nm

14.4 Cleaning the S120 Combi heat sink

The S120 Combi heat sink should be cleaned at regular intervals using either compressed air or high-pressure water jets.

To clean the heat sink, the air baffle plate at the rear of the S120 Combi must be removed as follows:

Table 14- 5 Removing the air baffle plate on the S120 Combi

<p>Releasing the fixing screws through the holes in the reinforcement plates</p>		<p>Screws: Slotted or cross slot M4 x 10, DIN EN ISO 7046-1/2</p>
<p>Remove the air baffle plate in the direction of the arrow</p>		<p>The heat sink can now be cleaned</p>

After cleaning the heat sink, the air baffle plate is reinstalled in the reverse sequence.

Tightening torque for the screws: 1.8 Nm.

14.5 Forming the DC link capacitors

 **CAUTION**

If the S120 Combi Power Modules and the Motor Modules Booksize Compact have been kept in storage for more than two years, the DC link capacitors have to be reformed. If the capacitors are not reformed, then there is a danger that the components could be damaged when switching on.

If the cabinet is commissioned within two years of its date of manufacture, the DC link capacitors do not need to be reformed. The date of manufacture can be taken from the serial number on the rating plate.

Note

The storage period is calculated from the date of manufacture and not from the date that the equipment was shipped.

A defined voltage and a limited current are applied to the DC link capacitors when forming them. As a consequence, the internal relationships required for the DC link capacitors to function correctly are re-established.

Date of manufacture

The date of manufacture can be determined from the following assignment to the serial number (e.g. T-**XN**2067000015 for 2009, November):

Table 14- 6 Production year and month

Character	Year of manufacture	Character	Month of manufacture
X	2009	1 to 9	January to September
A	2010	O	October
B	2011	N	November
C	2012	D	December
D	2013		

The serial number is found on the rating plate.

Forming circuit

The S120 Combi Power Module has internal PTC resistors to pre-charge the DC link capacitors. The resistors can be used to form the DC link capacitors of the S120 Combi Module as well as the expansion axes (Motors Modules Booksize Compact).

During the forming process, it is not permissible for the S120 Combi Power Module to receive a switch-on command. Therefore, disconnect the 24 V power supply to the S120 Combi Power Module.

Procedure

S120 Combi Power Modules

1. Connect the S120 Combi Power Module with line reactor to the line supply (see the connection example in Chapter "S120 Combi Power Modules / interface description").
2. Keep the module connected to the line supply for approx. 1 hour without issuing a switch-on command.

Expansion axis (Motor Module Booksize Compact)

1. Connect the expansion axis to be formed to the DC link of the S120 Combi Power Module.
2. Connect the S120 Combi Power Module with line reactor to the line supply (see the connection example in Chapter "S120 Combi Power Modules / interface description").
3. Keep the S120 Combi Power Module and the expansion axis connected to the line supply for approx. 1 hour without issuing a switch-on command.



Risk of electric shock

As a result of the DC link capacitors, a hazardous voltage is present for up to 5 minutes after the power supply has been switched off. Work may only be carried out on the components after this time has elapsed.

14.6 Recycling and disposal

The applicable national guidelines must be observed when disposing of the product.

The products described in this Equipment Manual are extensively recyclable on account of the low-toxic composition of the materials used. For environmentally-compliant recycling and disposal of your electronic waste, please contact a company for the disposal of electronic waste.

Appendix

A.1 List of abbreviations

Note:

The following list of abbreviations includes all abbreviations and their meanings used in the entire SINAMICS user documentation.

Abbreviation	Source of abbreviation	Meaning
A		
A...	Alarm	Alarm
AC	Alternating Current	Alternating current
ADC	Analog Digital Converter	Analog digital converter
AI	Analog Input	Analog input
AIM	Active Interface Module	Active Interface Module
ALM	Active Line Module	Active Line Module
AO	Analog Output	Analog output
AOP	Advanced Operator Panel	Advanced Operator Panel
APC	Advanced Positioning Control	Advanced Positioning Control
AR	Automatic Restart	Automatic restart
ASC	Armature Short Circuit	Armature short circuit
ASCII	American Standard Code for Information Interchange	American standard code for information interchange
ASM	Asynchronmotor	Induction motor
B		
BERO	-	Contactless proximity switch
BI	Binector Input	Binector input
BIA	Berufsgenossenschaftliches Institut für Arbeitssicherheit	Germany's Institute for Occupational Safety and Health
BICO	Binector Connector Technology	Binector connector technology
BLM	Basic Line Module	Basic Line Module
BO	Binector Output	Binector output
BOP	Basic Operator Panel	Basic Operator Panel

Abbreviation	Source of abbreviation	Meaning
C		
C	Capacitance	Capacitance
C...	-	Safety message
CAN	Controller Area Network	Serial bus system
CBC	Communication Board CAN	Communication board CAN
CD	Compact Disc	Compact Disc
CDC	Crosswise data comparison	Crosswise data comparison
CDS	Command Data Set	Command data set
CF Card	CompactFlash Card	CompactFlash Card
CI	Connector Input	Connector input
CLC	Clearance Control	Clearance control
CNC	Computer Numerical Control	Computer numerical control
CO	Connector Output	Connector output
CO/BO	Connector Output/Binector Output	Connector/binector output
COB ID	CAN Object Identification	CAN Object identification
COM	Common contact of a changeover relay	Center contact of a changeover contact
COMM	Commissioning	Commissioning
CP	Communication Processor	Communication processor
CPU	Central Processing Unit	Central processing unit
CRC	Cyclic Redundancy Check	Cyclic redundancy check
CSM	Control Supply Module	Control Supply Module
CU	Control Unit	Control Unit
CUA	Control Unit Adapter	Control Unit Adapter
CUD	Control Unit DC MASTER	Control Unit DC MASTER
D		
DAC	Digital Analog Converter	Digital analog converter
DC	Direct Current	DC current
DC link	DC link	DC link
DCB	Drive Control Block	Drive Control Block
DCC	Drive Control Chart	Drive Control Chart
DCC	Data Cross Check	Crosswise data comparison
DCN	Direct Current Negative	DC current negative
DCP	Direct Current Positive	DC current positive
DDS	Drive Data Set	Drive data set
DI	Digital Input	Digital input
DI/DO	Digital Input/Digital Output	Digital input/output bidirectional
DMC	DRIVE-CLiQ Hub Module Cabinet	DRIVE-CLiQ Hub Module Cabinet
DME	DRIVE-CLiQ Hub Module External	DRIVE-CLiQ Hub Module External
DO	Digital Output	Digital output
DO	Drive Object	Drive object

Abbreviation	Source of abbreviation	Meaning
DP	Decentralized Peripherals	Distributed IOs
DPRAM	Dual Ported Random Access Memory	Memory with dual access ports
DRAM	Dynamic Random Access Memory	Dynamic memory
DRIVE-CLiQ	Drive Component Link with IQ	Drive Component Link with IQ
DSC	Dynamic Servo Control	Dynamic Servo Control
E		
EASC	External Armature Short Circuit	External armature short circuit
EDS	Encoder Data Set	Encoder data set
ESD	Electrostatic Sensitive Devices	Electrostatic sensitive devices
ELCB	Earth Leakage Circuit Breaker	Earth leakage circuit breaker
ELP	Earth Leakage Protection	Earth leakage protection
EMC	Electromagnetic Compatibility	Electromagnetic compatibility
EMF	Electromagnetic Force	Electromagnetic force
EMC	Electromagnetic compatibility	Electromagnetic compatibility
EN	European standard	European standard
EnDat	Encoder Data Interface	Encoder interface
EP	Enable Pulses	Pulse enable
EPOS	Einfachpositionierer	Basic positioner
ES	Engineering System	Engineering System
ESB	Equivalent circuit diagram	Equivalent circuit diagram
ESD	Electrostatic Sensitive Devices	Electrostatic sensitive devices
ESR	Extended Stop and Retract	Extended stop and retract
F		
F...	Fault	Fault
FAQs	Frequently Asked Questions	Frequently asked questions
FBL	Free Blocks	Free function blocks
FCC	Function Control Chart	Function Control Chart
FCC	Flux Current Control	Flux current control
FD	Function Diagram	Function diagram
F-DI	Failsafe Digital Input	Fail-safe digital input
F-DO	Failsafe Digital Output	Fail-safe digital output
FEM	Fremderregter Synchronmotor	Separately excited synchronous motor
FEPROM	Flash EPROM	Non volatile read and write memory
FG	Function Generator	Function generator
FI	-	Fault current
FOC	Fiber-Optic Cable	Fiber-optic cable
FP	Function diagram	Function diagram
FPGA	Field Programmable Gate Array	Field Programmable Gate Array

A.1 List of abbreviations

Abbreviation	Source of abbreviation	Meaning
FW	Firmware	Firmware
G		
GB	Gigabyte	Gigabyte
GC	Global Control	Global Control Telegram (Broadcast Telegramm)
GND	Ground	Reference potential for all signal and operating voltages, usually defined as 0 V (also referred to as G)
GSD	Generic Station Description	Generic station description: Describes the characteristics of a PROFIBUS slave
GSV	Gate Supply Voltage	Gate Supply Voltage
GUID	Globally Unique Identifier	Globally unique identifier
H		
HF	High Frequency	High frequency
HFD	Hochfrequenzdrossel	High-frequency reactor
HMI	Human Machine Interface	Human machine interface
HTL	High-Threshold Logic	Logic with a high fault threshold
HW	Hardware	Hardware
I		
I/O	Input/Output	Input/output
I2C	Inter-Integrated Circuit	Internal serial data bus
IASC	Internal Armature Short Circuit	Internal armature short circuit
IBN	Inbetriebnahme	Commissioning
ID	Identifier	Identification
IE	Industrial Ethernet	Industrial Ethernet
IEC	International Electrotechnical Commission	International Electrotechnical Commission
IF	Interface	Interface
IGBT	Insulated Gate Bipolar Transistor	Insulated gate bipolar transistor
IGCT	Integrated Gate-Controlled Thyristor	Semiconductor power switch with integrated control electrode
IL	Impulslöschung	Pulse cancelation
IP	Internet Protocol	Internet Protocol
IPO	Interpolator	Interpolator
IT	Isolé Terré	Non-grounded three-phase power supply
IVP	Internal Voltage Protection	Internal voltage protection
J		
JOG	Jogging	Jogging

Abbreviation	Source of abbreviation	Meaning
K		
KIP	Kinetische Pufferung	Kinetic buffering
Kp	-	Proportional gain
KTY	-	Special temperature sensor
L		
L	-	Formula symbol for inductance
LED	Light Emitting Diode	Light Emitting Diode
LIN	Linear motor	Linear motor
LSB	Least Significant Bit	Least significant bit
LSC	Line-Side Converter	Line-side converter
LSS	Line Side Switch	Line side switch
LU	Length Unit	Length unit
M		
M	-	Formula symbol for torque
M	Masse	Reference potential for all signal and operating voltages, usually defined as 0 V (also referred to as GND)
MB	Megabyte	Megabyte
MCC	Motion Control Chart	Motion Control Chart
MDS	Motor Data Set	Motor data set
MLFB	Maschinenlesbare Fabrikatebezeichnung	Machine-Readable Product Code
MMC	Man-Machine Communication	Man-machine communication
MMC	Micro Memory Card	Micro memory card
MSB	Most Significant Bit	Most significant bit
MSC	Motor-Side Converter	Motor-side converter
MSCY_C1	Master Slave Cycle Class 1	Cyclic communication between master (Class 1) and slave
MSR	Motorstromrichter	Motor-side converter
MT	Machine Tool	Machine tool
N		
N. C.	Not Connected	Not connected
N...	No Report	No message or internal message
NAMUR	Normenarbeitsgemeinschaft für Mess- und Regeltechnik in der chemischen Industrie	Standardization association for measurement and control in the chemical industry
NC	Normally Closed (contact)	NC contact
NC	Numerical Control	Numerical control
NEMA	National Electrical Manufacturers Association	Standardization body in the US
NM	Nullmarke	Zero mark
NO	Normally Open (contact)	NO contact

A.1 List of abbreviations

Abbreviation	Source of abbreviation	Meaning
NSR	Netzstromrichter	Line-side converter
NVRAM	Non-Volatile Random Access Memory	Non-volatile read/write memory
O		
OA	Open Architecture	Open Architecture
OC	Operating Condition	Operating condition
OEM	Original Equipment Manufacturer	Original Equipment Manufacturer
OLP	Optical Link Plug	Fiber-optic bus connector
OMI	Option Module Interface	Option module interface
P		
p...	-	Adjustable parameters
PB	PROFIBUS	PROFIBUS
PC	Position Controller	Position Controller
PcCtrl	PC Control	Control for master
PD	PROFIdrive	PROFIdrive
PDS	Power unit Data Set	Power unit data set
PE	Protective Earth	Protective earth
PELV	Protective Extra Low Voltage	Protective extra low voltage
PEM	Permanenterregter Synchronmotor	Permanent-magnet synchronous motor
PG	Programmiergerät	Programming device
PI	Proportional Integral	Proportional integral
PID	Proportional Integral Differential	Proportional integral differential
PLC	Programmable Logic Controller	Programmable logic controller
PLL	Phase-Locked Loop	Phase-locked loop
PN	PROFINET	PROFINET
PNO	PROFIBUS Nutzerorganisation	PROFIBUS user organization
PPI	Point-to-Point Interface	Point-to-point interface
PRBS	Pseudo Random Binary Signal	White noise
PROFIBUS	Process Field Bus	Serial data bus
PS	Power Supply	Power supply
PSA	Power Stack Adapter	Power Stack Adapter
PTC	Positive Temperature Coefficient	Positive temperature coefficient
PTP	Point-To-Point	Point-to-Point
PWM	Pulse Width Modulation	Pulse width modulation
PZD	Prozessdaten	Process data
R		
r...	-	Display parameters (read-only)
RAM	Random Access Memory	Read/write memory
RCCB	Residual Current Circuit Breaker	Residual current operated circuit breaker
RCD	Residual Current Device	Residual current operated circuit breaker
RCM	Residual Current Monitor	Residual current monitor

Abbreviation	Source of abbreviation	Meaning
RFG	Ramp-Function Generator	Ramp-function generator
RJ45	Registered Jack 45	Term for an 8-pin socket system for data transmission with shielded or non-shielded multi-wire copper cables
RKA	Rückkühlanlage	Cooling unit
RO	Read Only	Read only
RPDO	Receive Process Data Object	Receive process data object
RS232	Recommended Standard 232	Interface standard for cable-connected serial data transmission between a sender and receiver (also known under EIA232)
RS485	Recommended Standard 485	Interface standard for a cable-connected differential, parallel, and/or serial bus system (data transmission between a number of senders and receivers, also known under EIA485)
RTC	Real Time Clock	Real time clock
RZA	Raumzeigerapproximation	Space vector approximation
S		
S1	-	Uninterrupted duty
S3	-	Intermittent duty
SBC	Safe Brake Control	Safe brake control
SBH	Sicherer Betriebshalt	Safe operating stop
SBR	-	Safe acceleration monitoring
SCA	Safe Cam	Safe cam
SD Card	SecureDigital Card	Secure digital memory card
SE	Sicherer Software-Endschalter	Safe software limit switch
SG	Sicher reduzierte Geschwindigkeit	Safely reduced speed
SGA	Sicherheitsgerichteter Ausgang	Safety-related output
SGE	Sicherheitsgerichteter Eingang	Safety-related input
SH	Sicherer Halt	Safe standstill
SI	Safety Integrated	Safety Integrated
SIL	Safety Integrity Level	Safety Integrity Level
SLM	Smart Line Module	Smart Line Module
SLP	Safely-Limited Position	Safely-limited position
SLS	Safely Limited Speed	Safely limited speed
SLVC	Sensorless Vector Control	Vector control without encoder
SM	Sensor Module	Sensor Module
SMC	Sensor Module Cabinet	Sensor Module Cabinet
SME	Sensor Module External	Sensor Module External
SN	Sicherer Software-Nocken	Safe software cam
SOS	Safe Operating Stop	Safe operating stop

A.1 List of abbreviations

Abbreviation	Source of abbreviation	Meaning
SP	Service Pack	Service pack
SPC	Setpoint Channel	Setpoint channel
SPI	Serial Peripheral Interface	Serial interface for connecting peripherals
SS1	Safe Stop 1	Safe stop 1 (monitored for time and ramping up)
SS2	Safe Stop 2	Safe stop 2
SSI	Synchronous Serial Interface	Synchronous serial interface
SSM	Safe Speed Monitor	Safe feedback for speed monitoring (n < nx)
SSP	SINAMICS Support Package	SINAMICS support package
STO	Safe Torque Off	Safe torque off
STW	Steuerwort	Control word
T		
TB	Terminal Board	Terminal Board
TIA	Totally Integrated Automation	Totally Integrated Automation
TM	Terminal Module	Terminal module
TN	Terre Neutre	Grounded three-phase supply network
Tn	-	Integral time
TPDO	Transmit Process Data Object	Transmit process data object
TT	Terre Terre	Grounded three-phase supply network
TTL	Transistor-Transistor Logic	Transistor-transistor logic
Tv	-	Rate time
U		
u.d.	under development	Under development: This feature is not currently available
UL	Underwriters Laboratories Inc.	Underwriters Laboratories Inc.
UPS	Uninterruptible Power Supply	Uninterruptible power supply
UTC	Universal Time Coordinated	Universal time coordinated
V		
VC	Vector Control	Vector control
Vdc	-	DC link voltage
VdcN	-	Partial DC link voltage negative
VdcP	-	Partial DC link voltage positive
VDE	Verband Deutscher Elektrotechniker	Association of German electrical engineers
VDI	Verein Deutscher Ingenieure	Association of German Engineers
VPM	Voltage Protection Module	Voltage Protection Module
Vpp	Volt peak-to-peak	Volt peak-to-peak
VSM	Voltage Sensing Module	Voltage Sensing Module

Abbreviation	Source of abbreviation	Meaning
X		
XML	Extensible Markup Language	Standard language for Web publishing and document management
Z		
ZM	Zero Mark	Zero mark
ZSW	Zustandswort	Status word

Index

A

Autotransformer, 53

B

Braking Module, 141

C

Cable Installation, 246

Cleaning the S120 Combi heat sink, 286

Components

Braking Module, 141

Control Supply Module CSM, 153

DME20 DRIVE-CLiQ Hub Module, 204

DRIVE-CLiQ cabinet bushing, 235

DRIVE-CLiQ coupling, 240

DRIVE-CLiQ Hub Module DMC20, 197

Line filter, 35

Line reactors, 40

Motor Module Booksize Compact, 119

S120 Combi Power Modules, 57

Sensor Module External SME20, 220

Sensor Module External SME25, 228

Terminal Module TM54F, 177

Control Supply Module CSM, 153

Current consumption (24 V DC), 253

D

Derating

Motor Modules Booksize Compact, 138

Derating characteristics

S120 Combi Power Modules, 100

Diagnostics

via LEDs for DRIVE-CLiQ Hub Module

DMC20, 200

Diagnostics via LEDs

Braking Module Booksize, 147

Control Supply Module, 162

Motor Module Booksize Compact, 129

S120 Combi Power Modules, 84

Sensor Module Cabinet SMC20, 216

Terminal Module TM54F, 191

Dimension drawings

Braking Module, 148

Braking resistors for Braking Modules, 167

Control Supply Module, 163

DRIVE-CLiQ cabinet gland, 236

DRIVE-CLiQ coupling, 241

DRIVE-CLiQ Hub Module DMC20, 201

DRIVE-CLiQ Hub Module External DME20, 208

Line filter, 39

Line reactors, 42

Motor Modules Booksize Compact, 130

S120 Combi Power Modules, 85

Sensor Module Cabinet SMC20, 217

Sensor Module External SME20, 224

Sensor Module External SME25, 231

Terminal Module TM54F, 193

DME20 DRIVE-CLiQ Hub Module, 204

DRIVE-CLiQ cabinet bushing, 235

DRIVE-CLiQ cable, 256

DRIVE-CLiQ coupling, 240

DRIVE-CLiQ Hub Module DMC20, 197

E

Electronics power supply, 23

EMC Directive, 245

Environmental conditions, 23

Equipotential bonding, 264

ESD information, 7

Expansion axes, 60

F

Fuses, 32

H

Heat dissipation, 265

I

Installation

Braking Module, 149

Control Supply Module, 164

DRIVE-CLiQ Hub Module DMC20, 202

- Motor Module Booksize Compact, 133
- S120 Combi Power Modules, 86
- Sensor Module Cabinet, 218
- Sensor Module External SME20/SME25, 225, 232
- Terminal Modules, 194

Interface descriptions

- Braking Module Booksize, 143
- Control Supply Module, 155
- DRIVE-CLiQ cabinet bushing, 236
- DRIVE-CLiQ coupling, 240
- DRIVE-CLiQ Hub Module DMC20, 198
- DRIVE-CLiQ Hub Module External DME20, 205
- Line filter, 37
- Line reactors, 41
- Motor Modules Booksize Compact, 122
- S120 Combi 3 axes Power Module, 64
- S120 Combi 4 axes Power Module, 67
- Sensor Module Cabinet SMC20, 212
- Sensor Module External SME20, 221
- Sensor Module External SME25, 228
- Terminal Module TM54F, 178

Isolating transformer, 54

L

LEDs

- Braking Module Booksize, 147
- Control Supply Module, 162
- Motor Module Booksize Compact, 129
- on the DRIVE-CLiQ Hub Module DMC20, 200
- S120 Combi Power Modules, 84
- Sensor Module Cabinet SMC20, 216
- Terminal Module TM54F, 191

- Line connection, 29
- Line connection voltage, 23
- Line Connections, 45
- Line disconnecter, 30
- Line filter, 35
- Line frequency, 23
- Line reactors, 40
- Line supply types, 23

M

MOTION-CONNECT cables

- DRIVE-CLiQ signal cables, 256
- Power cables, 258

Motor Module Booksize Compact, 119

Motors

- Line connection, 46

Mounting

- DRIVE-CLiQ cabinet gland, 238
- DRIVE-CLiQ coupling, 242

O

Overcurrent protection

- Line side, 30
- Solid-state circuit, 252

P

- Power cables, 258
- Power loss, 272
- Power loss calculation, 271
- Power Supply Units, 255
- Protective conductor connection and shield support
- Terminal Module TM54F, 195

R

Rated duty cycles

- Motor Modules Booksize Compact, 136
- S120 Combi Power Modules, 98

Replacing the fan

- Control Supply Module CSM, 284
- S120 Combi - internal fan, 280

Residual risks, 10

Residual risks of power drive systems, 10

Residual-current operated circuit breakers, 33

S

S120 Combi Power Modules, 57

Safety information

- Control Supply Module, 154
- DRIVE-CLiQ cabinet bushing, 235
- DRIVE-CLiQ coupling, 240
- DRIVE-CLiQ Hub Module DMC20, 197
- DRIVE-CLiQ Hub Module External DME20, 204
- Line filter, 36
- Line reactors, 40
- Motor Modules Booksize Compact, 119
- S120 Combi Modules, 171
- S120 Combi Power Modules, 61
- Sensor Module Cabinet SMC20, 211
- Sensor Module External SME20, 220
- Terminal Module TM54F, 178

Sensor Module External SME20, 220

Sensor Module External SME25, 228

Short-circuit current rating, 23

- Spare parts, 278
- Specification of encoder systems and encoders
 - Sensor Module Cabinet SMC30, 77
- Standards, 26
- Storage, 23
- System data, 23

T

- Technical data
 - Braking Module Booksize, 150
 - Braking resistors without a thermostatic switch, 169
 - Control Supply Module, 165
 - Double Motor Modules Booksize Compact, 135
 - DRIVE-CLiQ cabinet bushing, 239
 - DRIVE-CLiQ coupling, 242
 - DRIVE-CLiQ Hub Module DMC20, 203
 - DRIVE-CLiQ Hub Module External DME20, 209
 - Line filter, 39
 - Line reactors, 44
 - S120 Combi 3 axes Power Modules, 93
 - S120 Combi 4 axes Power Modules, 95
 - Sensor Module Cabinet SMC20, 219
 - Sensor Module External SME20, 226
 - Sensor Module External SME25, 233
 - Single Motor Modules Booksize Compact, 134
 - Terminal Module TM54F, 196
- Technical support, 277
- Terminal Module TM54F, 177
- Transport, 23

Siemens AG
Industry Sector
Drive Technologies
Motion Control Systems
Postfach 3180
91050 ERLANGEN
GERMANY

www.siemens.com/motioncontrol

Subject to change without prior notice
© Siemens AG 2012